D-Link®

COVr

AC3900 WHOLE HOME WI-FI SYSTEM | COVR-3902

Simple **Setup** Guide

Before You Start

① Check the contents of your Covr Wi-Fi System with the list on the right. Be sure to keep the Router and Extender close to each other during the setup process.

Covr Router COVR-2600R · Covr Extender COVR-1300E · Power Adapter x2 · Ethernet Cable · Antenna x4 · Wi-Fi Configuration Card

② Connect the four antennas to the router by screwing them in clockwise.

③ Connect the power adapter to the Covr Router and plug it into a power outlet. Wait for the 2.4G and 5G LEDs to light up solid green and then proceed to the next step.

TIP: If the Power LED does not light up, press the Power button on the back of the Router.

There are two easy ways to configure your Covr Wi-Fi System:

D-Link Wi-Fi App (iOS and Android Devices)

① Download the **D-Link Wi-Fi** app from the App Store or Google Play. Run the app and tap Add Device to get started.

Download on the App Store · GET IT ON Google Play

D-Link Wi-Fi

Browser Setup (PC/Mac/Mobile device)

① You can use either a wired (Ethernet) or wireless (Wi-Fi) connection to set up your Covr Wi-Fi System.

Wired – Connect the Ethernet port on your computer to one of the four black ports on the Covr Router.

Wireless – Connect to the Covr Wi-Fi using the Wi-Fi Name and Password on the Wi-Fi Configuration Card or the Covr Router.

or

② Type **http://covr.local./** into a web browser and follow the instructions to complete the setup.

http://covr.local./

For more support, please visit: support.dlink.com/COVR-3902

877-453-5465

Version 1.01(US) | 2017/06/26 6CV3902...02G