FLASHLIGHT INSTRUCTIONS

TURN ON

MAIN POWER SWITCH located on the **BACK** of the JumpSmart

PRESS & HOLD

the **LED FLASHLIGHT POWER BUTTON** to turn the flashlight **ON** & **OFF**

SINGLE-CLICK to cycle through modes

HIGH | LOW | S.O.S. | STROBE | OFF

For additional information, please visit:
LimitlessInnovations.com/Support or call us at: (855) 843-4828

LIMITLESS INNOVATIONS