JUMP STARTER

MULTI-FUNCTION
car jump starter

MANUAL

Made in China

Product parameters

Function keys
Start up output port
compass
USB output port 1/2
Charging input port Type-C
battery status
LED lighting
35mm
83mm
173mm

Use the steps Description

step1   step2   step3

START

step4   step5

1.Clip connected car battery positive and negative electrode
2.Plug into the host corresponding space
3.Auto ignition
4.Unplug the battery port
5.Remove clip from battery positive and negative pole

Multi-functional car jump starter

Functional Specifications

1. Car start:12V output

2. Flashlight:1W strong LED light,range>10M explosion-proof /SOS warning.

Note: Hold down the button for 3 seconds, and the LED light will be steady on. Press it again for slow flashing, press it again for fast flashing, and press it again for light off.

3.TYPE-C input:5V/2A

4.USB output:5V/2A

5. USB output:5V/2A

6.Cycle life:>1000 times

7.applicable temperature:-20C~60℃

Jump start   Laptop charging   Phone charging   SOS signal lamp   Strong light flashlight   Fault warning lamp

---

⚠ Precautions

1.Please check that the battery indicator is above 50%

2.When starting the car, the blue plug of the battery clip should be firmly inserted in place, otherwise it will affect the starting effect and even cause the melt of the joint plastic.

3.If the car does not start, check that the battery clamp is tight, if you still cannot start after 3 attempts, please do not force the start, this will cause damage, please check the vehicle for other faults

4.Do not clip on both ends of the floder,otherwise it may cause safety accidents

5.Please remove this product within 30 seconds after starting the car, otherwise it may cause a safety accident.

6.Do not disassemble the machine by yourself, which may cause safety accidents. When you disassemble the product yourself, the product will not be covered by warranty.