

HOMEDICSTM
#1 BRAND IN MASSAGE*



HOMEDICSTM
#1 BRAND IN MASSAGE*

HMC-500 MASSAGE CHAIR

Installation Manual

HMC-500 Installation Manual

STEP 1: HMC-500 arrives in one box. Open the box and take the chair out. There is an accessory box attached on the chair. The accessories include: one user manual, one power cord, and one remote control.



STEP 2: Connect the chair to power and turn on the power switch. The chair will go to the home position automatically.



STEP 3: Attach the backrest pad onto the backrest. Make sure the velcro on the backrest pad is aligned with the velcro on the backrest. Zip the backrest pad onto the backrest.



STEP 4: Place the remote control into the pocket on the left side board.

