



Mizco International Inc. Cranford, New Jersey 07016 techsupport@mizco.com www.toughtested.com



TT-PBLL26

LIFELIGHT PORTABLE PHONE CHARGER USER MANUAL

TOUGHTESTED*

Thank you for purchasing the Lifelight.

Please carefully read this manual before use, and keep it for reference in the future.

Product features	02
Operating the lifelight	03
Product specifications	04





FEATURES:

- 1. Work/emergency light
- 2. Flashlight
- 3. Built in 2600mAh battery
- 4. Side mounting magnets
- Power button
- 6. Window breaker
- 7. Removable cap
- 8. Micro USB input
- 9. USB output

CHARGING THE LIFELIGHT

- For best results fully charge the Lifelight before first use.
- Unscrew the endcap (the side opposite the flashlight).
- Connect a micro USB cable from the Lifelight to an AC wall or car charger.
- The red LED will blink to indicate charging, when the light turns blue the Lifelight is fully charged.

CHARGING YOUR PORTABLE DEVICES

- Unscrew the endcap (the side opposite the flashlight).
- Connect a charge cable between the Lifelight and your device.
- Your device will automatically start charging
- The side of the Lifelight will glow with a blue light while your device is charging.

USING THE FLASHLIGHT/WORK LIGHT

Quick press the power button to turn the flashlight on —> Quick press to activated work light on low power —> Quick press for medium power —> Quick press for high power —> Quick press to activate bug light —> Quick press to turn on emergency flashing lights —> Quick press to turn off

USING THE MAGNETS

The Lifelight comes with magnets on the side to attach to a metal surface for hands free operation.

04

USB Output: 5V/2A (10W max)

Battery Type: Lithium Ion

Battery life: 300 cycles

Operating temperature: 0-45C

Light type: LED

Worklight: 5W 160 lumens

Flashlight: 3W 100 lumens

IP Rating: IP68

©Mizco International, Inc. All rights reserved.

All trade names are registered trademarks of the respective manufacturers listed.

Cranford, New Jersey 07016 techsupport@mizco.com www.mizco.com