



E·SCOOTER



OPERATION MANUAL
HY-L5

HELMETS SAVE LIVES!

Always wear a properly fitted helmet that complies with CPSC or CE safety standards when you ride your bicycle.



Correct Fitting:

Make sure your helmet covers your forehead.



Incorrect Fitting:

Forehead is exposed and vulnerable to serious injury.

WARNING!

PLEASE READ THE USER MANUAL THOROUGHLY.

Failure to follow the basic instructions and safety precautions listed in the user manual can lead to damage to your device, other property damage, serious bodily injury, and even death.

Thank you for purchasing the Hover-1 E-Scooter. Please read all instructions carefully before using and retain this manual for future use and reference.

This manual applies to the Hover-1 E-Scooter

- In order to avoid dangers that are caused by collisions, falls, and loss of control, please learn how to ride the E-Scooter safely
- You can learn operating skills by reading the product manual and watching videos.
- This manual includes operating instructions and precautions, and users must read it carefully and follow the instructions.
- All users are responsible for any consequences caused by violating warning contents or prompt operations. Hover-1 can not be held liable.

ATTENTION

1. Use only the supplied charger with this scooter.
Charger Manufacturer: Shenzhen Gojusin Technology Co., LTD
Model: GJS150-0294200
2. The operating temperature range of the charger is 50° F-77° F (10-25° C).
3. The operating temperature range of the E-Scooter is 32-113° F (0-45° C).
4. Do not ride on icy or slippery surfaces.
5. Read the operation manual and warning labels before riding.
6. Store the E-Scooter in a dry, ventilated environment.
7. When transporting the E-Scooter, avoid violent crashes or impact.

LOW TEMPERATURE WARNING

Low temperature will affect the lubrication of moving parts inside the E-Scooter, increasing internal resistance. At the same time, in low temperatures, the discharge capacity and the capacity itself of the battery will be significantly decreased.

Use caution when riding the E-Scooter in cold temperatures (below 40 degrees F).

Doing so may increase the risk of mechanical failures of the scooter, which may lead to damage to your device, other property damage, serious bodily injury and even death.

SAFETY INSTRUCTIONS

- Keep the device away from heat sources, direct sunlight, humidity, water and any other liquids.
- Do not operate the device if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the device.
- Do not use the device if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by the manufacturer. Improper repair voids the warranty and may place the user at serious risk.
- Do not puncture or harm the exterior surface of the product in any way.
- Keep the device free from dust, lint, etc.
- Do not use this device for anything other than its intended use or purpose. Doing so may damage the device or lead to property damage, injury or death.
- This product is not a toy. Keep out of reach of children.
- Do not expose batteries, battery pack, or batteries installed to excessive heat, such as direct sunlight, or open flame.
- Do not allow hands, feet, hair, body parts, clothing or similar articles to come in contact with moving parts, wheels or drive-train, while the engine is running.

- Do not operate, or allow others to operate, the scooter, until the user understands all instructions, warnings and safety features described in this manual.
- Check with your doctor if you have a medical condition that could affect your ability to use the E-Scooter.
- Persons with head, back or neck ailments or prior surgeries to those areas of the body are not recommended to use this E-Scooter.
- Persons with any mental or physical conditions that may make them susceptible to injury or impair their physical or mental capabilities to recognize, understand and perform all of the safety instructions and to be able to assume the hazards inherent in unit use, should not use the Hover-1 E-Scooter.



NOTES:

In this manual, the above symbol with the word “NOTES” indicates instructions or relevant facts the user should remember prior to using the device.



CAUTION!

In this manual, the above symbol with the word “CAUTION” indicates a hazardous situation which, if not avoided, can cause minor or moderate injury.



WARNING!

In this manual, the above symbol with the word “WARNING” indicates a hazardous situation which, if not avoided, can cause death or serious injury.

SERIAL NUMBER

Please keep the serial number on file for warranty claims as well as proof of purchase.




INTRODUCTION

The E-Scooter is a personal transporter. Our technology and production processes are developed with strict testing for each E-Scooter. Operating the E-Scooter without following the contents of this manual may lead to damage to your E-Scooter, or bodily injury.

This manual is designed to give you the information you need for the safe operation and maintenance of your new E-Scooter. Please read it thoroughly before riding your E-Scooter.

PACKAGE CONTENTS

- Hover-1 Electric Folding Scooter
- Charging Cable
- Operation Manual



FEATURES/PARTS

- | | |
|--------------------------|----------------------|
| 1. Release Lever | 8. Handlebars(L) |
| 2. Kickstand | 9. Aluminum Frame |
| 3. LCD Display | 10. Foot Pad |
| 4. Power/Function Button | 11. LED Power Button |
| 5. Electric Brake | 12. LED Light |
| 6. Charging Port | 13. Mechanical Brake |
| 7. Throttle | 14. Handlebars(R) |

WARNING

Any E-Scooter that does not work properly can cause you to lose control and fall. Inspect the entire device thoroughly before every ride, and do not ride it until any problems have been corrected.

SPECIFICATIONS

Model:	HY-L5
Net Weight:	20.94 lbs (9. kg)
Max Supported Weight:	264 lbs (120 kg)
Min Supported Weight:	44 lbs (20 kg)
Max Speed:	Up to 13.6 mph (21.89 km/h)
Max Distance Range:	Up to 6.8 miles (10.94 km)
Minimum Turning Radius:	0°
Battery Type:	Lithium
Motor Power:	Brushless Motor
Battery Voltage:	25.2 V
Battery Capacity:	4.0 Ah
Power Requirement:	AC 100-240V, 50-60 Hz
Folding Size:	(42.52 in. x 16.92in. x 11.02in.) (108cm x 43 cm x 28 cm)
Open Size:	(38.19 in. x 16.92 in. x 42.52in.) (97 cm x 43 cm x 108 cm)
Tire Type:	Non-Pneumatic Solid Tires
Tire Size :	6.5 Inches (16.51 cm)
Brake Type:	Electronic & Mechanical Brakes

PREPARING YOUR E-SCOOTER

PLEASE READ THE FOLLOWING INSTRUCTIONS CAREFULLY


ATTACHING THE HANDLEBARS

Attach the handle bars by placing them into the appropriate sockets and twisting them in the correct direction.




NOTE: If the handlebars do not attach flush to the frame, you may need to shift the location of your throttle and brake assembly appropriately.

Tighten or loosen the throttle and brake assembly with the included hex key and make sure they are NOT touching or blocking your handlebars.



FOLDING & UNFOLDING YOUR E-SCOOTER.

Pull and hold the release lever, near the front of the foot pad, and lift the handlebars up to unfold or pull them down to fold. You will hear a click sound in both directions, this means it's now locked in place.



CONTROLS AND DISPLAY

LCD DISPLAY

Familiarize yourself with the LCD display of E-Scooter. If the readout of the LCD display of your E-Scooter is faded and unclear, you may need to recharge your device.

SPEED INDICATOR

Displays your current speed in MPH.

SPEED LEVEL INDICATOR


Displays your current speed level.

BATTERY LIFE INDICATOR

Displays your remaining battery life.

INFORMATION PANEL

Displays total mileage, current trip distance, voltage, and current trip time.



SPEED LEVEL BUTTON (+)

Press to increase top speed and acceleration.

1 – Low, 2 – Medium, 3 – High

POWER / FUNCTION BUTTON

Power ON Scooter - Press and hold for 3 seconds.

Power OFF Scooter - Press and hold for 3 seconds.

Cycle through total mileage, current trip distance, voltage, and current trip time.

SPEED LEVEL BUTTON (-)

Press to decrease top speed and acceleration.

1 – Low, 2 – Medium, 3 – High

BEFORE RIDING

WARNING

Any E-Scooter that does not work properly can cause you to lose control and fall. Do not ride a E-Scooter with a part that is damaged; replace the damaged part before riding.

It is important that you fully understand all elements of your E-Scooter. If these elements are not used correctly, you will not have full control of your E-Scooter. Before you ride, learn the functions of the various mechanisms on your scooter.

Practice using these elements of your E-Scooter at slower speeds in a flat, open area before taking the device out in public areas.

PRE-RIDE CHECKLIST

Ensure that your E-Scooter is in proper working order each and every time you ride. If a part of the scooter does not function correctly, please contact our Customer Support Center.

- Ensure the battery is fully charged before riding your scooter.
- If the E-Scooter is not to be used for an extended period of time, you may need to recharge the battery every 2 months to maintain the battery life.
- Please wear all appropriate safety and protective gear as previously mentioned in the User Manual before operating your device.
- Make sure to wear comfortable clothes and flat closed-toe shoes when operating your device.
- Please carefully read the Operation Manual, which will assist in explaining the basic working principles and provide tips on how to best enjoy your experience.

SAFETY PRECAUTIONS

The first rule in safe riding is to use common sense.

Different localities and countries have different laws governing riding on public roads, and you should check with local officials to ensure

you are complying with these laws.

Hover-1 is not liable for tickets or violations given to riders who do not follow local laws and regulations.

- For your safety, always wear a helmet that meets CPSC or CE safety standards. In the event of an accident, a helmet can protect you from serious injury and in some cases, even death.
- Obey all local traffic laws. Obey red and green lights, one-way streets, stop signs, pedestrian crosswalks, etc.
- Ride with the traffic, not against it.
- Ride defensively; expect the unexpected.
- Give pedestrians the right-of-way.
- Do not ride too close to pedestrians and alert them if you intend to pass them from behind.
- Slow down at all street intersections and look to the left and right before crossing.

Your E-Scooter is not equipped with reflectors. It is not recommended that you ride in conditions of low visibility.

If you are riding your scooter in low-visibility conditions, ensure your LED light is turned on, and that you are wearing bright, reflective clothing.



Think about safety when you ride. You can prevent many accidents if you think about safety. Below is a helpful checklist for riders.

SAFETY CHECKLIST

- Do not ride above your skill level. Ensure you have had enough

practice with all functions and features of your E-Scooter.

- Do not ride too fast – with increased speed comes increased risk. If you are moving at a higher speed, small bumps can turn into large impacts, leading to a higher risk of injury if an accident occurs.
- Do not ride with pets.
- Before stepping on your E-Scooter, make sure it is placed flat on level ground and the power is on.
- Do not try to open or modify your E-Scooter. Doing so, voids the manufacturer warranty and may cause your E-Scooter to fail, resulting in injury or death.
- Do not use the E-Scooter in a manner that would put people or property in danger.
- If you and your friend(s) are riding E-Scooters together, be sure to keep a safe distance between each other to prevent collisions, property damage, serious injuries or even death.
- Be sure to keep your feet on the scooter at all times. Moving your feet off your scooter while driving is dangerous and may cause the scooter to stop or veer sideways.
- Do not operate the E-Scooter while under the influence of drugs and/or alcohol.
- Do not operate the E-Scooter when you are restless or sleepy.
- Use your best judgment to keep yourself out of dangerous situations with your E-Scooter.
- Do not ride your E-Scooter off of curbs, ramps, or attempt to operate in a skate park, empty pool, or in any way similar to a skateboard. Misuse of your E-Scooter, voids the manufacturer warranty and may lead to injury or damage.
- Do not abuse your E-Scooter, doing so can damage your unit and cause failure to the operating system which may lead to injury. Physical abuse, including dropping your E-Scooter, voids the manufacturer warranty.
- Do not operate in or near puddles of water, mud, sand, stones, gravel, debris or near rough and rugged terrain.

- The E-Scooter can be used on paved surfaces that are flat and even. If you encounter uneven pavement, please lift your E-Scooter over and past the obstruction.
- Do not ride in inclement weather: snow, rain, hail, sleet, on icy roads or in extreme heat or cold.
- Bend your knees when riding on bumpy or uneven pavement to absorb the shock and vibration and help you keep your balance.
- If you are unsure if you can safely ride on a specific terrain, step off and carry your E-Scooter. ALWAYS BE ON THE SIDE OF CAUTION.
- Do not attempt to ride over bumps or objects greater than ½ in. even when prepared and bending your knees.
- PAY ATTENTION - look at where you are riding and be conscious of the road conditions, people, places, property and objects around you.
- Do not operate the E-Scooter in crowded areas.
- Operate your E-Scooter with extreme caution when indoors, especially around people, property, and narrow spaces.
- Do not operate the E-Scooter while talking, texting, or looking at your phone.
- Do not ride your E-Scooter where it is not permitted.
- Do not ride your E-Scooter near motor vehicles or on public roads.
- Do not travel up or down steep hills.
- The E-Scooter is intended for use by a single individual, DO NOT attempt to operate the E-Scooter with two or more people.
- Do not carry anything while riding the E-Scooter.
- Individuals with lack of balance should not attempt to operate the E-Scooter.
- Pregnant women should not operate the E-Scooter.
- Young children and the elderly should not operate the E-Scooter.
- At higher speeds, always take into consideration longer

stopping distances.

- Do not attempt to jump on or off your E-Scooter.
- Do not attempt any stunts or tricks with your E-Scooter.
- Do not ride the E-Scooter in dark or poorly lit areas.
- Do not ride the E-Scooter near or over potholes, cracks or uneven pavement or surfaces.
- Do not operate your E-Scooter off-road.
- Do not turn sharply, especially at high speeds.
- Do not exceed the maximum or minimum weight limits.
- Avoid driving the E-Scooter in unsafe places, including near areas with flammable gas, steam, liquid, dust, fiber, which could cause fire and explosion accidents.

RIDING YOUR E-SCOOTER

FAILURE TO FOLLOW ANY OF THE FOLLOWING SAFETY PRECAUTIONS CAN AND MAY LEAD TO DAMAGE TO YOUR DEVICE, VOID YOUR MANUFACTURER WARRANTY, LEAD TO PROPERTY DAMAGE, CAUSE SERIOUS BODILY INJURY, AND CAN LEAD TO DEATH.

OPERATING YOUR DEVICE

Make sure the device is fully charged before the first initial use. Before turning on your E-Scooter, ride it like a normal kick scooter to get comfortable with the device before using it with the motor.

When comfortable riding the scooter, power it on. For the motor to activate, you must first start riding the scooter and then push the throttle down.

To slow down the scooter, push the electric brake down. This will stop the motor and slow you down. Also press the mechanical brake with your foot to manually slow down the scooter.

The E-Scooter is equipped with a built-in 250 Watt Brushless Motor which allows you to accelerate (up to 13.6 mph) and decelerate.

To turn, use the handlebar to turn in the direction you wish to turn.

The E-Scooter can be operated manually if you do not wish to use the motor.

As you get comfortable on the device, you will notice it becomes easier to maneuver. Remember at higher speeds, it is necessary to shift your weight to overcome the centrifugal force.

Bend your knees if you encounter bumps or uneven surfaces, then dismount and carry your E-Scooter to a safe operating surface.

WARNING

Do not turn sharply or at high speeds to avoid danger. Do not turn or ride quickly along slopes, as it may cause injury.

WEIGHT AND SPEED LIMITATIONS

Speed and weight limits are set for your own safety. Please do not exceed the limits listed here in the manual.

- Maximum Weight: 264 lbs
- Minimum Weight: 44 lbs
- Maximum Speed: Up to 13.6 mph

WARNING

Overweight exertion on the device may increase possibility of injury or product damage.

OPERATING RANGE

The E-Scooter can travel a distance up to 7.5 miles on a fully charged battery in ideal conditions. The following are some of the major factors that will affect the operating range of your device.

- Terrain: Riding distance is highest when riding on a smooth, flat surface. Riding uphill and/or on rough terrain will reduce distance significantly.
- Weight: A lighter user will have further range than a heavier user.
- Ambient temperature: Please ride and store the device under recommended temperatures, which will increase driving distance; battery life, and overall performance of your device.
- Speed and Riding Style: Maintaining a moderate and consistent speed while riding produces maximum distance. Traveling at high speeds for extended periods, frequent starts and stops, idling and frequent acceleration or deceleration will decrease overall distance.

SAFETY ALERTS

While riding your E-Scooter, if there is a system error or illegal operation performed the device will prompt the user in a variety of ways.

The following are common occurrences where you will see Safety Alerts. These notices should not be ignored, but appropriate action should be taken to correct any illegal operation, failure or errors.

- Prohibited riding surfaces (uneven, too steep, unsafe, etc.)
- Battery voltage is too low.
- The device is still charging.
- Overheating, or motor temperature is too high.
- If the system enters protection mode, the alarm indicator will light up. This typically occurs when the battery is about to run out

of power.

- If any or both tires are blocked, the device will stop after 2 seconds.
- When the battery level has depleted below protection mode, the device engine will power off after 15 seconds.

While sustaining a high discharge current during use (such as riding up a steep slope for a long period of time), the device engine will power off after 15 seconds.

CHARGING YOUR E-SCOOTER

CHARGING THE DEVICE

- Ensure that the charging port is clean and dry.
- Make sure that there is no dust, debris or dirt inside the port.
- Plug the charger into a grounded wall outlet.
- Connect the cable with the power supply (100V ~ 240V; 50, 60 Hz).
- Align and connect the 1-pin charging cable into the charging port of the E-Scooter. **DO NOT FORCE OR BEND THE CHARGING CABLE INTO THE CHARGING PORT, AS IT MAY CAUSE THE PRONGS TO BEND OR BREAK.**
- The charging indicator light should change to RED, indicating that your device is now being charged.
- When the RED indicator light on your charger turns to GREEN, then your device is fully charged.
- A full charge may take up to 2.5 hours.
- After fully charging your E-Scooter, unplug the charger from your device and from the power outlet.

BATTERY CARE / MAINTENANCE

BATTERY SPECIFICATIONS

Battery Type: Rechargeable lithium-ion battery

Charge Time: Up to 2.5 hours

Voltage: 25.2V

Initial Capacity: 4.0 AH

Working Temperature: 32°F - 113°F

Charging Temperature: 50°F - 77°F

Storage Time: 1 year

Storage Temperature: -4°F - 77°F

Storage Humidity: 5% - 95%

BATTERY MAINTENANCE

The lithium-ion battery is built into the device. Do not disassemble the device to remove the battery or attempt to separate it from the device.

- When charging the device, please use the enclosed 1-pin charging cable or otherwise ensure that the battery charging conditions are met.
- Do not connect or attach the device or the battery to a power supply plug or directly to a car's cigarette lighter.
- Do not place the device or batteries near a fire, or into direct sunlight. Heating the device and/or the battery can cause additional heating, breaking, or ignition of the battery inside the device.
- Do not continue charging the battery if it does not recharge within the specified charging time. Doing so may cause the battery to become hot, rupture, or ignite.

To preserve natural resources, please recycle or dispose of batteries properly. This product contains lithium-ion batteries. Local, state, or federal laws may prohibit disposal of lithium-ion batteries in ordinary trash. Consult your local waste authority for information regarding available recycling and/or disposal options.



WARNING

Failure to follow the safety precautions listed below could lead to serious bodily injury and/or death.

- Do not attempt to modify, change, or replace your battery.
- Do not use your device if the battery begins to emit odor, overheats, or begins to leak.
- Do not touch any leaking materials or breathe fumes emitted.
- Do not allow children and animals to touch the battery.
- The battery contains dangerous substances, do not open the battery, or insert anything into the battery.
- Please only use the charger provided by Hover-1.
- Do not attempt to charge the device if the battery has discharge or emits any substances. In that case, immediately distance yourself from the battery in case of fire or explosion.

- Lithium-ion batteries are considered to be hazardous materials. Please follow all local, state and federal laws in regards to recycling, handling and disposing of Lithium-ion batteries.

WARNING

SEEK IMMEDIATE MEDICAL ASSISTANCE IF YOU ARE EXPOSED TO ANY SUBSTANCE THAT IS EMITTED FROM THE BATTERY.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CARE & MAINTENANCE

- Do not expose the device to liquid, moisture, or humidity to avoid damage to the product's internal circuitry.
- Do not use abrasive cleaning solvents to clean the device.
- Do not expose the device to extremely high or low temperatures as this will shorten the life of the electronic device, destroy the battery, and/or distort certain plastic parts.
- Do not dispose of the device in fire as it may explode or combust.
- Do not expose the device to contact with sharp objects as this will cause scratches and damage.
- Do not let the device fall from high places, as doing so may damage the internal circuitry.
- Do not attempt to disassemble the device.
- Use only the charger provided by Hover-1.

WARNING

Avoid using water or other liquids for cleaning. If water or other liquids enter the E-Scooter, it will cause permanent damage to the internal components.

WARNING

Users who disassemble the E-Scooter scooter without permission will void the warranty.

WARRANTY

This product comes with a 30 day limited replacement warranty for manufacturer's defects. This includes defects to the motor, battery, etc.

This product comes with a 120 day parts and labor warranty. Shipping & handling costs are not included.

The condition of this warranty and our responsibilities under this warranty are as follows:

Manufacturer's warranty is non-transferable. And this warranty is limited to the original purchaser only.

* You must be able to prove the date of original purchase of the device with a dated receipt.

* Warranty period begins on date of purchase, not date of first use.

* The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or repair by unauthorized third party.

* The responsibility of manufacturer shall be limited to the repair or replacement of the product at its sole discretion.

* Specifically exempt from any warranty are limited-life consumable components subject to normal wear and tear such as tires, decorates and other accessories.

* The manufacturer will not take any responsibility if the failure of the unit has resulted from accident, abuse, misuse, or any unauthorized repair, modification or disassembly.

* Modification and repair of the device should be done by authorized and qualified service personnel or the manufacturer.

* This warranty gives you specific legal rights, and you may also have other rights which vary under local laws.

The following conditions comprise the requirements and scope of our warranty conditions and do not affect our legal and contractual warranty obligations.

We offer a warranty on our products in accordance with the

following conditions:

1) The warranty does not cover over-charging, or damages due to improperly maintaining lithium-ion battery installed in unit. The warranty does not cover tires and other parts, which are considered consumables, parts that break easily such as glass or plastic or defects based on normal wear and tear. There is not warranty obligation in the event of marginal differences compared to the target appearance and workmanship provided these have a negligible effect on the product's fitness for use, in the event of damage caused by chemical or electrochemical effects, by water or generally from abnormal conditions.

2) The warranty will be performed in such a way that we shall decide whether to repair the defective parts or to replace them with working parts free of charge. Hover-1 reserves the right to exchange the product for a replacement product of equal value if the product sent in cannot be repaired within a reasonable time or at a reasonable cost. All repairs are performed at a Hover-1 facility. Parts that have been replaced or exchanged become property of Hover-1.

3) The warranty claim does not apply if repairs or other work is carried out by unauthorized persons or if our products are equipped with additional parts or accessories that are not approved for the E-Scooter.

4) Warranties that have been activated do not cause the warranty period to be extended, nor do they trigger a new warranty period. The warranty period for any replacement parts installed ends with the warranty period for the entire product.

5) Any other further claims are excluded, especially those for replacement due to damage caused to the outside of the product, provided there is no obligatory legal liability.

We therefore accept no liability for accidental, indirect or other consequential damage of any kind, which leads to usage restrictions, data loss, and loss of earnings or interruption to business.

Asserting a warranty claim:

1) To make use of the warranty services, you must contact the Hover-1 Service Center by visiting www.Hover-1.com or emailing support@hover-1.com

2) Hover-1 will try to diagnose and solve your problem. If it is determined that a warranty claim exists, you will be given an RMA number (Return Material Authorization) and will be asked to send the product to Hover-1.

IMPORTANT: Hover-1 will only accept parcels that have an RMA number.

Please observe the following when sending the product:

1) Send the product suitably packaged with carriage and insurance paid. The charger **MUST** be included. Use only a carrier that provides tracking.

2) Mark the RMA number on the outside of the package in such a way that is visible and clearly legible.

3) You must enclose a copy of the receipt as proof of purchase.

4) Once Hover-1 has received the product, it will meet its warranty obligations in accordance with the warranty conditions and will return the product to the sender. Outbound return shipping will be paid by Hover-1.

SERVICE OUTSIDE OF WARRANTY

Hover-1 can refuse any service claim made that is not covered by the warranty. Please contact support@hover-1.com for pricing and availability of repairs, outside of warranty.

If Hover-1 agrees to provide a service outside the warranty, the customer will be invoiced for all repair and transport costs. Hover-1 will not accept any packages that have not first been approved by Hover-1 by means of an RMA (Return Material Authorization).

Contact us with questions at:

support@Hover-1.com

www.Hover-1.com

Hover-1

Edison, NJ 08837

Affix Serial Number Label Here:

DESIGN

E-Scooter is designed to be easily controlled, providing a safe stable form of travel. The E-Scooter is equipped with a built-in 250 Watt brushless motor which allows you to accelerate (up to 13.6 mph) and decelerate. The electronic brakes allow for smooth stopping. The E-Scooter only requires 2.5 hours of charging for a full charge.

PERFORMANCE

E-Scooter is a two-wheel electric scooter. It provides a convenient, stable form of transportation allowing you to travel up to 6.8 miles at up to 13.6 mph.

- TRAVEL UP TO 6.8 MILES
- MAXIMUM SPEED OF UP TO 13.6 MPH
- SUPPORTS UP TO 264 LBS
- FULLY CHARGES IN UP TO 2.5 HOURS