

## 1

To unfold your HIGHLANDER, press down on the rear wheel fender and pull the steering column up. Raise the safety lock up and push it into place to secure the steering column, twist the black piece in the center to lock it. Ensure the steering column is secured in place.



## 2

Attach the handle bars by placing them into the appropriate sockets and twist them in the correct direction.



## 3

Fully charge your HIGHLANDER for up to 3 hours before using it for the first time.



## 4

Before turning on your HIGHLANDER ride it like a normal kick scooter to get comfortable with the device before using it with the motor.




## 5

When comfortable riding the scooter, power it on. **You must first kick off the ground** and then press the throttle **for the motor to start**. To slow down the scooter, squeeze the brake handle.




## You must first kick off the ground for the motor to start.

## CONTROLS AND DISPLAY



- A Electric Brake:** Press and hold to slow down the scooter.
- B LED Display:** Shows current speed, battery level.
- C Power Button:**  
Power ON/OFF Scooter:  
Press and hold for 2 seconds.  
Engage LED Headlights:  
Press twice  
Switch Eco/Normal/Sport Mode:  
Press once
- D Throttle:** Press and hold to accelerate the scooter.

## LCD DISPLAY



- 1. SPEEDOMETER**  
Displays your current speed in mph or (km/h).
- 2. SPEED UNIT**  
Indicates if speed shown is mph or km/h.
- 3. BATTERY INDICATOR**  
Displays current battery level
- 4. HEADLIGHT ICON**  
Displays when headlights are on
- 5. SPEED MODE**  
Indicates current speed mode.  
Off = Eco  
Blue S = Normal  
Red S = Sport



@RideHover1



@RideHover1



@RideHover1



www.Hover-1.com