

INSIGNIA™

USER GUIDE

Stand for PS4™ Slim/Pro

NS-GPS4UVS19



Console not included

Before using your new product, please read these instructions to prevent any damage.

Contents

Introduction	2
Features	2
Package contents	3
Setting up your vertical stand.....	4
Setting up your PS4 Pro system.....	4
Setting up your PS4 Slim system.....	6
ONE-YEAR LIMITED WARRANTY	8

Introduction

Congratulations on your purchase of a high-quality Insignia product. Your NS-GPS4UVS19 represents the state of the art in vertical game console stand design and is designed for reliable and trouble-free performance.

IMPORTANT SAFEGUARDS

CAUTION


- 1 Read these instructions.
- 2 Keep these instructions.
- 3 Heed all warnings.
- 4 Follow all instructions.
- 5 Clean only with a damp cloth.
- 6 Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 7 Do not put any extreme pressure on this product.

Features


- Designed to hold a PS4 Slim or PS4 Pro game console
- Provides a stable platform for your game console
- Rubber feet help keep your game console from sliding on most surfaces

Package contents


- Vertical stand
- PS4 Slim adapter
- Mounting screw
- *User Guide*



Vertical stand (part A)



Vertical stand (part B)



PS4 Slim adapter



Mounting screw

Setting up your vertical stand


CAUTION:

- Unplug and remove all cables from your game console before mounting it on the vertical stand.
- Perform all work on a flat, firm surface to prevent damage to the vertical stand or your game console.


Setting up your PS4 Pro system

Note: If you have a PS4 Slim, go to [Setting up your PS4 Slim system](#) on page 6.


- 1 Unplug and remove all cables from your game console.
- 2 Slide the vertical stand parts A and B together. Make sure that the stand parts are flush with each other. The stand parts only fit together one way.



- 3 Remove the Slim adapter parts from the top of your vertical stand.




- 4 Place the Slim adapter parts on each side of the bottom of your vertical stand, then remove the mounting screw from the bottom of your stand.




- 5 Using both hands, carefully stand your PS4 Pro game console upside down on a table, with the bottom facing up.
- 6 Place your stand on the bottom of your console so that the holes line up.


Note: The vertical stand has two mounting holes. Use the hole next to the **PRO** label.



- 7 Secure your stand to the bottom of your console with the mounting screw. Tighten the screw with a coin or a flat-blade screwdriver to make sure that your stand is tight against the bottom of your game console. Do not over-tighten the screw.




- Using both hands, turn your console and vertical stand assembly upright, then reattach all cables and plug in your game console.




Setting up your PS4 Slim system

- Unplug and remove all cables from your game console.
- Slide the vertical stand parts A and B together. Make sure that the stand parts are flush with each other. The stand parts only fit together one way.




- Remove the mounting screw the bottom of your stand.




- Using both hands, carefully stand your PS4 Slim game console upside down on a table, with the bottom facing up.

- 5 Place your stand on the bottom of your console so that the holes line up.


Note: The vertical stand has two mounting holes. Use the hole next to the **SLIM** label.



- 6 Secure your stand to the bottom of your console with the mounting screw. Tighten the screw with a coin of a flat-blade screwdriver to make sure that your stand is tight against the bottom of your game console. Do not over-tighten the screw.



- 7 Using both hands, turn your console and vertical stand assembly upright, then reattach all cables and plug in your game console.



ONE-YEAR LIMITED WARRANTY

Definitions:

The Distributor* of Insignia branded products warrants to you, the original purchaser of this new Insignia-branded product ("Product"), that the Product shall be free of defects in the original manufacturer of the material or workmanship for a period of one (1) year from the date of your purchase of the Product ("Warranty Period").

For this warranty to apply, your Product must be purchased in the United States or Canada from a Best Buy branded retail store or online at www.bestbuy.com or www.bestbuy.ca and is packaged with this warranty statement.

How long does the coverage last?

The Warranty Period lasts for 1 year (365 days) from the date you purchased the Product. Your purchase date is printed on the receipt you received with the Product.

What does this warranty cover?

During the Warranty Period, if the original manufacture of the material or workmanship of the Product is determined to be defective by an authorized Insignia repair center or store personnel, Insignia will (at its sole option): (1) repair the Product with new or rebuilt parts; or (2) replace the Product at no charge with new or rebuilt comparable products or parts. Products and parts replaced under this warranty become the property of Insignia and are not returned to you. If service of Products or parts are required after the Warranty Period expires, you must pay all labor and parts charges. This warranty lasts as long as you own your Insignia Product during the Warranty Period. Warranty coverage terminates if you sell or otherwise transfer the Product.

How to obtain warranty service?

If you purchased the Product at a Best Buy retail store location or from a Best Buy online website (www.bestbuy.com or www.bestbuy.ca), please take your original receipt and the Product to any Best Buy store. Make sure that you place the Product in its original packaging or packaging that provides the same amount of protection as the original packaging.

To obtain warranty service, in the United States and Canada call 1-877-467-4289. Call agents may diagnose and correct the issue over the phone.

Where is the warranty valid?

This warranty is valid only in the United States and Canada at Best Buy branded retail stores or websites to the original purchaser of the product in the country where the original purchase was made.

What does the warranty not cover?

This warranty does not cover:

- Customer instruction/education
- Installation
- Set up adjustments
- Cosmetic damage
- Damage due to weather, lightning, and other acts of God, such as power surges
- Accidental damage
- Misuse
- Abuse
- Negligence
- Commercial purposes/use, including but not limited to use in a place of business or in communal areas of a multiple dwelling condominium or apartment complex, or otherwise used in a place of other than a private home.
- Modification of any part of the Product, including the antenna
- Display panel damaged by static (non-moving) images applied for lengthy periods (burn-in).
- Damage due to incorrect operation or maintenance
- Connection to an incorrect voltage or power supply

- Attempted repair by any person not authorized by Insignia to service the Product
- Products sold "as is" or "with all faults"
- Consumables, including but not limited to batteries (i.e. AA, AAA, C etc.)
- Products where the factory applied serial number has been altered or removed
- Loss or Theft of this product or any part of the product
- Display panels containing up to three (3) pixel failures (dots that are dark or incorrectly illuminated) grouped in an area smaller than one tenth (1/10) of the display size or up to five (5) pixel failures throughout the display. (Pixel based displays may contain a limited number of pixels that may not function normally.)
- Failures or Damage caused by any contact including but not limited to liquids, gels or pastes.

REPAIR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS YOUR EXCLUSIVE REMEDY FOR BREACH OF WARRANTY. INSIGNIA SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR THE BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, INCLUDING, BUT NOT LIMITED TO, LOST DATA, LOSS OF USE OF YOUR PRODUCT, LOST BUSINESS OR LOST PROFITS. INSIGNIA PRODUCTS MAKES NO OTHER EXPRESS WARRANTIES WITH RESPECT TO THE PRODUCT, ALL EXPRESS AND IMPLIED WARRANTIES FOR THE PRODUCT, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF AND CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE WARRANTY PERIOD SET FORTH ABOVE AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THE WARRANTY PERIOD. SOME STATES, PROVINCES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.

Contact Insignia:

1-877-467-4289

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies.

*Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2019 Best Buy. All rights reserved.

Made in China

INSIGNIA™

www.insigniaproducts.com

1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)

INSIGNIA is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2019 Best Buy. All rights reserved.

Made in China

V1 ENGLISH
19-0392