

# Omega 4K/UHD Two-Input Switcher for HDMI and USB with USB Hub

AT-OME-MH21



The Atlona **AT-OME-MH21** is a compact, versatile switcher with HDMI and USB-C inputs. It is equipped with features for complete AV integration in huddle rooms and small meeting spaces, including automatic switching and display control, audio de-embedding, and a USB 3.0 hub for video conferencing peripherals or touch displays. Part of the Omega™ Series of integration products for modern AV communications and collaboration, the OME-MH21 is HDCP 2.2 compliant and supports 4K HDR and 4K/60 4:4:4 at HDMI data rates up to 18 Gbps. Additionally, 4K downscaling to 1080p @ 60, 30, or 24 Hz is available when connected to an HD display. The OME-MH21 includes USB 3.0 and USB-C interfaces for two host PCs, plus two peripheral devices such as a camera, microphone, speakerphone, touch-enabled display, or keyboard and mouse.

## **Package Contents**

- 1 x AT-OME-MH21
- 1 x USB-C cable
- 1 x IR emitter
- 1 x 5-pin captive screw connector
- 1 x 4-pin captive screw connector
- 2 x Mounting brackets
- 4 x Mounting screws
- 4 x Rubber feet
- 1 x 5 V DC power supply
- 1 x IEC power cord
- 1 x Installation Guide




**IMPORTANT:** Visit http://www.atlona.com/product/AT-OME-MH21 for the latest firmware updates and documentation.





## **Panel Descriptions**



#### 1 PWR

This LED indicator glows solid green when the unit is powered.

#### 2 DISPLAY

Press and release this button to toggle power on the connected display.

#### 3 INPUT

Press and release this button to toggle between the HDMI and USB-C input. A solid green LED indicator will display the currently active input. Each LED indicator corresponds to the input on the rear panel of the unit.

#### 4 IP MODE

Press and release this button, next to the green LED indicator, to switch the IP mode between DHCP and static IP modes. The LED indicator will provide the current IP mode. Refer to IP Configuration (page 8) for more information.

#### 5 RESET

Press and release this button to reset the unit to factory-default settings. Refer to Resetting to Factory-Defaults (page 9) for more information.

## 6 SHOW IP

Press and release this button to display the IP address of the AT-OME-MH21 on the connected display.



## **Panel Descriptions**



#### 1 INPUT

Connect a USB-C source to the USB-C port. Connect an HDMI cable from the HDMI port to a UHD/HD source.

## 2 OUTPUT

Connect an HDMI cable from the HDMI output to a display or other sink device. Connect an audio output device to this port using the included 5-pin captive screw block. Refer to Audio Output Connector (page 4) for wiring information.

## 3 USB HUB

Connect a USB device to each of these ports.

#### 4 HOST USB

Connect to a computer using a USB-B to USB-A cable.

## 5 RS-232 / IR OUT

Connect the included 4-pin captive screw block to this receptacle. The RS-232 port provides RS-232 control for the AT-OME-MH21 and the connected display. Refer to RS-232 and IR (page 5) for more information.

## 6 LAN

Connect an Ethernet cable to this port to control the unit and/or to pass Ethernet to a local device.

#### 7 DC 5V


Connect the included locking 5 V DC power supply to this power receptacle.






## **Audio Output Connector**

The AT-OME-MH21 provides two-channel LPCM audio de-embedding of the source device, using a dedicated audio output port.





- 1. Use wire strippers to remove a portion of the cable jacket.
- 2. Remove at least 3/16" (5 mm) of insulation from each of the wires.
- 3. Insert the wires into the correct terminals using the included 5-pin captive screw connector.
- 4. Attach the 5-pin connector block to the OUTPUT audio port on the AT-OME-MH21.





#### RS-232 and IR


The AT-OME-MH21 provides control using RS-232 and/or IR. This step is optional.

- 1. Use wire strippers to remove a portion of the cable jacket.
- Remove at least 3/16" (5 mm) from the insulation of the RX, TX, and GND wires for the RS-232 connection.
- 3. Insert the TX, RX, and GND wires into correct terminal using one of the included 4-pin captive screw connectors.
- 4. Repeat step 2 for the S and GND wires for the IR connection.
- 5. Insert the S (signal) wire in to the TX terminal and the ground wire to the GND terminal.
- 6. Tighten the captive screws to secure the wires in place. Do not over-tighten or use high-torque devices to prevent damage to the connector block.



**NOTE:** Typical DB9 connectors use pin 2 for TX, pin 3 for RX, and pin 5 for ground. On some devices functions of pins 2 and 3 are reversed. Note that the signal (S) pin for the IR is labeled as "TX" on the port.









AT-OME-MH2<sup>-</sup>

#### Installation

- Connect a USB-C device to the INPUT 1 port.
- 2. Connect an HDMI cable from the **INPUT 2** port to a UHD/HD source device.
- 3. Connect an HDMI cable from the HDMI **OUTPUT** port to a display device.
- 4. OPTIONAL: Connect an audio output device to this port using the included captive screw block. Refer to Audio Output Connector (page 4) for wiring information.
- 5. Connect up to two USB devices to the USB HUB ports.
- 6. Connect a computer to the **HOST USB** port, using a USB-A to USB-B cable.
- 7. OPTIONAL: Connect a serial cable from **RS-232** port to a display device. Refer to **RS-232** and **IR** (page 5) for wiring information. Connect an IR emitter to the **IR OUT** port.
- 8. Connect an Ethernet cable to the **LAN** port to control the AT-OME-MH21.
- 9. Connect the included 5 V DC power supply from this receptacle to an available AC outlet.







## **Mounting Instructions**

The AT-OME-MH21 includes two mounting brackets, which can be used to attach the unit to any flat surface. Use the two enclosure screws, on the sides of the unit to attach the mounting brackets.

 Using a small Phillips screwdriver, remove the two screws from the left side of the enclosure.



- Position one of the mounting brackets, as shown below, aligning the holes on the side of the enclosure with one set of holes on the mounting bracket.
- 3. Use the screws from Step 1 to attach the mounting bracket.



- Repeat steps 1 and 2 to attach the second mounting bracket to the opposite side of the unit.
- Mount the unit to a flat surface using the oval-shaped holes, on each mounting bracket. If using a drywall surface, a #6 drywall screw is recommended.





**NOTE:** Mounting brackets can also be inverted to mount the unit under a table or other flat surface.



AI-UIVIE-IVIHZ I

## **IP Configuration**

The AT-OME-MH21 is shipped with DHCP enabled. Once connected to a network, the DHCP server (if available), will automatically assign an IP address to the unit. If the AT-OME-MH21 is unable to detect a DHCP server within 15 seconds, then the unit will use a self-assigned IP address within the range of **169.254.xxx.xxx**.

Use an IP scanner, along with the MAC address on the bottom of the unit, to identify the unit on the network. If a static IP address is desired, the unit can be switched to static IP mode. The default static IP address is 192.168.1.254.

## Switching the IP mode

- 1. Make sure the AT-OME-MH21 is powered
- 2. Press and hold the **IP MODE** button, on the rear of the unit, for approximately five seconds.



3. Release the button once the LED indicator, next to the **IP MODE** button, begins to flash green. The number of flashes will indicate the currently selected IP mode.

IP MODE LED flashes	Description	
Two	Factory Static IP mode (IP address set to 192.168.1.254)	
Four	DHCP mode	

## Displaying the IP Address

To display the IP address of the AT-OME-MH21, on the connected display, press and release the **SHOW IP** button on the front panel.







## Resetting to Factory-Defaults

To reset the AT-OME-MH21 to factory-default settings, press and hold the **RESET** button for approximately 5 seconds. Release the button when the **RESET** LED indicator begins to flash. The LED indicator will flash three times to indicate that the reset procedure has completed.



## **AMS 2.0**

For easy configuration of Atlona devices, AMS 2.0 is available from https://atlona.com/AMS for free. Once AMS has been setup, following the instructions below.

- 1. Open a browser on the same network as AMS 2.0 and go to the IP of AMS 2.0. View the AMS 2.0 installation instructions on how to find the IP of the software, if necessary.
- 2. Enter the login information on the AMS 2.0 web page, then click the Login button.
- 3. View the AT-OME-MH21 manual for routing and configuration information.


#### **Web Server**

The AT-OME-MH21 includes a built-in web server, which allows easy management and control of all features. Follow the instructions below to access the web server.

- Set the IP mode of the AT-OME-MH21. Refer to IP Configuration (page 8) for more information.
- Connect an Ethernet cable from the LAN port on the AT-OME-MH21 to the Local Area Network (LAN).
- Connect an HDMI cable from the AT-OME-MH21 to a display, then press the SHOW IP button on the front panel to display the IP address.
- 4. Launch a web browser and enter the IP address of the unit.
- 5. The AT-OME-MH21 **Login** page will be displayed.
- 6. Enter the following information on the **Login** page. Login credentials are case-sensitive.

Login: admin Password: Atlona

Click the Login button.





## **Front Panel LED Indicators**

The LED indicators on both the front and rear of the unit provide basic information on the current status of the unit.

PWR		Description	
Solid green		Unit is receiving power using the optional 24 V DC power supply.	
Off	0	Unit is not powered.	

1, 2	Description	
Solid green	The input is the currently selected input.	
Off	O The input is not selected.	

IP MODE		Description
Flashes green (4x)	*	Flashes four times to indicate that the unit is being set to DHCP mode. Refer to IP Configuration (page 8) for more information.
Flashes green (2x)	*	Flashes four times to indicate that the unit is being set to DHCP mode. Refer to IP Configuration (page 8) for more information.
Off	0	Normal operating mode.



## Installation Guide

	a <b>Panduit</b> company	AT-OME-MH2
Natas		
Notes		
		,



## **English Declaration of Conformity**

The English version can be found under the resources tab at:

https://atlona.com/product/at-ome-mh21/.



## Chinese Declaration of Conformity 中国RoHS合格声明

由SKU列出於:

https://atlona.com/about-us/china-rohs/.





The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI licensing Administrator, Inc.



Toll free US International atlona.com • 877.536.3976 • 41.43.508.4321

© 2020 Atlona Inc. All rights reserved. "Atlona" and the Atlona logo are registered trademarks of Atlona Inc. All other brand names and trademarks or registered trademarks are the property of their respective owners. Pricing, specifications and availability subject to change without notice. Actual products, product images, and online product images may vary from images shown here.