

PS4 Universal Vertical Stand

NS-GPS4UVS18/NS-GPS4UVS18-C



* Console not included.

Before using your new product, please read these instructions to prevent any damage.

Contents

- Introduction 2
- Important Safety Instructions..... 2
- Features 3
 - Package contents 3
- Setting up your vertical stand 4
 - Setting up your PS4 Pro system..... 4
 - Setting up your PS4 Slim system..... 6
 - Setting up your PS4 system 9
- ONE-YEAR LIMITED WARRANTY..... 11

Introduction

Congratulations on your purchase of a high-quality Insignia product. Your NS-GPS4UVS18 represents the state of the art in vertical game console stand design and is designed for reliable and trouble-free performance.

Important Safety Instructions

CAUTION


- 1 Read these instructions.
- 2 Keep these instructions.
- 3 Heed all warnings.
- 4 Follow all instructions.
- 5 Clean only with damp cloth.
- 6 Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 7 Do not put any extreme pressure on this product.

Features


- Specifically designed to hold PS4, PS4 Slim, and PS4 Pro game consoles
- Provides a stable platform for your game console
- Equipped with rubber feet to keep your game console from sliding on the desktop (most surfaces)

Package contents

- Vertical stand
- PS4 Slim adapter
- PS4 Rubber locks (2)
- Mounting screw



Vertical stand



PS4 Slim adapter



PS4 Rubber locks



Mounting screw


Setting up your vertical stand

Caution

- Unplug and remove all cables from your game console before mounting it on the vertical stand.
- Perform all work on a flat, firm surface to prevent damage to the vertical stand or your game console.

Setting up your PS4 Pro system


- 1 Unplug and remove all cables from your game console.
- 2 Remove the mounting screw from the bottom of the vertical stand with your fingertip.




- 3 Using both hands, carefully stand your PS4 Pro game console upside down on a table, with the bottom facing up.
- 4 Place the vertical stand on the bottom of your PS4 Pro so that the holes line up.

Note


The vertical stand has two mounting holes. Use the hole that matches the mark shown in the graphic below.



- 5 Use the mounting screw to secure the vertical stand to the bottom of your PS4 Pro game console. Tighten the screw with a coin or flat blade screwdriver.




- 6 Make sure that the vertical stand is tight against the bottom of your game console. Do not overtighten the screw.
- 7 Using both hands, turn the game console/vertical stand assembly upright, then reattach all cables and plug in your game console.




Setting up your PS4 Slim system


- 1 Unplug and remove all cables from your game console.
- 2 Locate the front marking on the top of the vertical stand and the front of the PS4 Slim console.



- 3 Remove the mounting screw and the adapter from the bottom of the vertical stand.




- 4 Attach the adapter to the vertical stand, making sure that the adapter is properly seated in the stand.




- 5 Using both hands, carefully stand your PS4 Slim game console upside down on a table, with the bottom facing up.
- 6 Place the vertical stand on the bottom of your PS4 Slim so that the holes line up.

Note


The vertical stand has two mounting holes. Use the hole that matches the mark shown in the graphic below.



- 7 Use the mounting screw to secure the vertical stand to the bottom of your PS4 Slim game console. Tighten the screw with a coin or flat blade screwdriver.




- 8 Make sure that the vertical stand is tight against the bottom of your game console. Do not overtighten the screw.
- 9 Using both hands, turn the game console/vertical stand assembly upright, then reattach all cables and plug in your game console.



Setting up your PS4 system


- 1 Unplug and remove all cables from your game console.
- 2 Remove the rubber locks from the bottom of the vertical stand with your fingertips.




- 3 Attach the rubber locks to the stand using the lock that matches the marking shown in the illustration below.

Note

The vertical base and rubber locks are not symmetrical, so make sure that you attach the rubber lock that corresponds to the marking on the vertical base (F to Front).



- 4 Attach your PS4 game console to the stand. The front of the vertical stand and the PS4 game console should be facing the same direction.



- 5 Make sure that the vertical stand is correctly aligned and that the assembly is stable before moving it. Take care when moving it to make sure that the stand and console stay together.
- 6 Reattach all cables and plug in your game console.

ONE-YEAR LIMITED WARRANTY

Definitions:

The Distributor* of Insignia branded products warrants to you, the original purchaser of this new Insignia-branded product ("Product"), that the Product shall be free of defects in the original manufacturer of the material or workmanship for a period of one (1) year from the date of your purchase of the Product ("Warranty Period").

For this warranty to apply, your Product must be purchased in the United States or Canada from a Best Buy branded retail store or online at www.bestbuy.com or www.bestbuy.ca, and is packaged with this warranty statement.

How long does the coverage last?

The Warranty Period lasts for 1 year (365 days) from the date you purchased the Product. Your purchase date is printed on the receipt you received with the Product.

What does this warranty cover?

During the Warranty Period, if the original manufacture of the material or workmanship of the Product is determined to be defective by an authorized Insignia repair center or store personnel, Insignia will (at its sole option): (1) repair the Product with new or rebuilt parts; or (2) replace the Product at no charge with new or rebuilt comparable products or parts. Products and parts replaced under this warranty become the property of Insignia and are not returned to you. If service of Products or parts are required after the Warranty Period expires, you must pay all labor and parts charges. This warranty lasts as long as you own your Insignia Product during the Warranty Period. Warranty coverage terminates if you sell or otherwise transfer the Product.

How to obtain warranty service?

If you purchased the Product at a Best Buy retail store location, please take your original receipt and the Product to any Best Buy store. Make sure that you place the Product in its original packaging or packaging that provides the same amount of protection as the original packaging. If you purchased the Product from a Best Buy online web site (www.bestbuy.com or www.bestbuy.ca), mail your original receipt and the Product to the address listed on the web site. Make sure that you put the Product in its original packaging or packaging that provides the same amount of protection as the original packaging.

To obtain warranty service, in the United States call 1-888-BESTBUY, Canada call 1-866-BESTBUY. Call agents may diagnose and correct the issue over the phone.

Where is the warranty valid?

This warranty is valid only in the United States and Canada at Best Buy branded retail stores or websites to the original purchaser of the product in the county where the original purchase was made.

What does the warranty not cover?

This warranty does not cover:

- Food loss/spoilage due to failure of refrigerator or freezer
- Customer instruction/education
- Installation
- Set up adjustments
- Cosmetic damage
- Damage due to weather, lightning, and other acts of God, such as power surges
- Accidental damage
- Misuse
- Abuse

- Negligence
- Commercial purposes/use, including but not limited to use in a place of business or in communal areas of a multiple dwelling condominium or apartment complex, or otherwise used in a place of other than a private home.
- Modification of any part of the Product, including the antenna
- Display panel damaged by static (non-moving) images applied for lengthy periods (burn-in).
- Damage due to incorrect operation or maintenance
- Connection to an incorrect voltage or power supply
- Attempted repair by any person not authorized by Insignia to service the Product
- Products sold “as is” or “with all faults”
- Consumables, including but not limited to batteries (i.e. AA, AAA, C etc.)
- Products where the factory applied serial number has been altered or removed
- Loss or Theft of this product or any part of the product
- Display panels containing up to three (3) pixel failures (dots that are dark or incorrectly illuminated) grouped in an area smaller than one tenth (1/10) of the display size or up to five (5) pixel failures throughout the display. (Pixel based displays may contain a limited number of pixels that may not function normally.)
- Failures or Damage caused by any contact including but not limited to liquids, gels or pastes.

REPAIR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS YOUR EXCLUSIVE REMEDY FOR BREACH OF WARRANTY. INSIGNIA SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR THE BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, INCLUDING, BUT NOT LIMITED TO, LOST DATA, LOSS OF USE OF YOUR PRODUCT, LOST BUSINESS OR LOST PROFITS. INSIGNIA PRODUCTS MAKES NO OTHER EXPRESS WARRANTIES WITH RESPECT TO THE PRODUCT, ALL EXPRESS AND IMPLIED WARRANTIES FOR THE PRODUCT, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF AND CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE WARRANTY PERIOD SET FORTH ABOVE AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THE WARRANTY PERIOD. SOME STATES, PROVINCES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.

Contact Insignia:

For customer service please call 1-877-467-4289

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2017 Best Buy. All rights reserved.

Made in China

INSIGNIA™

www.insigniaproducts.com

1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)

INSIGNIA is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2017 Best Buy. All rights reserved.

Made in China.

V1 ENGLISH
17-0036