

TOSHIBA

firetv edition

32" / 43" / 49" 60 Hz LED TV

QUICK SETUP GUIDE

32LF221U19 | 43LF421U19
49LF421U19


INCLUDED ACCESSORIES




Voice Remote with Alexa and two AAA batteries



32"



Stand legs




M4 screws (25 mm length)
(4 pcs.)




Power cord

43"




Stand legs




M5 screws (27 mm length)
(4 pcs.)

49"



Stand legs



M5 screws (10 mm length)
(4 pcs.)



Power cord

FIND YOUR USER GUIDE ONLINE!

Go to www.tv.toshiba.com and search for 32LF221U19, 43LF421U19 or 49LF421U19.

WHAT YOU NEED (not included)



Phillips screwdriver



Internet connection (wired or wireless)*

*Subscription or other payment may be required to access certain content.

1 START HERE

How do I attach the stand to my TV? (not for wall mounting)


You'll need: Soft surface and a Phillips screwdriver.

Carefully place your TV face-down on a cushioned, clean surface.

Secure each TV stand leg to the back of your TV with two of the provided screws.


32" | M4 type (25 mm) screws

43" | M5 type (27 mm) screws



43" model illustrated

49" | M5 type
(10 mm) screws



OR

WALL MOUNT

How do I prepare my TV for wall mounting? (not for use with a TV stand)


You'll need: Soft surface and a Phillips screwdriver.

Before you mount your TV, make sure that:


- You remove the stand legs.
- The bracket supports the weight of your TV.

A Carefully place your TV face-down on a cushioned, clean surface.

B See the instructions that came with your wall mount for more information about how to correctly mount your TV.



43" model illustrated



VESA Mounting Pattern

32" 100 × 100 – M4 × 35 mm type screws (4 pcs)


43" 200 × 300 – M6 × 25 mm type screws (4 pcs)

49" 200 × 300 – M6 × 17 mm type screws (4 pcs)


Your TV has four VESA mounting holes on the back. If you attach a wall-mount bracket to the back of your TV, **the bracket must be securely attached, using all four holes.** If you do not use all four mounting holes, your TV may fall and cause property damage or personal injury. See the documentation that came with your wall mount for complete mounting instructions.

FEATURES

Front



Back



Before using your new product, please read these instructions to prevent any damage.


2 MAKING CONNECTIONS

How do I watch TV (cable, satellite, or antenna) or connect a device such as a DVD or Blu-ray disc player or game console?
How do I connect to the internet?

HDMI® (BEST)


Best video quality

Note: Connect an ARC-enabled home theater receiver to HDMI 1 (ARC).




ETHERNET (OPTIONAL)


Note: You have to connect either LAN or Wi-Fi to access the Internet. See back for additional info.



49" TV Illustration for example




COAXIAL (GOOD)



*connect HD Antenna to access live over-the-air TV


AV (GOOD)



3 CONNECTING AUDIO DEVICES


How do I connect my TV to external speakers?

Using digital audio



OR

Using analog audio




Note: See the instructions that came with your speakers or soundbar for more information.

4 TURNING ON MY TV

When can I turn on my TV?

WHEN YOUR TV IS IN PLACE:

- 1 Plug the power cord into a power outlet.
Note: On the 32" and 49", plug the power cord into the AC IN jack on the back of your TV, then plug the other end into a power outlet.
- 2 Remove the remote control cover and install the batteries.
- 3 Press  on your Voice Remote with Alexa.
- 4 Follow the on-screen instructions.



WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "hazardous voltage" within the product's enclosure, which may be of sufficient magnitude to induce a risk of electric shock to persons.

The exclamation mark inside an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

AMAZON TERMS & POLICIES


Before using Fire TV Edition, please read the terms located at www.amazon.com/deviceservices/support. Please also read all terms and policies for services related to Fire TV Edition, including but not limited to Amazon's Privacy Notice located at www.amazon.com/privacy, Amazon's Conditions of Use located at www.amazon.com/conditionsofuse, and any other terms or usage provisions available at www.amazon.com/deviceservices/support. All terms, rules, notices, policies, and provisions are, collectively, the "Agreements." By using Fire TV Edition, you agree to be bound by the terms of the Agreements.

5 COMPLETE THE ON-SCREEN SETUP

Using your remote, follow the on-screen setup.

- 1 Your TV should automatically be paired to your new Voice Remote with Alexa. If there were issues, you will be prompted to pair your remote by pressing down the "Home" button. If you continue to have issues, please try re-inserting your batteries or replacing them and repeat this step again.
- 2 Select your Wi-Fi network from the networks displayed on the screen.
Note: If your Wi-Fi network is password protected, have your Wi-Fi network password handy to connect your TV to the Internet. If your network is hidden, select the **Join Other Network** tile from the list. If required, enter your network password using the on-screen keyboard.
- 3 Select your experience: **Full** (Recommended) or **Basic**.
 - **Full:** Get the most out of your experience with access to live TV, over 500,000 streaming movies and TV episodes, thousands of apps, and Alexa skills. To get started, sign in or sign up for a free Amazon account.
 - **Basic:** This experience is limited to live TV and only six streaming apps. Alexa and the full Appstore are not included.

USING YOUR VOICE REMOTE WITH ALEXA



6 OPTIONAL

(Watching live over-the-air TV)

If you connected your TV to an antenna or cable wall jack, please complete the following steps:

- 1 When setup is complete, run a channel scan by going to **Settings > Live TV > Channel Scan**.
- 2 Follow the on-screen instructions to finish scanning for channels.
- 3 To browse and watch live over-the-air TV, use the **On Now** row or press the  Guide button on your remote.

TOSHIBA

firetv edition

A Smarter TV Is Here

High Definition Picture Quality, Fire TV Experience Built-In, Voice Remote with Alexa



Access Your Favorite Content – From The Home Screen
Fire TV Edition seamlessly integrates live over-the-air TV and your favorite streaming content on the Home screen, with access to tens of thousands of channels, apps, and Alexa skills.



Unlimited Entertainment – Watch over 500,000 streaming movies and TV episodes in brilliant High Definition from Netflix, Prime Video, Hulu, PlayStation Vue, HBO and more.



Control It All With Your Voice – Voice Remote with Alexa
Use your voice to control live TV playback, launch apps, search for content, control smart home devices, and more.

Full Experience required to access all features described.

Access the online User Guide


Go to www.tv.toshiba.com and search for your model number. Many questions regarding parts, service, and warranties can be answered by visiting the Support section of our website: www.tv.toshiba.com

Contact Toshiba Customer Support Center

1-855-527-2411 From the United States and Canada

Contact Amazon Fire TV Customer Service

www.amazon.com/firetv/contactus



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories.

For DTS Patents, see <http://patents.dts.com>. Manufactured under license from DTS Licensing Limited. DTS, the Symbol, & DTS and the Symbol together are registered trademarks and DTS TruSurround is a trademark of DTS, Inc. © DTS, Inc. All Rights Reserved.

Amazon, Fire, Alexa, Prime, and all related logos are trademarks of Amazon.com, Inc. or its affiliates.

Certain services are subject to change at any time, may not be available in all areas, and may require separate subscriptions.

Distributed and warranted by Best Buy Purchasing LLC
7601 Penn Avenue South, Richfield, MN 55423 USA

©2018 Best Buy. All rights reserved.
Made in China