

Cuisinart®

Compact Bullet Ice Cube Maker

IMC-2 SERIES



Instruction
Booklet

For your safety and continued enjoyment of this product,
always read the instruction book carefully before using.

Important Safeguards

When using an electrical appliance, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury, including the following:

1. Read all instructions before using.
 2. Remove all packing material and carefully check your ice maker to ensure it is in good condition and that there is no damage to the ice maker or power cord and plug.
 3. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
 4. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children should not play with the appliance. Cleaning and user maintenance should not be done by children without supervision.
 5. This appliance is intended to be used in household and similar applications such as staff kitchen areas in shops, offices and other working environments; farmhouses and by clients in hotels, motels and other residential type environments; bed and breakfast type environments.
 6. **WARNING:** Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
WARNING: Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
WARNING: Do not damage the refrigerant circuit.
WARNING: When positioning the appliance, ensure the supply cord is not trapped or damaged.
- WARNING:** Do not locate power strips or other portable power supplies at the rear of the appliance.
WARNING: When disposing of the appliance, do so only at an authorized waste disposal center. Do not expose to flame.
WARNING: Fill with potable water only.
7. The refrigerant (R600a) is flammable.
CAUTION: The refrigerant circuit of the appliance contains isobutane (R600a). Isobutane is a natural refrigerant gas with a high level of environmental compatibility, but it is nevertheless flammable. During transportation and installation of the appliance, ensure that none of the components of the refrigerant circuit becomes damaged.
If the refrigerant circuit should be damaged: Avoid open flames and sources of ignition. Thoroughly ventilate the room in which the appliance is situated.
 8. Before using the ice maker for the first time, please wait 2 hours after positioning it, and keep the transparent lid open for at least 2 hours.
 9. Tap water should not be used in this unit: spring or filtered water is recommended.
 10. Ensure the voltage is compliant with the voltage range stated on the rating label and ensure the grounding of the socket is in good condition.
 11. Do not upend this product or incline it over a 45° angle.
 12. To protect against risk of electric shock, do not pour water on cord, plug and ventilation, or immerse the appliance in water or any other liquid.
 13. Unplug the appliance when not in use or before cleaning.
 14. Keep the appliance 3.5 inches from other objects to ensure enough room for ventilation.
 15. Do not use accessories that are not recommended by manufacturer.
 16. Do not use the appliance near flames, hot plates or stoves.
 17. After switching the unit off, wait at least 5 minutes before switching it on again to avoid damaging the compressor.
 18. Do not use outdoors.
 19. Never clean with scouring powders or hard implements.
 20. Please keep the instruction manual.
 21. Opening the lid for long periods can cause a significant increase of the temperature in the compartments of the appliance.

22. To avoid contamination of water/ice cubes: Regularly clean surfaces that can come in contact with water and accessible drainage systems. Clean water tanks if they have not been used for 48 hr. If the refrigerating appliance is left empty for long periods, switch off, clean, dry, and leave the lid open to prevent mold from developing within the appliance.
23. Component parts shall be replaced with like components and that servicing should be done by factory authorized service personnel, to minimize the risk of possible ignition due to incorrect parts or improper service.
24. During servicing, service personnel should power down and unplug the ice maker.
25. If the power cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.
26. It is normal for the compressor and condenser surface to reach temperatures between 158°F - 198°F during operation, and surrounding areas may be very hot.
27. Due to fast freezing, ice cubes may be opaque. This is air trapped in the water and will not affect quality or taste of ice.

Save These Instructions For Household Use Only

Special Cord Set Instructions

A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord. Extension cords may be used if care is exercised in their use.

If an extension cord is used, the marked electrical rating of the extension cord must be at least as great as the electrical rating of the appliance, and the longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over.

Notice

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.

Specifications

Model Number: IMC-2

Voltage: 110-120V/60Hz

Current: 2A

Daily Ice Output: 26.5 lb/24 hours

Ice Storage Capacity: 1.0L/600g

Water Reservoir Capacity: 1.1 qt

N.W: 14.37 lb

G.W: 15.54 lb

Compression-Type Refrigeration: 110-120V/60Hz

Cooling Agent: R600a environmentally friendly refrigerant

Max Overall Dimensions (WxDxH): 8.11" x 11.10" x 10.55"

Packaging Dimensions (WxDxH): 13.14" x 9.96" x 12.16"

Carton Dimensions (WxDxH): 13.66" x 10.43" x 12.71"

Warning: Risk of Fire or Electric Shock



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated, dangerous voltage within the product’s enclosure that may be of sufficient magnitude to constitute a risk of fire or electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Contents

Important Safeguards 2-3

Unpacking Instructions 4

Setting Up Your Ice Machine 4

Parts and Features 5

Getting to Know Your Control Panel 5

Before First Use 6

Operating Instructions 6

After Use 6

Cleaning and Maintenance 7

Troubleshooting 8

Warranty 9

Unpacking Your Ice Cube Maker

Remove all packaging material. This includes all adhesive tape holding the ice cube maker accessories inside and outside. You may want to keep the box and packing materials for use at a later date.


Before using your Cuisinart® Compact Bullet Ice Cube Maker for the first time, remove all protective paper and wrapping. Wipe housing and internal compartments with a damp cloth to remove any dust from the warehouse or shipping.

Setting Up Your Ice Machine

1. During transportation, do not tilt the machine more than 45 degrees, and do not turn the machine upside down. This may damage the compressor and the internal sealing system.
2. Remove all packing materials, check the machine carefully, and make sure that the machine, power cord, and plug are undamaged.
3. Put the machine on a level surface. To ensure sufficient ventilation, the distance from the back of ice maker to the wall should be at least 6 inches. Place it away from the oven, radiator, or other heat sources.
4. Before using the machine for the first time, leave it unplugged and open for at least two hours.
5. Make sure that the home voltage is consistent with the voltage indicated by the machine.
6. When the ambient temperature is lower than 15°C/59°F, please choose small ice. When the ambient temperature is higher than 30°C/86°F, choose large ice.
7. Do not use chemicals, acidic or alkaline liquids to make ice.


Features and Benefits

- 1. Unit Transparent Lid
- 2. Ice Basket
- 3. Control Panel
- 4. Water Tank
- 5. Back Cover
- 6. Automatic Ice Shovel
- 7. Thermal Window/Air Vent
- 8. Ice Scoop
- 9. Filter Cover
- 10. Drain Outlet (not shown)



Getting to Know Your Control Panel

- 1. **ICE FULL**
Ice full alarm indicator light
- 2. **ADD WATER**
Water shortage alarm indicator light
- 3. **POWER ON/OFF BUTTON**
Starts/stops the ice making process and allows to select the size of the ice cubes
- 4. **SMALL**
Small ice indicator light
- 5. **LARGE**
Large ice indicator light



Before First Use

Follow the steps under Cleaning and Maintenance before using this unit.

Operating Instructions

1. Adding water: Flip up the transparent lid, and remove the ice basket. Pour fresh, potable water into the reservoir. Do not fill past the MAX fill line. Replace the ice basket and close the lid.



2. Plug in the unit to a power supply. The SMALL indicator light will flash, indicating that size is selected and the unit is in standby.
NOTE: If the ADD WATER indicator is illuminated, add water to the water tank, close lid, and then press and hold the POWER ON/OFF button for 5 seconds to continue.




3. Set size preference: SMALL is the default size setting. To change from SMALL to LARGE, quick press the POWER ON/OFF button once to toggle through and change the size setting. The LARGE indicator light will illuminate and flash, indicating the selection is active.
4. Making ice: Press and hold the POWER ON/OFF button for 2 seconds to begin making ice. The selected ice size indicator light will remain solid, indicating the unit ice making cycle is active.
NOTE: To cancel operation, press and hold the POWER ON/OFF button for 2 seconds to return to standby mode.



5. The unit will continue to make ice until the ice basket is full, the reservoir is out of water, or the operation is canceled.

6. ICE FULL: The unit will continue to make ice until the ice basket is full. The ICE FULL indicator light will illuminate, and the unit will stop. Remove and empty the ice basket, and then return to the ice maker to continue making ice.



NOTE: The water reservoir holds enough water to make 2 full baskets of large ice cubes, or 3 full baskets of small ice cubes. The machine will continue to make ice until the ice basket is full, the reservoir is out of water, or operation is canceled.

7. ADD WATER: When the water level in the water tank is low, the ADD WATER indicator light will illuminate and the unit will stop. To continue making ice, remove the ice basket and add water to the reservoir. Replace the ice basket, close lid, and then press and hold the POWER ON/OFF button for 5 seconds to return to standby mode.



After Use

1. Empty the ice basket and position back into the unit.
2. Drain excess water from the reservoir after use. To empty the reservoir, locate the drain outlet positioned on the bottom side of the unit.



To access, carefully slide the unit to the edge of the counter and hold a cup below the drain outlet. Remove the plug and let water drain into the cup until the water stops flowing. Your unit can also be brought to the edge of the sink to drain. Be sure the unit remains flat at all times and is not tilted more than 45 degrees to avoid damaging the compressor system.

NOTE: Always use potable water before starting ice production either at initial installation or after a long shutoff period.

3. The filter cover in the water tank should be cleaned regularly after disassembly to prevent the water inlet from being blocked by scale. Remove the ice basket and then the filter cover from the water tank. Clean the filter cover with a brush. Replace the filter cover and then the ice basket. See the image below for the filter cover location.



4. For the freshest ice, change the water in the reservoir at least once a day. If the ice maker is going to be idle for an extended period of time, drain and clean the water reservoir.
5. If the compressor doesn't work because the water reservoir is empty, the ice basket is full, or power has failed, the machine has a 3-minute delay before restarting.

Maintenance

Any other servicing should be performed by an authorized service representative.

Cleaning and Maintenance

Your ice maker is equipped with an automatic cleaning function to help clean the interior of your unit, including the water lines. Following these steps will help to maintain the unit and add to longevity. It is recommended to follow these cleaning steps on a monthly basis to ensure optimal cleanliness.

1. Before cleaning, unplug the unit and remove the ice cubes, then drain any leftover water by unplugging the drain valve on the bottom of the unit. Replace the drain valve. Clean the inner liner, ice basket, water tank, and ice scoop frequently. Use a diluted solution of water and white vinegar to clean the inside and the outside surfaces of the ice maker. Rinse thoroughly before using again.
2. Fill the water tank with $\frac{1}{2}$ tank of fresh potable water. Plug in the unit to a power supply. Press and hold the POWER ON/OFF button for 10 seconds to initiate auto cleaning mode. The 4 indicator lights on the control panel will flash in sequence when unit enters cleaning mode.
3. If the ice machine has been idle for a period of time, an air blockage may prevent it from being able to pump enough water to make ice. If this happens, the ADD WATER light will illuminate. Press and hold the POWER ON/OFF button for 5 seconds to return to standby mode.

Troubleshooting

1. If the power cord is disconnected or the power button has been pushed off during an ice making cycle, small ice chips may form and lodge in the automatic ice shovel causing it to jam. If this occurs, the ice chips may be removed by disconnecting the power cord and gently pushing the shovel to the rear of the cabinet and removing the ice chips, then restarting.
2. If the automatic ice shovel cannot remove the ice to ice collecting tray, press and hold the POWER ON/OFF button for 2 seconds to return to standby model and restart.

PROBLEM	POSSIBLE CAUSE	SUGGESTED SOLUTIONS
The compressor works abnormally with a buzzing noise	The voltage is lower than recommended	Stop the ice maker and do not restart until the voltage is normal.
ADD WATER indicator is on	1. There is no water 2. The pump is full of air	1. Add some water until it reaches MAX position. 2. Press the POWER ON/OFF button to restart the machine.
Indicator lights on control panel are not on	Blown fuse/No power	Replace fuse/turn power on.
The ice made is too large and with pieces sticking together	Ice of previous cycles left in the ice basket	Remove the ice from the ice basket when the ice maker is in standby mode.
The ice making process was correct, but no ice came out	1. The compressor has no refrigerant 2. Compressor damaged 3. Fan motor damaged	Call the service hotline.
All indicator lights flash at the same time	1. The water tank is blocked by ice 2. The motor fails, is stuck or is damaged 3. Micro switch damaged	1. Unplug the unit. Take out the ice under the automatic ice shovel, plug in power again, and press the POWER ON/OFF button. After 3 minutes, the machine will restart automatically. 2. Call the service hotline.
The ice cubes are thin and small	The room temperature or water temperature is high	The ice cubes will become bigger after initial cycles as the water temperature gets lower.

Warranty

Limited One-Year Warranty

This warranty is available only to U.S. consumers who purchase products directly from Cuisinart or an authorized Cuisinart® reseller. You are a consumer if you own a Cuisinart® Compact Bullet Ice Cube Maker that was purchased at retail for personal, family, or household use. Except as otherwise required under applicable law, this warranty is not available to retailers or other commercial purchasers or owners or consumers who purchase from unauthorized Cuisinart® resellers. We warrant that your Cuisinart® Compact Bullet Ice Cube Maker will be free of defects in materials and workmanship under normal home use for 1 year from the date of original purchase.

We recommend that you visit our website, <https://cuisinart.registria.com>, for a fast, efficient way to complete your product registration. However, product registration does not eliminate the need for the consumer to maintain the original proof of purchase in order to obtain the warranty benefits. In the event that you do not have proof of purchase date, the purchase date for purposes of this warranty will be the date of manufacture.

California Residents Only

California law provides that for In-Warranty Service, California residents have the option of returning a nonconforming product (A) to the store where it was purchased or (B) to another retail store that sells Cuisinart® products of the same type. The retail store shall then, according to its preference, either repair the product, refer the consumer to an independent repair facility, replace the product, or refund the purchase price less the amount directly attributable to the consumer's prior usage of the product. If neither of the above two options results in the appropriate relief to the consumer, the consumer may then take the product to an independent repair facility, if service or repair can be economically accomplished. Cuisinart and not the consumer will be responsible for the reasonable cost of such service, repair, replacement, or refund of nonconforming products under warranty. California residents may also, according to their preference, return nonconforming products directly to Cuisinart for repair or, if necessary, replacement by calling our Consumer Service Center toll-free at **1-800-726-0190**. Cuisinart will be responsible for the cost of the repair, replacement, and shipping and handling of such nonconforming products under warranty.

Hassle-Free Replacement Warranty

Your ultimate satisfaction in Cuisinart products is our goal, so if your Cuisinart® Compact Bullet Ice Cube Maker should fail within the generous warranty period, we will repair it or, if necessary, replace it at no cost to you. To obtain a return shipping label, please visit us at <https://www.cuisinart.com/customer-care/product-assistance/product-inquiry>. Or call our toll-free Customer Service Department at **1-800-726-0190** to speak with a representative.

Your Cuisinart® Compact Bullet Ice Cube Maker has been manufactured to the strictest specifications and has been designed for use only in 120-volt outlets and only with authorized accessories and replacement parts. This warranty expressly excludes any defects or damages caused by attempted use of this unit with a converter, as well as use with accessories, replacement parts, or repair service other than those authorized by Cuisinart. This warranty does not cover any damage caused by accident, misuse, shipment, or other than ordinary household use. This warranty excludes all incidental or consequential damages. Some states do not allow the exclusion or limitation of these damages, so these exclusions may not apply to you. You may also have other rights, which vary from state to state.

Important: If the nonconforming product is to be serviced by someone other than Cuisinart's Authorized Service Center, please remind the servicer to call our Consumer Service Center at **1-800-726-0190** to ensure that the problem is properly diagnosed, that the product is serviced with the correct parts, and that the product is still under warranty.

This image shows a full page of blank white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page, providing a template for writing or drawing. There are no margins, text, or other markings on the page.

[illegible]

©2024 Cuisinart
Glendale, AZ 85307

Printed in China

24CE091356

IB-18396