


NEXT

QUICK SETUP GUIDE

CHARGING DOCK FOR XBOX® SERIES X | S NX-XCHRG2

PACKAGE CONTENTS

- Charging Dock
- Rechargeable Battery Packs (2)
- Black Battery Covers for Xbox Series X | S (2)



Before using your new product, please read these instructions to prevent any damage.

FEATURES

- Charges two Xbox Series X | S controllers
- Sturdy weighted base with anti-slip rubber feet
- LED charging indicators
- Rechargeable battery eliminates disposable batteries
- 1200mAh pack lets you play longer between charges
- Powered by USB cable (4 ft)
- Fully UL-certified battery cell

SAFETY INFORMATION

Incorrect battery use may result in battery leakage, overheating, or explosion.





When using batteries, make sure that you follow these instructions:

- Keep batteries out of the reach of children.
- Do not heat, open, puncture, mutilate, or dispose of batteries in fire.
- If a battery leaks, remove the battery, taking care to keep the leaked fluid from touching your skin or clothes. If fluid from the battery comes into contact with skin or clothes, flush skin with water or remove the clothing immediately. Before inserting a new battery, thoroughly clean the controller with a damp paper towel.
- Do not allow metal objects to touch the battery terminals, because they can become hot and cause burns. For example, do not carry the battery in a pocket with keys or coins.
- Remove the battery when the product will not be used for an extended period of time.


INSTALLING THE BATTERY PACK

- Open the battery cover on the Xbox Series X or S controller and insert the rechargeable battery pack into the battery compartment as shown below. The contacts should be facing left and the charge contact should be facing outward. Replace with supplied battery cover.

Warning: If you find that the battery is requiring force or does not fit correctly, do not force the battery in. Carefully reevaluate the position of the battery and try again - the battery should not be forced into the controller.




USING THE CHARGING DOCK



- 1** Place the charging dock on a flat and stable surface.
- 2** Plug the USB power cable into one of the open USB ports on the console or any compatible USB A power source.
- 3** Align the bottom connector on the controller with the tabs on the charging dock. Then place your controller onto the charging dock.
- 4** The Charging indicator will glow amber while charging, then turn green with charging is complete.

CHARGING INDICATOR INFORMATION

LED COLOR	DESCRIPTION
Amber	Controller is charging
Green	Charging is complete



Charging indicator

SPECIFICATIONS

Battery capacity	1200mAh
Battery type	Ni-MH LSD battery
Cable Length	4 ft. (1.2 m)
Input	USB 5V
Output	5V 450mA x 2
Dimensions	
Charging system	6.9 x 2.2 x 2.2 in. (17.5 x 5.6 x 5.6 cm)
Rechargeable Battery Pack	1.9 x 1.2 x .6 in. (4.8 x 3.0 x 1.5 cm)
Operating temperature	32°F~104°F (0°C~40°C)

LEGAL NOTICES

FCC Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ICES-003 Statement

This Class B digital apparatus complies with Canadian ICES-3(B) / NMB-3(B) standard.

ONE-YEAR LIMITED WARRANTY

Visit www.next-accessories.com for details.

This product is not approved, endorsed or affiliated with Microsoft.

©2024. All Rights Reserved.

Made in China

English V1-24-0820