



049-023

REMATCH Advanced Wired Controller

Xbox Series X|S

Xbox One

Windows 10/11

Quick Start Guide

1. Initial Setup

EN

Plug the USB-C end of the cable into the top of the controller, and the USB side into your console or PC. The light above the Xbox logo will appear to indicate it is connected.




*Switch with new controller lineart

2. Mute Microphone

EN


Press the function button twice to mute your microphone.



3. Control Volume

EN


While holding down the function button, press D-Pad +Up/-Down to adjust game volume.



4. **Game/Chat** Balance


EN

While holding down the function button, press D-Pad Left/Right to adjust game/chat balance.




5. Program Back Buttons

A



While holding down the function button, press the back button you would like to map a function to, and the function button LED will start flashing.

B



Press any button you would like mapped, and the function button LED will flash 3 times indicating a successfully mapped function.

Note: To clear a mapped function or disable the back buttons completely, hold down the function button and double press any back button.

6. PDP Control Hub

EN

To customize your controller further, download the free PDP Control Hub App from the Windows Store on your PC or Xbox. You can use it to re-map buttons, run diagnostics, recalibrate analog sticks and triggers, and much more.

(Add Screenshot of APP)

LIMITED WARRANTY Pages (in 5 languages)