

User Guide



Two-Piece Speaker System

NS-22

Insignia NS-22

Two-Piece Speaker System

Contents

Welcome	3
Introduction	3
Safety information	3
Features	4
Setting up your speakers	4
Using your speakers	5
Troubleshooting	6
Copyright	6
One-Year Limited Warranty	7

Welcome

Congratulations on your purchase of a high-quality Insignia product. Your NS-22 two-piece speaker system represents the state of the art in speaker design, and is designed for reliable and trouble-free performance.

Introduction


This system is designed to deliver superior performance with devices such as computers, MP-3 players, DVD players, CD players, and various other sources.

Safety information

Cautions:

- Do not plug the power supply in until all connections are made.
- Use only the AC power adapter supplied with these speakers. Insignia will not be held responsible for damage caused by another power supply.
- Read the entire owners guide before making any connections.
- Keep your speakers away from extreme heat or humid and wet conditions.
- Use a dry cloth for cleaning. Do not expose any part of the system to cleaning liquids or solvents.

Features




Feature	Description
Power button	This button is on the right speaker. Press to turn on the speakers. Press again to turn the speakers off.
Master volume control knob	This knob is on the right speaker. Rotate clockwise to turn the volume up or counterclockwise to turn the volume down.
Headphone jack	The headphone jack is on the right speaker. Connect a set of headphones to this jack. The speakers automatically mute. The master volume control can be used to control the volume to your headphones.

Setting up your speakers

We recommend that these speakers be placed as far apart as possible in the listening area. For example, when the speakers are connected to a computer, place the left speaker on the far left corner of your desktop and the right speaker on the far right corner of your desktop.

Connecting the speakers

These speakers are compatible with a variety of audio devices. Read the instructions first and then refer to the diagrams below to connect your speakers.



Using your speakers

To use your speakers:

- 1 Plug the AC adapter into a power outlet, then plug the black plug into the back of the right speaker.
- 2 Plug the green audio connector plug into the audio source.
- 3 Press the Power button to turn on the speakers.
- 4 Turn on the audio source, then adjust the volume to a comfortable level.

Troubleshooting

Problem	Solution
The speakers will not turn on	The AC adapter is not connected to the speaker and the AC wall outlet
	The power is not turned on
The speaker does not produce sound	Make sure that the speakers are getting power (see above steps)
	The volume setting is too low. Turn up the master volume control to the 1/4 to 1/2 level
	Check all cable connections
	Check to see if your music source is functioning correctly. (see more on this below)

Checking your sound source:

You may believe that the speakers are not working, when in fact the sound source may be the problem. When connecting to a computer, the most common problem is an incorrect connection. Make sure that you are connected to the audio output jack from your computer sound card. Many times it has a green color to it. Also, make sure that your CD or DVD drive is playing and the volume settings are turned up and not muted. If you still have problems, disconnect the speaker source cable from your computer and connect it to a Walkman or personal CD player, or anything else with a mini headphone jack. If your speakers work on the other source, you know the speakers are OK and the problem is in your computer or the connections.

Copyright

© 2008 Insignia. Insignia and the Insignia logo are trademarks of Best Buy Enterprise Services, Inc. Other brands and product names are trademarks or registered trademarks of their respective holders. Specifications and features are subject to change without notice or obligation.

For service and support call (877) 467-4289.

One-Year Limited Warranty

Insignia Products ("Insignia") warrants to you, the original purchaser of this new **NS-22** ("Product"), that the Product shall be free of defects in the original manufacture of the material or workmanship for a period of one (1) year from the date of your purchase of the Product ("Warranty Period"). This Product must be purchased from an authorized dealer of Insignia brand products and packaged with this warranty statement. This warranty does not cover refurbished Product. If you notify Insignia during the Warranty Period of a defect covered by this warranty that requires service, terms of this warranty apply.

How long does the coverage last?

The Warranty Period lasts for 1 year (365 days) from the date you purchased the Product. The purchase date is printed on the receipt you received with the Product.

What does this warranty cover?

During the Warranty Period, if the original manufacture of the material or workmanship of the Product is determined to be defective by an authorized Insignia repair center or store personnel, Insignia will (at its sole option): (1) repair the Product with new or rebuilt parts; or (2) replace the Product at no charge with new or rebuilt comparable products or parts. Products and parts replaced under this warranty become the property of Insignia and are not returned to you. If service of Products or parts are required after the Warranty Period expires, you must pay all labor and parts charges. This warranty lasts as long as you own your Insignia Product during the Warranty Period. Warranty coverage terminates if you sell or otherwise transfer the Product.

How to obtain warranty service?

If you purchased the Product at a retail store location, take your original receipt and the Product to the store you purchased it from. Make sure that you place the Product in its original packaging or packaging that provides the same amount of protection as the original packaging. If you purchased the Product from an online web site, mail your original receipt and the Product to the address listed on the web site. Make sure that you put the Product in its original packaging or packaging that provides the same amount of protection as the original packaging.

To obtain in-home warranty service for a television with a screen 25 inches or larger, call 1-888-BESTBUY. Call agents will diagnose and correct the issue over the phone or will have an Insignia-approved repair person dispatched to your home.

Where is the warranty valid?

This warranty is valid only to the original purchaser of the product in the United States, Canada, and Mexico.

What does the warranty not cover?

This warranty does not cover:

- Customer instruction
- Installation
- Set up adjustments
- Cosmetic damage
- Damage due to acts of God, such as lightning strikes
- Accident
- Misuse
- Abuse
- Negligence
- Commercial use

- Modification of any part of the Product, including the antenna
- Plasma display panel damaged by static (non-moving) images applied for lengthy periods (burn-in).

This warranty also does not cover:

- Damage due to incorrect operation or maintenance
- Connection to an incorrect voltage supply
- Attempted repair by anyone other than a facility authorized by Insignia to service the Product
- Products sold as is or with all faults
- Consumables, such as fuses or batteries
- Products where the factory applied serial number has been altered or removed

REPAIR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS YOUR EXCLUSIVE REMEDY. INSIGNIA SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR THE BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, INCLUDING, BUT NOT LIMITED TO, LOST DATA, LOSS OF USE OF YOUR PRODUCT, LOST BUSINESS OR LOST PROFITS. INSIGNIA PRODUCTS MAKES NO OTHER EXPRESS WARRANTIES WITH RESPECT TO THE PRODUCT, ALL EXPRESS AND IMPLIED WARRANTIES FOR THE PRODUCT, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF AND CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE WARRANTY PERIOD SET FORTH ABOVE AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THE WARRANTY PERIOD. SOME STATES, PROVINCES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.

Contact Insignia:

For customer service please call 1-877-467-4289

www.insignia-products.com

Distributed by Best Buy Purchasing, LLC

7601 Penn Avenue South, Richfield, Minnesota, U.S.A. 55423-3645

© 2008 Best Buy Enterprise Services, Inc.

All rights reserved. INSIGNIA is a trademark of Best Buy Enterprise Services, Inc. Registered in some countries. All other products and brand names are trademarks of their respective owners.



www.insignia-products.com

(877) 467-4289

Distributed by Best Buy Purchasing, LLC
7601 Penn Avenue South, Richfield, MN USA 55423-3645
© 2008 Best Buy Enterprise Services, Inc.

All rights reserved. INSIGNIA is a trademark of Best Buy Enterprise Services, Inc. Registered in some countries.
All other products and brand names are trademarks of their respective owners.

ENGLISH
08-1514