

5

STEP 5: On-screen setup and activation

Follow the instructions on
your TV screen.

Activate your streaming
player by using your
computer or smartphone
to link to a Roku account.

Common questions

Why do I need to create a Roku account?

Before you can start streaming, channels must be downloaded and installed on your streaming player. You'll need a Roku account to access the Roku Channel Store, manage your subscriptions, view your purchase history, and add a payment method. For more info, visit go.roku.com/whyaccount

Why do I need to enter a credit card?

Saving a payment method makes it easy to rent or buy movies on demand, subscribe to popular services, and enroll in free trials. Charges will not be made without your authorization. For more information, visit go.roku.com/paymenthelp

What should I do if my streaming player is not connecting to my wireless network?

Your streaming player connects to your wireless network the same as your laptop or smartphone. If these other devices can access the internet, then your streaming player should be able to do the same. Make sure to select the same network name, and enter the same password you use with the other devices. Remember that passwords are case-sensitive and easy to enter incorrectly. For more help, visit go.roku.com/wireless

Can I take my Roku streaming player with me when I travel?

Yes. You can bring your streaming player and watch your favorite entertainment when you travel. Remember to also bring a USB power adaptor (like your phone charger), remote, and any cables you use to connect your streaming player at home. Make sure your destination has a good internet connection. You may need a computer or smartphone to help connect your streaming player to a new wireless network. For more details, visit go.roku.com/travelwithroku

NOTE: Roku does not charge for activation support - **beware of scams.**

Need more help
getting started?
go.roku.com/rssplus



Video
tutorials



Wireless
help

Getting the most
out of your Roku
streaming player.
go.roku.com/usingroku



Add
channels



Mobile
app

Tips, what's
streaming for free,
and more...
blog.roku.com



Roku Blog



Roku

© 2019 Roku, Inc. All rights reserved. ROKU, ROKU logo and STREAMING STICK are the registered trademarks of Roku, Inc. All other logos and trademarks herein not owned by Roku, Inc. are the property of their respective owners.




4100000578_1

ROKU® Streaming Stick®+


ROKU

Quick Start Guide


What's included



Features



Setup




STEP 1: Connect to TV

HDTVs:
Plug your streaming player into an HDMI® port on your TV.


4K and HDR TVs:
To stream 4K or HDR, choose an HDMI port that supports **HDCP 2.2**. For help determining which port supports HDCP 2.2, visit go.roku.com/hdcp

Doesn't fit?
Order a free HDMI extender cable at my.roku.com/HDMI




STEP 2: Connect to power

For the best streaming experience, use the included USB power cable, power extender cable and power adaptor to connect your streaming player to a wall outlet.



Or use the included USB power cable to connect to the USB port on your TV.


NOTE: See a red light on your streaming player? That means the USB port on your TV is not providing enough power. Use the included power adaptor instead. For help, visit go.roku.com/lowpower



STEP 3: Power on TV and select input

Use your TV remote to power on your TV and select the input you used to connect your streaming player.

For help on how to select the correct input, visit go.roku.com/selectinput



STEP 4: Insert batteries

On the back side of the remote, slide open the battery cover. Insert included Duracell® batteries placing the negative (-) ends in first.

Your remote should pair with your streaming player automatically. For help pairing your remote, visit go.roku.com/remotehelp