

A 120±2

B 160±2

VAVA

Model: VA-IH006
VAVA Baby Monitor
Quick Start Guide

EN

BABY MONITOR VA-IH006 QUICK START GUIDE

SAFETY INSTRUCTIONS

Keep cord out of the reach of children (more than 3ft / 0.9m away) in case of STRANGULATION.

NEVER place the camera or cord in or near the crib or playpen.
NEVER mount the camera directly above the crib or playpen to avoid risk of injury.
Only use the AC adapters provided.
Never use the unit near water, including near a bathtub, sink, laundry machine tube, wet basement, etc.
Do not install near any heat sources such as radiators, heat registers, stoves, or other devices that produce heat.
Only use attachments and accessories specified by the manufacturer.
Unplug this device when used for long periods of time.
Do not insert anything into the upgrade pinholes. This operation is only intended for professionals.

CAUTION

NOT toys. Do not allow children to play with them.
The lens and lens hood are small parts; keep them out of your baby's reach at all times.
This product is NOT intended to replace the proper supervision of children. You MUST check your child's activity regularly.
This product is not intended for use as a medical camera and its use should not replace adult supervision.
Unplug the product during lightning storms.
Please check the operating range and condition of the camera carefully at the initial installation, and on a regular basis after that.
Check the reception regularly; test the camera before use and after changing the camera's location.
For indoor use only.
Clean the camera with a dry cloth only.
Do not block any ventilation openings.
Microphone feedback might occur when the monitor is too close to the camera. Please keep them at least 1.5m / 4.9ft apart.

Charging & Powering Baby Monitor

- Select the spot to mount the camera, keeping it beyond your baby's reach.
- Insert the screw (not included) pre-installed on the wall into the mounting hole of the camera.

Powering Camera

- Connect the camera to the power source via the Micro-USB cable and camera adapter.
- Slide the Power Switch on the camera and power cord within the reach of your baby.

Only use the power adapters included in the package.
Do not place the power cord within the reach of your baby.

Pairing the Baby Monitor & the Camera

By default, one camera has been paired with the monitor when manufactured. When you power on the monitor and camera, the two will automatically pair.
To add more cameras, press the Pair Button at the bottom of the camera, press Menu button, select through **[]** → **[]** → **[]**, and then the monitor will auto-pair with the camera. It is recommended to pair in the baby's room, or wherever you intend to place the camera.

Placing the Camera

Place the camera 1.5-2m / 4.9-6.6ft away from your baby for safety reasons and for a better view when in night vision mode.

Wall Mounting Camera

- Select the spot to mount the camera, keeping it beyond your baby's reach.
- Insert the screw (not included) pre-installed on the wall into the mounting hole of the camera.

It's strongly recommended to use a screw and screw anchor. Don't release the camera until you're sure it is firmly mounted.

Wide-Angle Lens (Optional)

The aluminum lens hood (no special video effects) has been installed when the camera was manufactured.

To install wide-angle lens (sold separately), simply rotate the original lens hood counterclockwise to remove. Then install the new lens and rotate clockwise to fix in place.

Camera

Cmos	720p(1280x720), 1OM, 1/4"
Connectivity	2.4GHz
Image Compression	H.264 (frame rate = 18fps)
Power Input	5V / 1.2A, 2m-long Micro-USB cable
Pan-n-Tilt	108 degrees vertical (Up=90, Down=18) 270 degrees horizontal (Left=135, Right=135)
Zoom	Zoom In (2X) Zoom In (6X) Auto-Preset (2 cycles)
View Angle	Vertical: 15m, Horizontal: 14m
Depth of Field	1.5m to 6m
Night Vision	Black & White image, 2m clear range, up to 6m
IR LED	Non-visible IR LED with wavelength 940nm (x 12pcs)
Light Sensor	Yes
Two-Way Talk	Yes
Storage Temperature	-10°C - 55°C / 14 - 131°F
Operation Temperature	0°C - 40°C / 32 - 104 °F

E-MAIL
support@vava.com

MANUFACTURER
Manufacturer: Shenzhen NearbyExpress Technology Development Co., Ltd.
Address: Floor 9 Building E, Galaxy World Phase II, Shenzhen, China

ZBIT International Trading GmbH
Address: Halstenbecker Weg 96C, 25462 Rellingen, Deutschland

Hiermit erklärt NearbyExpress, dass der Funkantagentyt VA-IH006 der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar:
<https://www.vava.com/pages/user-manual>

Rev_13_EN-DE

The image shows the front cover of a VAVA Baby Monitor Quick Start Guide. The cover is white with a large, stylized 'VAVA' logo in the center. Below the logo, the text 'Model VA-1H009' is printed. At the bottom, the title 'VAVA Baby Monitor' is followed by 'Quick Start Guide' in a bold font. The cover is shown as part of a stack of papers, with the edges of other pages visible at the top and bottom.

技术要求：

- 1、材料必须符合 RoHS2.0 要求;
- 2、IQC应对来料做尺寸&外观检验，*带英文字母为重要特性尺寸、IQC须重点管控；
- 3、颜色：单黑双面印；
- 4、装钉方式: 风琴折;
- 5、表面外觀光洁、字迹清晰、无杂色、无漏印,无破损，切边整齐；
- 6、摩擦测试: 使用粉红橡皮擦(70#)施加100g重力,速度为120次/分钟,循环50次, 测试后可接受轻微掉墨, 文字图案无明显断痕，且仍可认读为合格；
- 7、详细印刷内容请参阅电子档或样品(线上_英德说明书)；

未注公差		 朝阳聚声泰(信丰)科技有限公司 ZhaoYang Gevotai (XinFeng) Technology Co.,Ltd.		文件编号:GVT-BD-RD-			
尺寸范围 (mm)	尺寸公差 (mm)			工厂资料		图号: DR-5630	
0-50	±1.0	机 型 名 称 料 号 材 质	GC001B (IH006) 英德快速指南 5.11.10234 128克铜版纸 单黑双面印	共 1 页 第 1 页			
50-200	±2.0			单 位	mm	绘 图	廖春明
200-300	±3.0			比 例	1:1	确 认	
300以上	±5.0			ERP管理员		审 核	
角度公差	±1°						