643651C

The Construct 'n Learn Smart Workbench™ will launch and run on all Android devices 4.3 or higher and all Apple devices running iOS 7 and above. Devices must support Bluetooth LE for the app to sync with the Workbench. For a complete list of compatible devices, please visit

littletikes.com/smartworkbench

1. Get Started!



Download the Smart Workbench app to your tablet or mobile device by scanning the QR code, or by visiting littletikes.com/smartworkbench

IMPORTANT: Make sure your device is fully charged and has a working Internet connection. Be sure your Workbench has a fresh set of batteries.

2. To sync the workbench with the app:

Turn on your device.

- · Be sure that the device's Bluetooth feature is turned on.
- · Launch the Construct 'n Learn Smart Workbench™ app. The "connecting" screen appears while connecting to the Workbench (Fig. 1).
- Press the "Connect" button old located on the work surface. A green LED will flash while it is searching for your device (Fig. 2).
- When connecting screen disappears and the green LED remains solid, you're connected!

NOTE: If you're having trouble connecting, select "More Help" for troubleshooting tips (Fig. 3).







3. Update the firmware on your workbench:

IMPORTANT: Do not turn off the workbench or close the app during the update process.

- · Once connected, the app will automatically search for a firmware update.
- · If the app does not find an update, it will proceed to the home screen.
- · If the app finds an available update, it will promp you to "update" or do so at a later time (Fig. 4).
- · Tap "Update" to download to your device.
- · An "Updating" progress bar will appear to indicate the update status. This may take a few minutes (Fig. 5).
- · Once the update is complete, turn off the Workbench and then turn it back on and re-connect with the app (Fig. 6).







Remember to sync the Workbench with the app before every use, and keep your device near the Workbench as you play!





Home Screen

Choose your Activity









Proceed

Trophies

Toggles music

ON/OFF

Free Play

As kids engage in traditional role-play, the app recognizes and responds to the items they are using with fun animation, encouraging phrases and interesting facts.



Blueprints

Follow the on-screen instructions to build your vehicles with the included tools and parts!







Fix-It Fast!

Learn how to fix various items by selecting the tool you would need to repair it! There are two play modes: beginner and advanced.



Tool Trivia

Can you tell the difference between all of the tools in your tool box? Select beginner or advanced mode according to your skill level



BEGINNER



ADVANCED

GENERAL TROUBLESHOOTING

Workbench does not turn on or does not respond

- · Make sure batteries are correctly installed.
- · Remove batteries and put them back in.
- · Install new batteries.
- · Keep your device near the Workbench

during play

· Remove batteries and put them back in. · Install new batteries.

· Close out of app. App is not syncing or screen freezes

· Turn Workbench off, then on, and reconnect with app.

App not recognizing an object

Workbench behaves erratically

- · Check that it is an item with a RFID chip.
- · Be sure the item is placed correctly on the Workbench.

iOS TROUBLESHOOTING

Device must support Bluetooth 4.0 (LE) technology in order to connect to the unit.

How to Connect



1. On your iOS device, go to Settings > Bluetooth and make sure Bluetooth is turned on. If you can't turn on Bluetooth or you see a spinning gear, restart your

Once the device has restarted:

- 2. Turn on the Workbench.
- 3. Launch the app on your device.
- 4. Press and hold the "Connect" button for about three seconds.
- * The green LED next to the button should begin blinking.
- 5. Allow up to 30 seconds for connection to be established.

Tips for Connecting



- Ensure device's Bluetooth is enabled and broadcasting. *See your device's user manual for instructions.
- Try turning both device and Workbench off and on completely.
- Ensure your device has the most current supported operating system.
- Remember to press and hold the green "Connect" button on the Workbench until the LED begins flashing.
- Make sure your device and Workbench are close to each other.

ANDROID TROUBLESHOOTING

Device must support Bluetooth 4.0 (LE) technology in order to connect to the unit.

How to Connect



- 1. Tap the "apps" icon on your Android device's home screen.
- 2. Tap on the Settings icon.
- 3. Scroll down to Application Manager from the Application section.
- 4. Display "All" tab by swiping left or right.
- 5. Tap on Bluetooth.
- 6. Tap FORCE STOP button.
- 7. Tap CLEAR DATA.

Tips for Connecting



- Ensure device's Bluetooth is enabled and broadcasting.*See your device's user manual for instructions.
- Try turning both device and Workbench off and on completely. • Ensure your device has the most current
- supported operating system. Remember to press and hold the green "Connect" button on the Workbench
- until the LED begins flashing. Make sure your device and Workbench
- are close to each other.