

Thank you for purchasing this product


For optimum performance and safety, please read these instructions carefully before connecting, operating or adjusting this product. Please keep this manual for future reference.

Surge protection device recommended

This product contains sensitive electrical components that may be damaged by electrical spikes, surges, electric shock, lightning strikes, etc. Use of surge protection systems is highly recommended in order to protect and extend the life of your equipment.

Caution

The product requires the use of UTP connectors. Please connect in direct interconnection method and do not cross connect.



Direct Interconnection Method

Table of Contents

1. Introduction.....	1
2. Features.....	1
3. Package Contents.....	1
4. Specifications.....	2
5. Operation Controls and Functions.....	4
6. Application Example.....	5

1. Introduction

This Dante® 2CH XLR Input Adapter is an audio transmitter based on the Dante® Ultimo 2x2 solution. It converts two-channel balanced/unbalanced XLR analog audio into Dante® 2CH digital audio, then transmits the audio to the receiving end through network (Dante®). Analog audio input supports 5-level sensitivity adjustment.

The adapter supports local USB-C port power supply and PoE function.

2. Features

- ☆ Two-channel XLR analog audio to Dante® 2CH digital audio
- ☆ Balanced/unbalanced XLR analog audio input
- ☆ Dante® audio sampling rate supports 44.1/48/88.2/96KHz@24bit
- ☆ Dante® audio delay supports 1/2/5ms (configurable)
- ☆ Analog audio input supports 5-level sensitivity adjustment (+24dBu, +4dBu, 0dBu, 0dBv, -10dBv)
- ☆ Supports local USB-C port power supply and PoE function (Class 0 802.3af PoE)
- ☆ Compact design for easy and flexible installation

3. Package Contents


- ① 1x Dante® 2CH XLR Input Adapter
- ② 2x Hook & Loop
- ③ 1x User Manual

4. Specifications

Technical		
Input	Two-channel balanced/unbalanced XLR analog audio	
Output	Dante® 2CH digital audio	
Control Method	Dante® Controller	
Video Network Bandwidth	100M	
Audio Latency	Configurable Dante® device latency (Supports 1, 2 or 5ms configurable using Dante® Controller)	
Audio Formats	XLR IN [Analog audio input, Balanced/unbalanced 2CH, Max input level +24dBu] DANTE OUT [Digital audio output, PCM 2CH 44.1K-96KHz 16/24bit]	
Audio Parameters	XLR Analog Audio In	
	Input Impedance	20k Ohm balanced 10k Ohm unbalanced
	Line Input Level (Maximum)	+24dBu (12.28Vrms) @balanced audio +18dBu (6.15Vrms) @unbalanced audio
	Frequency Response	20Hz to 20kHz (-/+0.5dB)
	Dynamic Range	>100dB@0dBu, 1kHzA-weighted
	Audio S/N Ratio	>100dB@0dBu, 1kHzA-weighted
	Audio THD+N	< 0.01% at +4dBu, 1KHz
	Audio Output Sync Delay	<10ms
Transmission Distance	328ft/100m (CAT6/6A/7)	
ESD Protection	IEC 61000-4-2: ±8kV (Air-gap discharge) & ±4kV (Contact discharge)	

Connection	
Input port	2x CH1/CH2 XLR IN [XLR female plug, with 30cm cable] 1x POWER [USB-C power and firmware update port, 12-pin female]
Output port	1x DANTE [RJ45 connector, PoE]
Others	1x RESET button [System reboot button] 2x SENSITIVITY knob [5-level dip switch]
Mechanical	
Housing	Plastic Enclosure
Color	Black
Dimensions	115mm [W] x 40mm [D] x 28 mm [H]
Weight	173g
Power Supply	USB input: 5V/500mA PoE input: PoE IEEE802.3af Class 0
Power Consumption	2W (Max)
Operating Temperature	32 ~ 104°F / 0 ~ 40°C
Storage Temperature	-4 ~ 140°F / -20 ~ 60°C
Operating Humidity	20% ~ 80% RH (relative humidity, non-condensing)
Storage Humidity	10% ~ 90% RH (relative humidity, non-condensing)

5. Operation Controls and Functions




No.	Name	Function Description
1	DANTE (PoE) port	Dante® digital audio output port, connected to the Network Switch through RJ45 line, supporting PD power supply. The green LINK LED is always on after normal connection. The yellow DATA LED is flashing when there is data transmission.
2	CH1 Knob	The 5-level sensitivity adjustment knob for analog audio input channel 1. The knob arrows indicate: 1. +24dBu, 2. +4dBu, 3. 0dBu, 4. 0dBv, 5. -10dBv.
3	CH2 Knob	The 5-level sensitivity adjustment knob for analog audio input channel 2. The knob arrows indicate: 1. +24dBu, 2. +4dBu, 3. 0dBu, 4. 0dBv, 5. -10dBv.
4	CH1 plug	Balanced/unbalanced XLR analog audio input plug 1, connected to the analog audio source device.
5	CH2 plug	Balanced/unbalanced XLR analog audio input plug 2, connected to the analog audio source device.
6	RESET button	Press this button to reboot the unit.

No.	Name	Function Description
7	POWER port	USB-C port with following two functions: (1) USB-C 5V/500mA power input port. (2) Firmware update port.

Note: The RESET button can only be used for device reboot, and device reset setting needs to be done through the Dante® Controller.

6. Application Example

Dante® 2CH XLR Input Adapter



Network Switch (PoE)



Mixing Console



DVD or Blu-ray Player



Dante® Amplifier

Dante® 2CH XLR Output Adapter



Audio Amplifier



Speakers

Trademarks

Dante® is registered trademark of Audinate Pty Ltd. All other trademarks are the property of their respective owners.