

Thank you for your purchase. This guide will help you start using your new TV safely and quickly.

Basic recommended requirements

- 2 people
- Razor knife
(shallow set to cut tape only)
- Screwdriver
- Tape measure
- A soft clean surface, towel,
or blanket to lay the TV on
after unboxing

Start by measuring the path from your home's entry to the TV's final location if you haven't done so already. Then visit [BestBuy.com/HandleWithCare](https://www.bestbuy.com/HandleWithCare) before unboxing, and find the correct video that supports the size and box for your specific unit. The instructions in these videos can help prevent any damage to your TV during unboxing.

Lifting

Test the weight of the product before lifting to determine if you can safely lift it by yourself. When necessary, use 2 or 3 people to lift your TV or product depending on its size. When lifting, keep a wide base of support. Squat down, bending at the hips and knees only. Keep good posture. Look straight ahead, and keep your chest out, and your shoulders back. Lift gradually, not suddenly. Keep your back straight, and do not twist as you lift. Hold the load as close to your body as possible, at the level of your belly button. Use your feet to change direction, taking small steps. Keep your shoulders in line with your hips as you move. Set down your load carefully, squatting with the knees and hips only.

Unboxing and Installing

1. Carefully cut the tape at the top of the box.
2. Locate and remove the User Manual, remote, batteries, stand and extra packing that could be stored at the top of the TV.
3. Remove the 4 clips on the lower part of the TV. This is usually done by squeezing and pulling away from the box. This may vary for each TV manufacturer.
4. Hold the top part of the box on each end and lift directly up over the top of the TV.
5. For TVs that are 32" and smaller, grab both ends of the TV and lift it out of the packaging.

For larger TVs each person should put one hand as low as they can and lift the TV out of its packaging, while the person's other hand balances the TV from above. Make sure to only hold the TV by the edges and do not pinch the screen – this can break the display.

6. Lay the TV flat on the soft clean surface you prepared. Make sure the screen is facing down to avoid risk of damage to the screen and to more easily attach the stand(s).
7. If you're using the included TV stand, attach the TV stand(s) to the TV, and make sure to follow the manufacturer's instructions included with the TV.
8. With the stand(s) securely attached, carefully lift the TV with a similar grip as in step 5, then place the TV in your desired location. Make sure not to pinch the screen while lifting.
9. If mounting your new TV, make sure to use a mounting kit that matches your TV's size and weight. Before mounting, refer to the manufacturer manual that came with the mount, and make sure that your mount is securely anchored into the wall before attaching your TV.
10. Plug in your TV and connect any external sources like cable boxes, antennas, media players, or game consoles. Be sure to refer to the included owner's manual for any device or external source for basic setup instructions.
11. Finally, follow the guided setup on your new TV.

FOR GENERAL QUESTIONS please contact us @ 1-888-BEST BUY (237-8289).

FOR PRODUCT-SPECIFIC QUESTIONS contact the manufacturer support number provided in the user and installation manual.