



QUICK SETUP GUIDE

RF-ANT316 Ultra Thin Antenna


This antenna is designed for both analog and digital over-the-air TV broadcast reception. It can receive all the TV signals available in your area in the VHF and UHF bands.

PACKAGE CONTENTS

- Ultra thin antenna
- Antenna stand
- 2-sided foam tape (2 needed, 4 provided)
- Quick Setup Guide


FEATURES

- Reversible black/white-sided, ultra-thin structure
- Receives 1080i and 720p HDTV signals through built-in UHF and VHF antennas
- Multiple placement options: stand mount or hang on wall
- 5.5 ft (1.7 m) attached coaxial cable



POSITIONING YOUR ANTENNA

1 Choose a mounting method:




2 If possible, place your antenna near a window and away from sources of interference. See page 2 for more placement tips.

CONNECTING YOUR ANTENNA

This antenna can be connected directly to an HDTV or digital converter box.

HDTV


Connect the antenna's cable to the coaxial jack on the back of your TV.



OR

Digital converter box

- 1 Connect the antenna's cable to the coaxial jack on your digital converter box (not included).
- 2 Connect a video/audio cable (such as a coaxial or composite cable) from your converter box to your TV.



SCANNING FOR CHANNELS

- 1 Turn on your TV, then press input or source to select the input your antenna is connected to (usually labeled TV).
- 2 Open your TV's setup menu, then select the "scan" or "channel scan" option. Your TV automatically searches for available channels in your area.

Note: See your TV's user manual for detailed instructions.

TIPS FOR BETTER RECEPTION

- Place the antenna near a window if possible.
- Install the antenna as high as possible to avoid possible obstacles between the antenna and transmission tower. Obstacles may cause temporary signal loss.
- Keep the antenna away from sources of interference, such as air conditioners, hair dryers, or microwave ovens.
- Run a channel scan every time you move your antenna.
- If possible, position your antenna toward the transmission tower. To determine which channels are available in your area, visit www.antennaweb.org. Type in your zip code to get help with antenna placement.
- Test the antenna in multiple locations to find the strongest signal.
- This antenna is an indoor antenna. Do not place it outside.
- Run a channel scan monthly to make sure you are receiving all possible channels.
- Some TVs have a signal strength indicator that can help with antenna placement. See your TV manual to see if your TV has this feature.
- This antenna works with any TV or device with an ATSC tuner. Refer to the device manual to check compatibility.

TROUBLESHOOTING

PROBLEM	SOLUTION
Cannot find any channels	<ul style="list-style-type: none">• Make sure that you have selected the correct input on your TV.• Go to the menu on your TV or set top box, such as a cable/satellite box or streaming media device, and rescan the channels.• Make sure that all your connections are correct and secure.• Adjust your antenna, then rescan for available channels on your TV or set top box.• Make sure that you are connected to a TV or set top box with an ATSC tuner.
Picture quality is good on some channels and poor or no reception on others	<ul style="list-style-type: none">• Adjust your antenna, then scan for available channels on your TV or set top box.• Keep the antenna away from sources of interference such as air conditioners, hair dryers, and microwave ovens.• Your antenna may be too far from the broadcast antenna to receive an adequate signal. The signal may also be affected by obstructions between the broadcast antenna and your antenna.• Make sure that the signal strength from the antenna is adequate. Some TVs have a signal strength indicator. See your TV manual to see if your TV has this feature.• If you use a UHF/VHF amplifier to boost the signal level, make sure that it is operating correctly.
I don't know what digital TV reception I get in my area	<ul style="list-style-type: none">• To determine which channels are available in your area, visit www.antennaweb.org. Type in your zip code to get help with antenna placement.
Not all channels are available after performing a channel scan	<ul style="list-style-type: none">• Adjust your antenna, then scan for available channels on your TV or set top box.• Make sure that the signal strength from the antenna is adequate. Some TVs have a signal strength indicator. See your TV manual to see if your TV has this feature.

SPECIFICATIONS

- Frequency range: VHF 174-220 MHz, UHF 470-860 MHz
- Receiving range: UHF/VHF

LIFETIME PARTS & LABOR WARRANTY

Visit www.rocketfishproducts.com for details.

CONTACT ROCKETFISH:

For customer service, call
1-800-620-2790 (U.S. and Canada) or 01-800-926-3010 (Mexico)
www.rocketfishproducts.com

ROCKETFISH is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC

©2016 Best Buy. All rights reserved.

Made in China