

MAG Series

OLED Monitor

MAG 271QP QD-OLED X28 (3CF1)

User Guide

Contents

Getting Started	3
Package Contents	3
Installing the Monitor Stand	4
Adjusting the Monitor	5
Monitor Overview	6
Connecting the Monitor to PC	8
OSD Setup	10
Navi Key	10
Hot Key	10
OSD Menus	11
G.I	12
Gaming	12
Professional	14
Image	15
Input Source	15
Navi Key	16
Settings	16
MSI OLED Care	18
Specifications	20
Preset Display Modes	22
Troubleshooting	27
Safety Instructions	28
TÜV Rheinland Certification	30
Regulatory Notices	31

Revision

V1.0, 2025/05

Getting Started

This chapter provides you with the information on hardware setup procedures. While connecting devices, be careful in holding the devices and use a grounded wrist strap to avoid static electricity.

Package Contents

Monitor	MAG 271QP QD-OLED X28	
Documentation	Quick Start Guide	
Accessories	Stand	
	Stand Base with Screw(s)	
	Screw(s) for Wall Mount Bracket(s)	
	Power Cord	
Cable	DisplayPort Cable	




// Important

- Contact your place of purchase or local distributor if any of the items is damaged or missing.
- Package contents may vary by country and model.
- The included power cord is exclusively for this monitor and should not be used with other products.

Installing the Monitor Stand

- 1. Leave the monitor in its protective packaging. Align the stand to the monitor groove. Push the stand towards the monitor groove until it locks in place.
- 2. Connect the base to the stand and tighten the base screw to secure the base.
- 3. Make sure the stand assembly is properly installed before setting the monitor upright.



Important

- Place the monitor on a soft, protected surface to avoid scratching the display panel.
- Do not use any sharp objects on the panel.
- The groove for installing the stand bracket can also be used for wall mount. Please contact your dealer for proper wall mount kit.

Adjusting the Monitor


This monitor is designed to maximize your viewing comfort with its adjustment capabilities.





Important

- Avoid touching the display panel when adjusting the monitor.
- Please slightly tilt the monitor backwards before pivoting it.











Monitor Overview



0	Cable Routing Hole
2	G Key
	To activate the OSD Application.
3	Navi Key
4	Power Button
5	Kensington Lock
6	Power Jack
•	HDMI™ Connector H⊅ IIII™
	NIGH-DEFINITION MULTIMEDIA INTERFACE Supports HDMI™ CEC, 2560x1440@280Hz as specified in HDMI™ 2.1.
	↑
	Important
	To ensure optimal performance and compatibility, please use only HDMI™ cables certified with the official HDMI™ logo when connecting this monitor.
	For more information, please visit https://www.hdmi.org/resource/cables .
8	HDMI™ Connector H⊃ IIII™
	Supports 2560x1440@280Hz as specified in HDMI™ 2.1.
	1mportant
	To ensure optimal performance and compatibility, please use only HDMI™
	cables certified with the official HDMI [™] logo when connecting this monitor. For more information, please visit https://www.hdmi.org/resource/cables .
	DisplayPort
9	Supports 2560x1440@280Hz as specified in DisplayPort 1.4.
10	USB Type-C Port
	This port supports DisplayPort Alternate (DP Alt) Mode and up to 5V/3A (15W) power delivery.
	1mportant
	Your USB-C signal source and cable must support DisplayPort Alternate Mode to enable video output to the monitor.
1	Headphone Jack
M	Ventilator
	The ventilator on the enclosure is used for air convection and to prevent the equipment from overheating. Do not cover the ventilator. Please remove the protective film.


Connecting the Monitor to PC

- 1. Turn off your computer.
- 2. Connect the video cable from the monitor to your computer.
- 3. Connect the power cord to the monitor power jack. (Figure A)
- 4. Plug the power cord into the electrical outlet. (Figure B)
- 5. Turn on the monitor. (Figure C)
- 6. Power on the computer and the monitor will auto detect the signal source.





Please remove the protective films from the display panel and ventilation ports before use to optimize performance and prevent overheating.



OSD Setup

This chapter provides you with essential information on OSD Setup.




Important

All information is subject to change without prior notice.

Navi Key

The monitor comes with a Navi Key, a multi-directional control that helps navigate the On-Screen Display (OSD) menu.



Up/Down/Left/Right:

- selecting function menus and items
- adjusting function values
- entering into/exiting from function menus


Press (OK):

- launching the On-Screen Display (OSD)
- · entering submenus
- · confirming a selection or setting

Hot Key

- Users may enter into preset function menus by moving the Navi Key up, down, left or right when the OSD menu is inactive.
- Users may customize their own Hot Keys to enter into different function menus.

OSD Menus





Important

The following settings will be grayed out when HDR signals are received:

- Night Vision
- Low Blue Light
- Brightness
- Contrast

- Color Temperature
- Al Vision
- sRGB, Adobe RGB, Display P3

G.I.

1st Level Menu	2nd/3rd Lev	el Menu	Description
Smart Crosshair	Icon	None [+] -!!::::::::-	Through AI algorithm, this function enhances the visibility of in-game crosshair. Users can select the color and position of the crosshair.
	Color	White	
		Red	
		Auto	
	Position		
	Reset		

Gaming

1st Level Menu	2nd/3rd Level Menu	Description
Game Mode	Premium Color	Use Up or Down Button to select and preview
	User	mode effects. • Press the OK Button to confirm and apply your
	FPS	mode type.
	Racing	
	RTS	
	RPG	
Night Vision	OFF	This function optimizes background brightness
	Normal and is recommended for FF	and is recommended for FPS games.
	Strong	
	Strongest	
	A.I.	
Al Vision	OFF	Al Vision enhances image quality by optimizing
	ON	the contrast of images and background brightness.
		Activating AI Vision will affect:
		Affected Function Function Status
		» Night Vision Unable to select

1st Level Menu	2nd/3rd Level Menu		Description		
MPRT	OFF ON		MPRT Sync is available when the refresh rate is		
			over 85Hz. • Activating MPRT will affect:		
				Affected Function	Function Status
				» Adaptive-Sync	Set to OFF
Refresh Rate	Location	Left Top		Location is adjustable	in OSD Menu. Press the
Refresh Rate	Location	Right Top	1	OK Button to confirm a	and apply your Refresh
		Left Bottom		Rate Location. This monitor follows a	nd works at the
		Right Bottom	1		reset Screen Refresh Rate.
		Customize	$\frac{1}{1}$		
	OFF	Custofffize	1		
	ON		1		
Alarm Clock	Location	Left Top	•	After setting the time,	press the OK Button to
Autili clock	Location	Right Top	1	activate the timer.	press the on button to
		Left Bottom	•	Users have to manuall Alarm Clock after any	
		Right Bottom	1	reconnection.	to power toss and
		Customize	\mathbf{I}		
	OFF	Custofffize	1		
	15:00	00:01 ~ 99:59	1		
	30:00				
	45:00	_			
	60:00	-			
Adaptive-Sync	OFF		•	Adaptive-Sync prevent	ts screen tearing.
	ON		4	Activating Adaptive-Sy	•
				Affected Function	Function Status
				» Screen Size 1:1/ 24.5"	Set to Auto
				» MPRT	Set to OFF
DSC	OFF		•	Users can toggle DSC (Compression) on/off.	Display Stream
	ON				
				Affected Function	Function Status
				» Screen Size 16:10	Unable to select
HDMI™ 2.1 Console		The Console mode offers broader compatibility			
	PC		with more console devices.		

Professional

1st Level Menu	2nd Level Menu	Description
Pro Mode	Eco	Use Up or Down Button to select and preview mode
	User	effects.Press the OK Button to confirm and apply your mode
	Anti-Blue	type.
	Movie	The default setting "Eco" mode meets the requirements of TUV Rheinland's "Low Blue Light" standard.
	Office	Activating sRGB, Adobe RGB, and Display P3 will affect:
	sRGB	Affected Function Function Status
	Adobe RGB	» Color Temperature
	Display P3	» Low Blue Light Unable to select » Contrast
		" Contrast
Low Blue Light	OFF	Low Blue Light protects your eyes against blue light. When enabled, Low Blue Light adjusts the screen color
	ON	temperature to a more yellow glow.
		When Pro Mode is set to Anti-Blue, it is mandatory to enable Low Blue Light.
		This monitor is a Low Blue Light monitor which will decrease the blue light emitted without adjusting the OSD settings.
Image Enhancement	OFF	Image Enhancement enhances image edges to improve
	Weak	their acutance.
	Medium	
	Strong	
	Strongest	

Image

1st Level Menu	2nd/3rd Level Menu		De	escription	
Brightness	0-100		Properly adjust Brightness according to the surrounding lighting.		
Contrast	0-100		•	Properly adjust Contras	t to relax your eyes.
Sharpness	0-5		•	Sharpness improves cla images.	rity and details of
Color Temperature	Cool		•	Use Up or Down Button	to select and preview
	Normal			mode effects. Press the OK Button to o	confirm and apply your
	Warm			mode type.	committed apply your
	Customization	R (0-100)	•	Users can adjust Color 1	emperature in
		G (0-100)		custofffization friede.	
		B (0-100)			
Screen Size	Auto		Users can adjust Screen Size in any mode, any		
	4:3		resolution and any screen refresh rate.		
	16:9		•	Activating Screen Size 1	
	16:10		1	Affected Function	Function Status
	1:1		1	» Adaptive-Sync	Set to OFF
	24.5"		Important		
			at di	creen Size 1:1 refers to its original resolution sabled when the mon solution.	
DisplayHDR	True Black 400		The DisplayHDR function enhances visuals with customizable settings for optimized brightness and contrast.		
	Peak 1000 nits				
	EOTF Boost				

Input Source

1st Level Menu	2nd Level Menu	Description
HDMI™ 1		Users can adjust Input Source in any mode.
HDMI™ 2		
DP		
Type C		
Auto Scan	OFF	Users can use the Navi Key to select Input Source at
	ON	below status: While "Auto Scan" is set to "OFF" with the monitor at power saving mode; While "No Signal" message box is shown on the monitor.

Navi Key

1st Level Menu	2nd Level Menu	Description
Up	OFF	All Navi Key items can be adjusted via OSD Menus.
Down	Brightness	
Left Right	Game Mode	
G Key		
Alarm Clock Input Source Refresh Rate		
	Info. On Screen	
	Night Vision	

Settings

1st Level Menu	2nd Level Menu	Description
Language	繁體中文	Users have to press the OK Button to confirm and apply
	English	the Language setting. • Language is an independent setting. Users' own
	Français	language setting will override the factory default. When
	Deutsch	users set Reset to Yes, Language will not be changed.
	Italiano	
	Español	
	한국어	
	日本語	
	Русский	
	Português	
	简体中文	
	Bahasa Indonesia	
	Türkçe	
	(More languages coming soon)	
Transparency	0~5	Users can adjust Transparency in any mode.
OSD Time Out	5~30s	Users can adjust OSD Time Out in any mode.
Power Button OFF • When set to OFF, users can press the p turn off the monitor.	When set to OFF, users can press the power button to turn off the monitor.	
	Standby	When set to Standby, users can press the power button to turn off the panel and backlight.

1st Level Menu	2nd Level Menu	Description
Info. On Screen	OFF	The information of the monitor status will be shown on
	ON	the right side of the screen.
HDMI™ CEC	OFF	HDMI [™] CEC (Consumer Electronics Control) supports
	ON	Sony PlayStation®, Nintendo® Switch™, Xbox Series X S consoles and various audio-visual devices that are CEC-capable.
		If HDMI™ CEC is set to ON:
		The monitor will automatically power on when the CEC device is turned on.
		The CEC device will enter power saving mode when the monitor is turned off.
		 When Sony PlayStation®, Nintendo® Switch™, or Xbox Series X S console is connected, Game Mode and Pro Mode will be automatically set to default modes and can be adjusted to users' preferred modes later.
Type C PD Charge	OFF	This function enables users to charge their devices
	ON	through a USB Type-C connector.
Power LED	OFF	Users can toggle the Power LED on/off.
	ON	During the Panel Protect process, the power LED indicator will blink orange until the process is complete.
Reset	YES	Users can Reset and restore settings to original OSD
	NO	Default in any mode.

MSI OLED Care

1st Level Menu	2nd/3rd Level M	lenu	Description		
Pixel Shift	Slow		Pixel Shift moves the pixels of your screen at		
	Normal		regular intervals to reduce the possibility of screen burn-in or image retention.		
Fast					
Panel Protect			To maintain panel image quality, panel protect function will automatically activate when monitor using over 4 hours.		
			This protect function may take several minutes to complete.		
			The power indicator will blink orange color until process done.		
			During process executing, please do not unplug the power cord from monitor.		
			During process executing, press power button again to cancel this function.		
Protect Notice	Auto		When set to Auto, Protect Notice will pop up when the panel exceeds 4 hours of sumulative		
	Usage 24 hrs		when the panel exceeds 4 hours of cumulative usage.		
			When set to Usage 24 hrs, Protect Notice will pop up when the panel exceeds 24 hours of cumulative usage.		
			When Panel Protect is interrupted, Protect Notice will pop up upon next power-up.		
Static Screen	OFF		If Static Screen Detection is set to ON: When detecting static visuals over long periods of time, the monitor reduces brightness to prevent screen burn-in. Once detecting moving visuals, the monitor restores its previous brightness setting.		
Detection	ON				
	Starting in	50 Sec	Starting in detects the time a static image		
		100 Sec	remains on the screen.		
	Time required	120 Sec	Time required specifies the time for brightness reduction after detecting a static image for		
		240 Sec	50/100 seconds.		
			The brightness reduction level depends on the setting of Reducing Level.		
	Reducing Level	1-7	Users can select a level for brightness reduction.		
			Reducing effect depends on Brightness/ DisplayHDR setting.		

1st Level Menu	2nd/3rd Level M	lenu	Description		
Multi Logo Detection	OFF		This function helps prevent image sticking phenomenon. When set to ON, brightness		
	ON		reduction of multi logo areas will kick in if logos are detected.		
	Reducing Level	1-4	Users can select a level for brightness reduction.		
			Reducing effect depends on Brightness/ DisplayHDR setting.		
Taskbar Detection	OFF		This function helps prevent image sticking phenomenon. When set to ON, brightness		
	ON		reduction of taskbar areas will kick in if taskbars are detected.		
	Reducing Level	1-4	Users can select a level for brightness reduction.		
			Reducing effect depends on Brightness/ DisplayHDR setting.		
Boundary Detection	OFF		This function helps prevent image sticking phenomenon. When set to ON, brightness		
	ON		reduction of boundary areas will kick in if boundaries, such as letters & pillars, are detected.		
	Reducing Level	1-4	Users can select a level for brightness reduction.		
			Reducing effect depends on Brightness/ DisplayHDR setting.		
V-Split Detection	OFF		This function helps prevent image sticking phenomenon. When set to ON, brightness reduction along vertical boundaries during multitasking or split-screen gaming will kick in.		
	ON				
	Reducing Level	1-4	Users can select a level for brightness reduction.		
			Reducing effect depends on Brightness/ DisplayHDR setting.		
Auto DIM Control	OFF ON		This function prevents image sticking by gradually dimming the screen. When set to ON,		
			it automatically reduces full-screen brightness when detecting static images.		
	Starting Speed	Slow	Starting Speed defines how quickly Auto DIM Control detects a static image.		
		Fast	Control detects a static image.		
	Reducing Speed	Slow	Users can specify the speed for brightness reduction.		
	Fast		A Harran and advantage of the Control of the Contro		
	Reducing Level	1-6	Users can select a level for brightness reduction.		
			Reducing effect depends on Brightness/ DisplayHDR setting.		
OLED Panel Info.			This field shows the information of MSI OLED Care.		

Specifications*

Monitor	MAG 271QP QD-OLED X28
Size	26.5 inch
Curvature	Flat
Panel Type	QD-OLED
Resolution	2560x1440 (WQHD)
Aspect Ratio	16:9
Brightness	Typical SDR: 250 nits
	Peak HDR: 1000 nits
Contrast Ratio	1500000:1
Refresh Rate	280Hz
Response Time	0.03ms (GTG)
I/O	2 x HDMI [™] Connector
	• 1 x DisplayPort
	• 1 x USB Type-C Port
	• 1 x Headphone Jack
View Angles	178°(H), 178°(V)
DCI-P3** / sRGB	99.1%/ 138.4%
Surface Treatment	Anti-Reflection
Display Colors	1.07B (10 bits)
Monitor Power Options	100-240V~, 50/60Hz, 2.7A
Power Consumption	Power On < 120W
(Typical)	Standby < 0.5W
	Power Off < 0.3W
Adjustment (Height)	0 ~ 110mm
Adjustment (Tilt)	-5° ~ 20°
Adjustment (Swivel)	-30° ~ 30°
Adjustment (Pivot)	-90° ~ 90°
Kensington Lock	Yes
VESA Mounting	Plate Type: 100 x 100 mm
	Screw Type: M4 x 10 mm
	Thread Diameter: 4 mm
	Thread Pitch: 0.7 mm
	Thread Length: 10 mm

Monitor		MAG 271QP QD-OLED X28			
Dimension (W x H x D)		609 x 416 x 242 mm			
Weight	Net	8.2 kg			
	Gross	10.9 kg			
Operating Envir	onment	Temperature: 0°C to 40°C			
		Humidity: 20% to 90%, non-condensing			
		• Altitude: 0 ~ 5000m			
Storage Environment		• Temperature: -20°C to 60°C			
		Humidity: 10% to 90%, non-condensing			

^{*} Some technical specifications of the device may be subject to change by the manufacturer. Please verify the specifications with the seller or the manufacturer's representative.

^{**} Based on CIE1976 test standards.

Preset Display Modes



Important

- All information is subject to change without prior notice.
- HDMI™ VRR (Variable Refresh Rate) synchronizes with Adaptive-Sync (ON/ OFF). For VRR ON/OFF status, please check Adaptive-Sync.
- To activate DSC-specific timing and frequency, ensure your graphics card supports DSC (Display Stream Compression).

Standard Default Mode (HDMI™ 2.1 - PC, DSC On)

Standard	Resolution		HDMI™	DP	USB-C
VGA	640x480	@60Hz	V	V	V
		@67Hz	V	V	V
		@72Hz	V	V	V
		@75Hz	V	V	V
Dos-Mode	720x480	@60Hz	V	V	V
	720x576	@50Hz	V	V	V
SVGA	800x600	@56Hz	V	V	V
		@60Hz	V	V	V
		@72Hz	V	V	V
		@75Hz	V	V	V
XGA	1024x768	@60Hz	V	V	V
		@70Hz	V	V	V
		@75Hz	V	V	V
SXGA	1280x1024	@60Hz	V	V	V
		@75Hz	V	V	V
WXGA+	1440x900	@60Hz	V	V	V
WSXGA+	1680x1050	@60Hz	V	V	V
Full HD	1920x1080	@60Hz	V	V	V
QHD	2560x1440	@60Hz	V	V	V
		@120Hz	V	V	V
		@240Hz	V	V	V
		@280Hz	V	V	V
Video Timing	720P	•	V	V	V
Resolution	1080P	@60Hz	V	V	V
		@120Hz	V	V	V
HDMI™ VRR	HDMI™ VRR				

HDMI[™] 2.1 - PC, DSC Off

Standard	Resolution		HDMI™	DP	USB-C
VGA	640x480	@60Hz	V	V	V
		@67Hz	V	V	V
		@72Hz	V	V	V
		@75Hz	V	V	V
Dos-Mode	720x480	@60Hz	V	V	V
	720x576	@50Hz	V	V	V
SVGA	800x600	@56Hz	V	V	V
		@60Hz	V	V	V
		@72Hz	V	V	V
		@75Hz	V	V	V
XGA	1024x768	@60Hz	V	V	V
		@70Hz	V	V	V
		@75Hz	V	V	V
SXGA	1280x1024	@60Hz	V	V	V
		@75Hz	V	V	V
WXGA+	1440x900	@60Hz	V	V	V
WSXGA+	1680x1050	@60Hz	V	V	V
Full HD	1920x1080	@60Hz	V	V	V
QHD	2560x1440	@60Hz	V	V	V
		@120Hz	V	V	V
		@240Hz	V	V	V
		@280Hz	V		
Video Timing	720P		V	V	V
Resolution	1080P	@60Hz	V	V	V
		@120Hz	V	V	V
HDMI™ VRR	HDMI™ VRR				

HDMI™ 2.1 - Console, DSC On

Standard	Resolution		HDMI™	DP	USB-C
VGA	640x480	@60Hz	V	V	V
		@67Hz	V	V	V
		@72Hz	V	V	V
		@75Hz	V	V	V
Dos-Mode	720x480	@60Hz	V	V	V
	720x576	@50Hz	V	V	V
SVGA	800x600	@56Hz	V	V	V
		@60Hz	V	V	V
		@72Hz	V	V	V
		@75Hz	V	V	V
XGA	1024x768	@60Hz	V	V	V
		@70Hz	V	V	V
		@75Hz	V	V	V
SXGA	1280x1024	@60Hz	V	V	V
		@75Hz	V	V	V
WXGA+	1440x900	@60Hz	V	V	V
WSXGA+	1680x1050	@60Hz	V	V	V
Full HD	1920x1080	@60Hz	V	V	V
QHD	2560x1440	@60Hz	V	V	V
		@120Hz	V	V	V
		@240Hz	V	V	V
		@280Hz	V	V	V
Video Timing	720P		V	V	V
Resolution	1080P	@60Hz	V	V	V
		@120Hz	V	V	V
	2160P	@30Hz	V		
		@60Hz	V		
		@120Hz	V		
HDMI™ VRR	HDMI™ VRR				

HDMI[™] 2.1 - Console, DSC Off

Standard	Resolution		HDMI™	DP	USB-C
VGA	640x480	@60Hz	V	V	V
		@67Hz	V	V	V
		@72Hz	V	V	V
		@75Hz	V	V	٧
Dos-Mode	720x480	@60Hz	V	V	٧
	720x576	@50Hz	V	V	V
SVGA	800x600	@56Hz	V	V	V
		@60Hz	V	V	V
		@72Hz	V	V	V
		@75Hz	V	V	V
XGA	1024x768	@60Hz	V	V	V
		@70Hz	V	V	V
		@75Hz	V	V	V
SXGA	1280x1024	@60Hz	V	V	V
		@75Hz	V	V	V
WXGA+	1440x900	@60Hz	V	V	V
WSXGA+	1680x1050	@60Hz	V	V	V
Full HD	1920x1080	@60Hz	V	V	V
QHD	2560x1440	@60Hz	V	V	V
		@120Hz	V	V	V
		@240Hz	V	V	V
		@280Hz	V		
Video Timing	720P		V	V	V
Resolution	1080P	@60Hz	V	V	V
		@120Hz	V	V	V
	2160P	@30Hz	V		
		@60Hz	V		
		@120Hz	V		
HDMI™ VRR	HDMI™ VRR				

Screen Size 16:10 (Not Support HDR)

Standard	Resolution		HDMI™	DP	USB-C
VGA	640x480	@60Hz	V	V	V
		@67Hz	V	V	V
		@72Hz	V	V	V
		@75Hz	V	V	V
Dos-Mode	720x480	@60Hz	V	V	V
	720x576	@50Hz	V	V	V
SVGA	800x600	@56Hz	V	V	V
		@60Hz	V	V	V
		@72Hz	V	V	V
		@75Hz	V	V	V
XGA	1024x768	@60Hz	V	V	V
		@70Hz	V	V	V
		@75Hz	٧	٧	٧
SXGA	1280x1024	@60Hz		٧	٧
		@75Hz	V	V	V
WXGA+	1440x900	@60Hz		٧	٧
WSXGA+	1680x1050	@60Hz		٧	٧
Full HD	1920x1080	@60Hz	V	V	٧
QHD+	2560x1600	@60Hz	V	V	٧
		@120Hz	V	V	V

Troubleshooting

The power LED is off.

- Press the monitor power button again.
- Check if the monitor power cable is properly connected.

No image.

- Check if the computer graphics card is properly installed.
- Check if the computer and monitor are connected to electrical outlets and are turned on.
- Check if the monitor signal cable is properly connected.
- The computer may be in Standby mode. Press any key to activate the monitor.

The screen image is not properly sized or centered.

 Refer to Preset Display Modes to set the computer to a setting suitable for the monitor to display.

No Plug & Play.

- Check if the monitor power cable is properly connected.
- Check if the monitor signal cable is properly connected.
- Check if the computer and graphics card are Plug & Play compatible.

The icons, font or screen are fuzzy, blurry or have color problems.

- Avoid using any video extension cables.
- · Adjust brightness and contrast.
- Adjust RGB color or tune color temperature.
- Check if the monitor signal cable is properly connected.
- Check for bent pins on the signal cable connector.

The monitor starts flickering or shows waves.

- Change the refresh rate to match the capabilities of your monitor.
- Update your graphics card drivers.
- Keep the monitor away from electrical devices that may cause electromagnetic interference (EMI).

Safety Instructions

- Read the safety instructions carefully and thoroughly.
- All cautions and warnings on the device or User Guide should be noted.
- Refer servicing to qualified personnel only.

Power

- Make sure that the power voltage is within its safety range and has been adjusted properly to the value of 100~240V before connecting the device to the power outlet.
- If the power cord comes with a 3-pin plug, do not disable the protective earth pin from the plug. The device must be connected to an earthed mains socket-outlet.
- Please confirm the power distribution system in the installation site shall provide the circuit breaker rated 120/240V, 20A (maximum).
- Always disconnect the power cord or switch the wall socket off if the device would be left unused for a certain time to achieve zero energy consumption.
- Place the power cord in a way that people are unlikely to step on it. Do not place anything on the power cord.
- If this device comes with an adapter, use only the MSI provided AC adapter approved for use with this device.

Environment

- To reduce the possibility of heat-related injuries or of overheating the device, do not place the device on a soft, unsteady surface or obstruct its air ventilators.
- Use this device only on a hard, flat and steady surface.
- To prevent the device from tipping over, secure the device to a desk, wall or fixed object with an anti-tip fastener that helps to properly support the device and keep it safe in place.
- To prevent fire or shock hazard, keep this device away from humidity and high temperature.
- Do not leave the device in an unconditioned environment with a storage temperature above 60°C or below -20°C, which may damage the device.
- The maximum operating temperature is around 40°C.
- When cleaning the device, be sure to remove the power plug. Use a piece of soft cloth rather than industrial chemical to clean the device. Never pour any liquid into the opening; that could damage the device or cause electric shock.
- Always keep strong magnetic or electrical objects away from the device.

- If any of the following situations arises, get the device checked by service personnel:
 - The power cord or plug is damaged.
 - Liquid has penetrated into the device.
 - The device has been exposed to moisture.
 - The device does not work well or you can not get it working according to the User Guide.
 - The device has dropped and damaged.
 - The device has obvious sign of breakage.

TÜV Rheinland Certification

TÜV Rheinland Low Blue Light Certification

Blue light has been shown to cause eye fatigue and discomfort. MSI now offers monitors with TÜV Rheinland Low Blue Light certification to ensure users' eye comfort and well-being. Please follow the instructions below to reduce the symptoms from extended exposure to the screen and blue light.



- Place the screen 20 28 inches (50 70 cm) away from your eyes and a little below eye level.
- Consciously blinking the eyes every now and then will help to reduce eye strain after extended screen time
- Take breaks for 20 minutes every 2 hours.
- Look away from the screen and gaze at a distant object for at least 20 seconds during breaks.
- Make stretches to relieve body fatigue or pain during breaks.

TÜV Rheinland Flicker Free Certification

- TÜV Rheinland has tested this product to ascertain whether the display produces visible and invisible flicker for the human eye and therefore strains the eyes of users.
- TÜV Rheinland has defined a catalogue of tests, which sets out minimum standards at various frequency ranges. The test catalogue is based on internationally applicable standards or standards common within the industry and exceeds these requirements.
- The product has been tested in the laboratory according to these criteria.
- The keyword "Flicker Free" confirms that the device has no visible and invisible flicker defined in this standard within the range of 0 - 3000 Hz under various brightness settings.
- The display will not support Flicker Free when Anti Motion Blur/MPRT is enabled. (The availability of Anti Motion Blur/MPRT varies by products.)



Regulatory Notices

CE Conformity

This product has been tested and found to comply with the harmonized standards for Information Technology Equipment published under Directives of Official Journal of the European Union.



FCC-B Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may



cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures listed below:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice 2

Shielded interface cables and AC power cord, if any, must be used in order to comply with the emission limits

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

MSI Computer Corp.

901 Canada Court, City of Industry, CA 91748, USA (626) 913-0828

www.msi.com

WEEE Statement

Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2012/19/EU, products of "electrical and electronic equipment" cannot be discarded as municipal waste anymore and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life.



Chemical Substances Information

In compliance with chemical substances regulations, such as the EU REACH Regulation (Regulation EC No. 1907/2006 of the European Parliament and the Council), MSI provides the information of chemical substances in products at: https://csr.msi.com/global/index

RoHS Statement

Japan JIS C 0950 Material Declaration

A Japanese regulatory requirement, defined by specification JIS C 0950, mandates that manufacturers provide material declarations for certain categories of electronic products offered for sale after July 1, 2006.

https://csr.msi.com/global/Japan-JIS-C-0950-Material-Declarations

India RoHS

This product complies with the "India E-waste (Management and Handling) Rule 2016" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

Turkey EEE Regulation

Conforms to the EEE Regulations of the Republic Of Turkey

Ukraine Restriction of Hazardous Substances

The equipment complies with requirements of the Technical Regulation, approved by the Resolution of Cabinet of Ministry of Ukraine as of 10 March 2017, № 139, in terms of restrictions for the use of certain dangerous substances in electrical and electronic equipment.

Vietnam RoHS

As from December 1, 2012, all products manufactured by MSI comply with Circular 30/2011/TT-BCT temporarily regulating the permitted limits for a number of hazardous substances in electronic and electric products.

Green Product Features

- Reduced energy consumption during use and stand-by
- Limited use of substances harmful to the environment and health
- Easily dismantled and recycled
- Reduced use of natural resources by encouraging recycling
- Extended product lifetime through easy upgrades
- Reduced solid waste production through take-back policy

Environmental Policy

- The product has been designed to enable proper reuse of parts and recycling and should not be thrown away at its end of life.
- Users should contact the local authorized point of collection for recycling and disposing of their end-of-life products.



- Visit the MSI website and locate a nearby distributor for further recycling information.
- Users may also reach us at gpcontdev@msi.com for information regarding proper disposal, take-back, recycling, and disassembly of MSI products.
- Please visit <https://us.msi.com/page/recycling for information regarding the recycling of your product in the US.

Warning!

Overuse of screens is likely to affect eyesight.

Recommendations:

- 1. Take a 10-minute break for every 30 minutes of screen time.
- 2. Children under 2 years of age should have no screen time. For children aged 2 years and over, screen time should be limited to less than one hour per day.

Copyright and Trademarks Notice







Copyright © Micro-Star Int' I Co., Ltd. All rights reserved. The MSI logo used is a registered trademark of Micro-Star Int' I Co., Ltd. All other marks and names mentioned may be trademarks of their respective owners. No warranty as to accuracy or completeness is expressed or implied. MSI reserves the right to make changes to this document without prior notice.



The terms HDMI[™], HDMI[™] High-Definition Multimedia Interface, HDMI[™] Trade dress and the HDMI[™] Logos are trademarks or registered trademarks of HDMI[™] Licensing Administrator, Inc.

Technical Support

If a problem arises with your product and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please visit https://www.msi.com/support/ for further guidance.