




Assembly Instructions




For the most current instructions, additional assembly tips, to report damage or request parts, please visit our website at www.walker-edison.com.


Revised 06/2017

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product .






- VII. Power tools should not be used to assemble this product .




Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	30 pcs
B			Cam bolt	26 pcs
C		Ø15x11mm	Cam lock	26 pcs
D		Ø6x50mm	Bolt	4 pcs
E			Hinge	4 pcs
F		Ø3x12mm	Screw	24 pcs
G			Handle	2 pcs
H		Ø4x22mm	Bolt	4 pcs
J		Ø8x5x16mm	Shelf support pin	12 pcs
K			Plastic wedges	12 pcs
L		Ø3x17mm	Screw	12 pcs
M		30x20mm	Metal piece	2 pcs
N		Ø3x12mm	Screw	2 pcs
P			Door stopper	2 pcs
Q		Ø3x15mm	Screw	4 pcs
R			Sticker	26 pcs
S		Ø4mm	Wrench	1 pc
T			Glue tube	2 pcs
U		Ø4x45	Screw	3 pcs



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Attach cam bolts (B) to parts (1) and (2).

Step 2




Attach cam bolts (B) to part (8). Insert wooden dowels (A) to parts (9, 10) and (19).

Step 3




Insert wooden dowels (A) into designated areas in parts (3, 4, 5, 6) and (7). Attach cam bolts (B) to parts (3, 4, 5, 6).

Step 4




Attach parts (3) and (5) to part (7), and then attach cam locks (C) to fully assembled part (7).

Step 5





Attach parts (4) and (6) to the other part (7), and then insert cam locks (C) to the fully assembled part (7).

Step 6




Attach cam locks (C) to parts (13) to panel (2). Attach slat (19) to panel (2) using screw (U) as guides.

Step 7





Attach cam locks (C) to part (9) to connect part (8), and to part (10) to connect to the other part (8).

Step 8





Use the wrench (S) to use bolts (D) to connect parts (9) and (10) to part (2).

Step 9




Use cam bolts (C) to connect parts (3) and (5) to part (2).

Step 10




Use cam bolts (C) to connect parts (4) and (6) to part (2).

Step 11




Slide parts (14) and (17) into designated area.

Step 12




Use cam bolts to connect part (1) to the frame assembly as shown in the diagram.

Step 13




Attach the plastic wedges (K) by using the screws (L) as shown in the diagram.

Step 14




Attach door stopper (P) to designated areas by using screws (Q).

Step 15




Place stickers (R) over cam locks as desired.

Step 16




Insert shelf supports (J) and place shelves (15,16) and (18) as shown in the diagram.

Step 17




Attach hinges (E) to the doors (11,12) by using screws (F).

Step 18




Attach handles (G) to the doors (11,12) by using screws (H). Attach metal stopper (M) using screw (N).

Step 19



Attach hinges (E) by using screws (F) as shown in the diagram.

Step 20



Final Assembly