

Refrigerator Filter

Quick Setup Guide

BE-WP508531

BEST BUY
essentials™

Before using your new product, please read these instructions to prevent any damage.

Package contents

- Refrigerator water filter(s) (1 or 2 pack)
- *Quick Setup Guide*

Compatibility

Compatible with the following branded filters:

Whirlpool®

4396508, 4396508P, 4392857, 4392857R, 4396510, 4396510P, 8212491, 2255520, SBS002, SBS003, SBS004, 481281729632, 4396918, 4396562, 4396563, 2200203, 2203220, 2203980, 2305766, 2305767, 2305768, 2255518, 2186444, PWF-NL240V, PNL240V, WF-NL240V, WFNL240V, NL240V, WF-NL240, WFNL240, NL240, WF-NL300, WFNL300, NL300, PWF-L400V, PL400V, WFL400V, WFL400V, L400V, WF-L400, WFL400, L400, WF-L500, WFL500, L500, WF-300BR, (filter system that uses 4396508)

KitchenAid®

4396547, 4396163, 4396509, 4396509P, 4396548, 4396164, 2203221, 2255709

Sears® / Kenmore®

46-9902, 469902, 9902, 9902P, 04609902000, 46-9908, 469908, 9908, 9908P, 04609908000, 46-9010, 469010, 9010, 9010P, 04609010000

Installing your filter

- It is normal for black carbon particles to appear on the outside of your new filter during shipping. Simply wipe it away before installation.
 - This water filter is designed to prevent leaks. Please twist in place securely to ensure a proper fit.
- 1 Twist the old filter a quarter-turn counterclockwise, then pull it straight out.
 - 2 Remove the reusable color-keyed knob from the end of your old filter, then slide it on your new filter.
 - 3 Discard the old filter.
 - 4 Carefully remove the plastic cap from the new filter before installation.
 - 5 Push the new filter into the refrigerator until it stops.
 - 6 Twist the filter a quarter-turn clockwise.
 - 7 Run about two gallons (7.6 L) to three gallons (11.3L) of water through your refrigerator's water dispenser to remove air and loose carbon pieces. The water may be cloudy and sputter until the air is removed.
 - 8 Reset your "change filter" indicator (if your refrigerator has one). See below.

Before using your filter

If your refrigerator has a change filter indicator, reset it. See "Resetting your filter indicator" for instructions.

Resetting your filter indicator

Note: These are the most common filter reset instructions. If the instructions don't work for your refrigerator brand, see the documentation that came with your refrigerator.

- **Whirlpool® and Kitchen Aid®:** Press the light switch five times in 10 seconds. If the fridge has a filter button, press and hold it for 5-10 seconds.
- **Kenmore®:** The water filter reset for Kenmore refrigerators varies by model. See the documentation that came with your refrigerator.

Storage and maintenance

- Replace your filter every three to six months to prevent bacteria and fungus growth in your filter, supply lines, and storage tank.
- Stored filters do not expire. Keep your unused filters in a cool, dark, and dry place until you need them.
- If you do not use your water dispenser for more than four days, run two gallons (7.6 L) of water before using it to prevent bad tasting water.

Troubleshooting

My refrigerator is not dispensing water

- Make sure that the filter is securely connected to the receiver. Do not use tools to tighten the filter in place.
- Make sure that the water line to the refrigerator is turned on. The valve must be completely open for the refrigerator to receive water.
- Make sure that the refrigerator door is closed or the dispenser will not work.

My water dispenser is dripping

- A few drops are normal. If the water is dripping constantly, have a service technician check your refrigerator's water valve.

My water is cloudy or contains black carbon pieces

- Cloudy water is caused by microscopic air bubbles. Run two (7.6 L) to three (11.3L) gallons of water from your dispenser to clear the air bubbles out.
- Black carbon pieces in the water are normal and appear with all carbon filters. Run two (7.6 L) to three (11.3L) gallons of water through your dispenser to remove loose carbon pieces.

My new filter is making noises or sputtering

- Noises and sputtering are caused by trapped air pockets. Run two (7.6 L) to three gallons (11.3 L) of water through your dispenser to push the air out.
- Reinstall the new filter as instructed and make sure that the filter is securely connected to the receiver. Do not use tools to tighten the filter in place.

My water tastes bad

- If you do not use your water dispenser for more than four days, run two gallons (7.6 L) of water through the dispenser before using it.
- Make sure that you replace your filter every three to six months to prevent bacteria growth.

Specifications

- **Temperature:** 33~100° F (0.6~38° C)
- **Pressure:** 20-100 psi (140-689 kPa)
- **Capacity:** 300 gal (1137 L)
- **Flow rate:** 0.5 gpm (1.9 lpm)

Substance reduction

The system has been tested and certified by the NSF International according to NSF/ANSI Standards 42 and 53 for the reduction of the substances listed below. The concentration of the indicated substances in water entering the system was reduced to a concentration less than or equal to the permissible limit for the water leaving the system, as specified by NSF/ANSI Standards 42 and 53. While testing was performed under standard laboratory conditions, actual performance may vary.

Performance data sheet

| SUBSTANCE | INFLUENT AVERAGE | NSF SPECIFIED CHALLENGE CONCENTRATION | AVE. % REDUCTION | AVERAGE PRODUCT WATER CONCENTRATION | MAX. PERMISSIBLE PRODUCT WATER CONCENTRATION | NSF REDUCTION REQUIREMENTS | NSF TEST REPORT |
|---------------------------|-------------------|---------------------------------------|------------------|-------------------------------------|--|----------------------------|-----------------|
| Chlorine, taste, and odor | 1.9 mg/L | 2.0 mg/L ± 10% | 95.7% | 0.082 mg/L | N/A | ≥50% | J-00295502 |
| Benzene | 15 ug/L | 15 ug/L ± 10% | 96.6% | 0.5 ug/L | 0.5 ug/L | N/A | J-00268283 |
| Carbofuran | 73 ug/L | 73 ug/L ± 10% | 98.4% | 2 ug/L | 40 ug/L | N/A | J-00268284 |
| Lead (pH 8.5) | 140 ug/L | 140 ug/L ± 10% | 99.6% | 0.5 ug/L | 10 ug/L | N/A | J-00268279 |
| Lead (pH 6.5) | 140 ug/L | 140 ug/L ± 10% | 99.6% | 0.5 ug/L | 10 ug/L | N/A | J-00268280 |
| Cyst | 120,000 oocysts/L | minimum 50000 oocysts/L | >99.99% | 1 oocysts/L | N/A | ≥99.95% | J-00263594 |
| Endrin | 6 ug/L | 6 ug/L ± 10% | 93.6% | 0.3 ug/L | 2 ug/L | N/A | J-00296278 |
| Mercury (pH 8.5) | 6 ug/L | 6 ug/L ± 10% | 92.3% | 0.5 ug/L | 2 ug/L | N/A | J-00326152 |
| Mercury (pH 6.5) | 6 ug/L | 6 ug/L ± 10% | 93.8% | 0.3 ug/L | 2 ug/L | N/A | J-00268282 |

Certifications



Tested and Certified by NSF International in Model EFF-6002S against NSF/ANSI Standards 42 and 53 for the reduction of the claims specified on the Performance Data Sheet.

System Model No.: EFF-6002S
Replacement Filter Cartridge Model No.: BE-WP508531

One-year limited warranty

Visit www.bestbuy.com/bestbuyessentials for details.

Contact Best Buy essentials

For customer service, call 866-597-8427 (U.S. and Canada)
www.bestbuy.com/bestbuyessentials

Best Buy essentials is a trademark of Best Buy and its affiliated companies.
Distributed by Best Buy Purchasing, LLC
7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2021 Best Buy. All rights reserved.