

Please see www.insigniaproducts.com for the latest Quick Start Guide and troubleshooting.

ouick setup guide Racing Wheel Stand NS-URSS22



Before using your new product, please read these instructions to prevent any damage.

PACKAGE CONTENTS



WARNING CHOKING HAZARD - Small parts not for children under 3 years or any individuals who have a tendency to place inedible objects in their mouths.

 \bigcirc

 $\begin{array}{c} 0 \\ 0 \\ 0 \end{array}$

/0

00%

 \circ

WHEEL PLATE

0


Ο

 \circ

Ο

SHIFTER PLATE


0 %



M6 ALLEN KEY M8 ALLEN KEY



4 X M8 BOLT 16mm



2 X M8 KNOB 41mm

3 X M8 BOLT 40mm

WRENCH 10mm

WRENCH 12mm





15 X M6 BOLT 16mm

6 X WASHERS



3 X VELCRO CABLE TIE

STEP 1:

Pull out the latch to unfold the wheel stand. Then lay down the pedal frame.




STEP 2:


Install the knobs on the pivot joints. Secure it in place with 2 M8 41mm knobs.



STEP 3:

Loosen the preinstalled knobs on the vertical posts. Adjust to your desired height and then tighten the knobs to secure it in place.





STEP 4:


Loosen the bolts on both sides. Adjust the pedal plate to your desired angle and retighten the bolts.



STEP 5:


Line up the holes on the frame and wheel plate. Secure it using the M8 16mm bolts and nuts.






STEP 6:

Line up the hole on the shifter plate with the slots on the shifter arm. Install the bolts and secure using the M6 16mm bolts and nuts.





STEP 7:

The shifter mount can be used on the left or right side of the wheel stand. Pick your preferred side. Then line up the holes on the shifter mounting arm with the threaded inserts on the vertical post. Secure it in place with 2 M8 40mm bolts and nuts.



STEP 8:

This stand is compatible and predrilled for most major wheels and pedals or compatible using a table clamp (if provided with the wheel). Including Logitech® G25, G27, G29 and G920; Thrustmaster® T248, Tx 458, T500 RS, T300RS, T300 Ferrari Edition, T80 and all Fanatec® wheels on the market.



FULL RANGE OF ADJUSTABILITY

- 1. Wheel angle adjustment
- 2. Wheel and Shifter height adjustment
- 3. Pedal plate angle adjustment



FOLDABLE DESIGN ALLOWS EASY STORAGE

- 1. Lift the pedal frame.
- 2. Pull in the latch to secure the pedal assembly.
- 3. Loosen the knobs on the pivot joint.
- 4. Pull the legs together to fold the stand.
- 5. Once fully open or closed, tighten all knobs to secure the stand.



INSIGNIA[®] ONE-YEAR LIMITED WARRANTY

Definitions:

The Distributor* of Insignia branded products warrants to you, the original purchaser of this new Insignia-branded product ("Product"), that the Product shall be free of defects in the original manufacturer of the material or workmanship for a period of one (1) year from the date of your purchase of the Product ("Warranty Period").

For this warranty to apply, your Product must be purchased in the United States or Canada from a Best Buy branded retail store or online at www.bestbuy.com or www.bestbuy.ca and is packaged with this warranty statement.

How long does the coverage last?

The Warranty Period lasts for 1 year (365 days) from the date you purchased the Product. Your purchase date is printed on the receipt you received with the Product.

What does this warranty cover?

During the Warranty Period, if the original manufacture of the material or workmanship of the Product is determined to be defective by an authorized Insignia repair center or store personnel, Insignia will (at its sole option): (1) repair the Product with new or rebuilt parts; or (2) replace the Product at no charge with new or rebuilt comparable products or parts. Products and parts replaced under this warranty become the property of Insignia and are not returned to you. If service of Products or parts are required after the Warranty Period expires, you must pay all labor and parts charges. This warranty lasts as long as you own your Insignia Product during the Warranty Period. Warranty coverage terminates if you sell or otherwise transfer the Product.

How to obtain warranty service?

If you purchased the Product at a Best Buy retail store location or from a Best Buy online website (www.bestbuy.com or www.bestbuy.ca), please take your original receipt and the Product to any Best Buy store. Make sure that you place the Product in its original packaging or packaging that provides the same amount of protection as the original packaging. To obtain warranty service, in the United States and Canada call 1-877-467-4289. Call agents may diagnose and correct the issue over the phone.

Where is the warranty valid?

This warranty is valid only in the United States and Canada at Best Buy branded retail stores or websites to the original purchaser of the product in the country where the original purchase was made.

What does the warranty not cover?

This warranty does not cover:

- Food, beverage, and or medicine loss/spoilage.
- Customer instruction/education
- Installation
- Set up adjustments
- Cosmetic damage
- Damage due to weather, lightning, and other acts of God, such as power surges
- Accidental damage
- Misuse
- Abuse
- Negligence

• Commercial purposes/use, including but not limited to use in a place of business or in communal areas of a multiple dwelling condominium or apartment complex, or otherwise used in a place of other than a private home.

• Modification of any part of the Product, including the antenna

INSIGNIA[®] ONE-YEAR LIMITED WARRANTY

- Display panel damaged by static (non-moving) images applied for lengthy periods (burn-in).
- Damage due to incorrect operation or maintenance
- Connection to an incorrect voltage or power supply
- Attempted repair by any person not authorized by Insignia to service the Product
- Products sold "as is" or "with all faults"
- Consumables, including but not limited to batteries (i.e. AA, AAA, C etc.)
- Products where the factory applied serial number has been altered or removed
- · Loss or Theft of this product or any part of the product

• Display panels containing up to three (3) pixel failures (dots that are dark or incorrectly illuminated) grouped in an area smaller than one tenth (1/10) of the display size or up to five (5) pixel failures throughout the display. (Pixel based displays may contain a limited number of pixels that may not function normally.)

• Failures or Damage caused by any contact including but not limited to liquids, gels or pastes.

REPAIR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS YOUR EXCLUSIVE REMEDY FOR BREACH OF WARRANTY. INSIGNIA SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR THE BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, INCLUDING, BUT NOT LIMITED TO, LOST DATA, LOSS OF USE OF YOUR PRODUCT, LOST BUSINESS OR LOST PROFITS. INSIGNIA PRODUCTS MAKES NO OTHER EXPRESS WARRANTIES WITH RESPECT TO THE PRODUCT, ALL EXPRESS AND IMPLIED WARRANTIES FOR THE PRODUCT, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF AND CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE WARRANTY PERIOD SET FORTH ABOVE AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THE WARRANTY PERIOD. SOME STATES, PROVINCES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE OR PROVINCE TO PROVINCE.

Contact Insignia:

1-877-467-4289

www.insigniaproducts.com INSIGNIA is a trademark of Best Buy and its affiliated companies. *Distributed by Best Buy Purchasing, LLC 7601 Penn Ave South, Richfield, MN 55423 U.S.A ©2022 Best Buy. All rights reserved.