


VICTROLA



SETUP VIDEO




ROCK SPEAKER *connect*


INSTRUCTION MANUAL
VOS-600

OVERVIEW

IN THE BOX



CONTROL PANEL



1. POWER BUTTON
2. MULTI-SPEAKER CONNECT BUTTON
3. BLUETOOTH BUTTON

4. POWER LED
5. STATUS LED
6. USB-C PORT

GETTING STARTED

STEP 1: CONNECT TO BLUETOOTH

1. Press and hold Power button for 1 second to turn speaker on.
2. The Status LED should be flashing blue to signify Bluetooth pairing mode.
Note: If the Status LED is flashing green the speaker is in Multi-Speaker Connect mode. Press the Multi-Speaker Connect button to switch to Bluetooth pairing mode.
3. Select **Victrola Rock Speaker** on your device's Bluetooth menu.
Once paired, the Status LED will turn solid blue.

STEP 2: CONNECT ADDITIONAL SPEAKERS

(MULTI-SPEAKER CONNECT MODE)

1. Ensure you have successfully paired one speaker to your Bluetooth device (*Step 1, above*), this will become the Host speaker. Any additional speakers will become Clients.
2. **Host speaker setup:** Quick press the Multi-Speaker Connect button on the Host speaker. The Status LED will turn light blue.
3. **Client speaker(s) setup:** Power on additional an speaker and quick press the Multi-Speaker Connect button. The Status LED will begin flashing green.
4. The additional speaker will search for and connect to the Host speaker and become a Client. The Status LED on the Client will turn solid green once connected to the Host speaker.
5. Repeat steps 3-4 to connect additional Client speakers to the Host speaker.

POWERING OFF

- If you power off a Client speaker, only the Client speaker will power off.
- If you power off a Host speaker, the Host and all connected Client speakers will power off.

FUTURE USE

- When powering back on, speaker will return to last used mode. If speakers were previously paired in Multi-Speaker Connect mode, the Host speaker's Status LED will flash green and blue until connected to a Bluetooth device. Any Clients will automatically search for a previously paired Host and connect automatically, if the host is powered on and nearby.




POWER BUTTON


PRESS & HOLD
 POWER ON / OFF




MULTI-SPEAKER CONNECT BUTTON


QUICK PRESS
 ENABLE/DISABLE MULTI-SPEAKER
 CONNECT MODE



BLUETOOTH BUTTON

QUICK PRESS
 PLAY/PAUSE AUDIO
 (IF A BLUETOOTH DEVICE IS CONNECTED)



PRESS & HOLD
 DISCONNECT BLUETOOTH DEVICE



PRESS & HOLD
 RESET (FORGET ALL DEVICES)



CHARGING VIA USB CABLE

Plug the USB-C end in the control panel, plug the other end of the cable into a USB 5V DC, output AC adaptor (not included).

 POWER LED	
FLASHING WHITE	CHARGING
SOLID WHITE	BATTERY >25%
SOLID RED	BATTERY 25% – 10%
FLASHING RED	BATTERY <10%

 STATUS LED	
BLUETOOTH (SINGLE SPEAKER) MODE	
FLASHING BLUE	BLUETOOTH PAIRING
SOLID BLUE	BLUETOOTH PAIRED
MULTI-SPEAKER CONNECT MODE	
SOLID LIGHT BLUE	HOST BROADCASTING
FLASHING GREEN	CLIENT PAIRING
SOLID GREEN	CLIENT PAIRED
FLASHING GREEN/BLUE	HOST DISCONNECTED SEARCHING FOR NEW BLUETOOTH DEVICE
OTHER	
5 BLUE FLASHES	FACTORY RESET



CHARGING VIA SOLAR PANEL

Place the rock speaker under direct sunlight and make sure the solar panel is facing the sun. The Power LED will flash white when charging.

TROUBLESHOOTING

BLUETOOTH

- The effective distance for an optimal Bluetooth connection is within 33ft (10m).
- If you are unable to pair to the speaker, ensure the speaker is in Bluetooth pairing mode (Status LED flashing blue) and not Multi-Speaker Connect pairing mode (Status LED flashing green).

MULTI-SPEAKER CONNECT

- The effective distance for optimal speaker pairing is within 66ft (20m).
- If a Host speaker becomes disconnected from Bluetooth, it will begin searching for a Bluetooth device (Status LED flashing green and blue). The Client speakers will remain connected to the Host.
- If a speaker is not connected to a Bluetooth device and then enters Multi-Speaker Connect mode, that speaker will automatically become a Client speaker and will connect to/receive audio from a nearby Host and can't connect to a Bluetooth device.
- Only one speaker should be connected to a Bluetooth device in Multi-Speaker Connect mode (Host), the other speakers (Clients) will connect to the Host.
- A Client speaker in multi-speaker connect mode can only play music from a Host. To exit, press the Multi-Speaker Connect button to become a "single" speaker and connect to a Bluetooth device.

CHARGING

- Fully charging the battery on solar power alone may take 15+ hours depending on weather conditions. *See the POWER LED GUIDE for LED charging indication.*
- The solar panel charges best in direct sunlight. However it can also charge the rock speakers in non-direct sunlight, such as cloudy weather.
- It is recommended to fully charge the rock speaker via USB-C and allow the solar panel to keep the speaker charged while outside in use.
- Battery life will vary depending on operation. Loud music with heavy bass will drain the battery faster than spoken word audio.
- If the unit has not been used for a long period of time, the rechargeable battery may be discharged into a "sleep mode." To initialize the battery, it is recommended to charge for longer than 6 hours but DO NOT exceed 24 hours.

CAUTION

The built-in rechargeable battery is not replaceable. Do not remove or replace it, do not throw in the trash or in a fire. Do not dispose device in standard garbage disposal sites. Dispose of device at available Battery Recycling Sites after fully discharging battery. Not doing so may violate local disposal laws and regulations. Please refer to local regulations for proper battery disposal.

SPECIFICATIONS

GENERAL

BATTERY	Built-in rechargeable 18650 3.7V 4,400 mAh lithium battery
BATTERY LIFE	up to 22 hrs (at 50% volume) up to 7 hours (at 100% volume) <i>*Depends on sunlight exposure and audio content played.</i>
USB-C INPUT	5.0V 2.0A
USB-C CHARGE TIME	3.5 hours
SOLAR PANEL INPUT.....	3W
WATER/DUST IP RATING	IP65
DIMENSION	12" W x 10.03" H x 9.64" D 305mm W x 255mm H x 245mm D
WEIGHT	7.36 lbs / 3.34 kg
OPERATING TEMPERATURE RANGE.....	32° – 113°F / 0° – 45°C (CHARGING) 32° – 131°F / 0° – 55°C (IN USE)

BLUETOOTH

VERSION	5.3
SUPPORTS	HFP, A2DP, AVRCP profiles;

Please note: As a result of continual improvements, the design and specifications of this product are subject to change without notice.

Bluetooth is a registered trademark of Bluetooth SIG, Inc.
Other trademarks and trade names are those of their respective owners.

Made In China.

WARNINGS

IMPORTANT SAFETY INFORMATION

1. Read these instructions – All the safety and operating instructions should be read before this product is operated.
2. Keep these instructions – The safety and operating instructions should be retained for future reference.
3. Heed all warnings – All warnings on the appliance and in the operating instructions should be adhered to.
4. Follow all instructions – All operating and use instructions should be followed.
5. Do not use this apparatus near water – The appliance should not be used near large bodies of water or moisture – for example, in a wet basement or near a swimming pool, and the like.
6. Do not attempt to clean the unit with chemical solvents as this might damage the finish. Use a clean, dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacture's instructions.
8. Do not install near any heat sources such as naked flames, lighted candles, radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Protect the power cord from being walked on or pinched particularly at the plugs, convenience receptacles, and at the point where they exit from the apparatus.
10. Only use attachments/accessories specified by the manufacturer.
11. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
12. Unplug the apparatus during lightning storms or when unused for long periods of time.
13. Refer all servicing to qualified personnel, to reduce the risk of electric shock. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



CAUTION/ATTENTION:

RISK OF ELECTRIC SHOCK. DO NOT
OPEN. / ATTENTION RISQUE DE
CHOC ELECTRIFIER. NE PAS OUVRIR.



14. This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of non-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.
 - a. Warning: To reduce the risk of electric shock, do not remove cover (or back) as there are no user-serviceable parts inside. Refer servicing to qualified personnel.
 - b. The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions in the literature accompanying the appliance.
15. The use of the equipment in moderate climate.
16. Please refer the information on exterior bottom/back enclosure for electrical and safety information.
17. CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or an equivalent type.

FCC & IC WARNINGS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

The device must not be co-located or operating in conjunction with any other antenna or transmitter. To maintain compliance with the FCC's RF exposure guidelines, place the product at least 20cm from nearby persons.

IC Radiation Exposure statement

This device complies with RSS247 of Industry Canada. This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

The device must not be co-located or operating in conjunction with any other antenna or transmitter. This device complies with IC radiation exposure limits set forth for an uncontrolled environment. The device should be installed and operated with a minimum distance of 20cm between the radiator and your body.

Cet appareil se conforme à RSS247 de Canada d'Industrie. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes: (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

L'appareil ne doit pas être localisé ou fonctionner avec d'autres antennes ou transmetteurs. Cet appareil est conforme aux limites d'exposition aux rayonnements de la IC établies pour un incontrôlé environnement. L'appareil doit être installé et utilisé avec une distance minimale de 20cm entre le radiateur et votre corps.

WARRANTY

Victrola is a registered trademark of Innovative Technology Electronics, LLC.

United States

Victrola (Innovative Technology Electronics, LLC) warrants to the original retail purchaser that this product will be free from defective materials and workmanship for one (1) year from the date of purchase, subject to the limitations below. This warranty period is not extended if we replace the product.

To obtain a replacement under the terms of this warranty, you must contact the dealer from which it was purchased with your original receipt. If assistance from the dealer from which it was purchased is impossible, you may contact our customer service for warranty assistance at victrola.com/contact.

Except as limited below, if the product proves defective in either material or workmanship within one (1) year from the date of purchase, Victrola will replace the product at no charge. If the product model is no longer available and cannot be replaced with an identical model, Victrola will issue a merchandise credit for the purchase price to be redeemed at victrola.com.

Limitations:

- This limited warranty does not cover failure of the product arising, in whole or in part, from improper installation, storage, transportation, misuse, abuse, accident, neglect, mishandling, unauthorized repair, modification, or wear from ordinary use or environmental deterioration.
- This limited warranty does not cover cosmetic damage, including paint damage, or consequential damage to other components or premises which may result for any reason from the failure of the product.
- This limited warranty is null and void for products not used in accordance with Victrola's instructions.
- This limited warranty terminates if the original retail purchaser sells or otherwise transfers this product.
- This limited warranty is null and void for defects or damage caused by installation or repair performed by any person or entity other than a Victrola authorized installer or dealer.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state, jurisdiction to jurisdiction or country to country. All express and implied warranties for the product, including but not limited to any implied warranties of merchantability and fitness for a particular purpose, are limited in time to the term of this warranty. Some states, jurisdictions or countries do not allow the exclusion of certain implied warranties or conditions, or limitations on how long an implied warranty or condition lasts, so this limitation may not apply to you. Victrola's responsibility for malfunctions and defects in hardware is limited to replacement or repair as set forth in this warranty statement. Victrola does not accept liability for special, punitive, consequential or incidental damages or losses, whether direct or indirect, including without limitation, any liability for third party claims against you for damages or losses or for products not being available for use. The maximum liability for which Victrola may be responsible will be no more than the amount you paid for the product that is the subject of the claim. Some states, jurisdictions or countries do not allow the exclusion or limitation of special, indirect, incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Canada and US Territories

The Warranty on this product shall comply with applicable law when sold to a consumer in Canada or a US Territory. To obtain any applicable warranty service, please contact the dealer from which you purchased the product, or the distributor that supplied the product, with your original receipt.

If assistance from the dealer from which it was purchased is impossible, you may contact our customer service for warranty assistance at victrola.com/contact.

If this product proves defective in either material or workmanship, Victrola will replace the product at no charge. If the product model is no longer available and cannot be repaired effectively or replaced with an identical model, Victrola at its sole option may replace the unit with a current model of equal or greater value.

Outside the U.S, Canada, and US Territories

The Warranty on this product shall comply with applicable law when sold to a consumer outside of the United States, Canada, and US Territories. To obtain any applicable warranty service, please contact the dealer from which you purchased the product, or the distributor that supplied the product, with your original receipt.