


Item # : BU44ABMD

Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkeredison.com


Revised 26/07/2019 (E)

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product.




- VII. Power tools should not be used to assemble this product.





- VIII. Drill may be needed for securing product to wall.

Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	20 pcs
B		Ø15x11mm	Cam lock	18 pcs
C		Ø6x35mm	Cam bolt	18 pcs
D		Ø30mm	Sticker	18 pcs
E		Ø6x50mm	Bolt	2 pcs
F		M 4	Hex Key	1 pc
G		Ø6x12mm	Bolt	8 pcs
H			Connecting iron sheet	4 pcs
J			Shelf support pin	8 pcs
K		Ø4x22mm	Bolt	4 pcs
L			Handle	2 pcs
M		Ø3x17mm	Screw	6 pcs
N			Plastic wedge	6 pcs
P			Hinge	4 pcs
Q			Door stopper	2 pcs
R			Bolt	2 pcs
S		Ø3x15mm	Screw	4 pcs
T		Ø4x32mm	Screw	2 pcs
U			Plastic strap	2 pcs
V			Nut	2 pcs
W			Glue tube	1 pc
X		Ø4x12mm	Screw	28 pcs
Y		Ø3x15mm	Screw	2 pcs



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Using cam bolt (C) secure part (1) , then using screw (S) attach door stopper (Q) to part (1) with Philips head screwdriver as per diagram .

Step 2




Using bolt (G) attach connecting iron sheet (H) into part (3) with hex key (F) ,then secure part (14) into part (3) as per diagram.

Step 3





Insert wooden dowel (A) into parts (2,8,9,14) as per diagram.

Step 4




Insert wooden dowel (A) into parts (4,5,6,7) ,then using cam bolt (C) secure parts (4,5,6,7) with Philips head screwdriver as per diagram.

Step 5





Using cam lock(B) secure parts (4,5) to part (8) , parts (6,7) to part (14) with Philips head screwdriver as per diagram.

Step 6




Using bolt (E) attach part (2) to part (9) with hex key (F) as per diagram.

Step 7




Align and attach the part (3) to assembly side frame, Using two bolts (G) per connecting iron sheet (H) with hex key (F) ,then using cam lock(B) secure part (2) to parts (6,7) with Philips head screwdriver as per diagram.

Step 8





Repeat the last action as per diagram.

Step 9






Put part (11) into parts (2,4,6) as per diagram.

Step 10




Using cam lock(B) secure part (1) to parts (8,9,14) with Philips head screwdriver as per diagram.

Step 11






Using screw (M) secure plastic wedge (N) to part (11) with Philips head screwdriver as per diagram.

Step 12




Place sticker (D) cover the holes as per diagram .

Step 13




Insert shelf support pin (J) into parts (8,9,14) as per diagram. Make sure you place the four shelf support pins (J) in the same level. So the shelf is not titled .Put part (10) into unit as per diagram. Tilt and rest the adjustable shelf(10) onto the shelf support pins .

Step 14




Using screw (X) attach hinge (P) into parts (12,13) with Philips head screwdriver as per diagram.

Step 15




Using screw (K) attach handle (L) into parts (12,13) ,and secure bolt (R) into parts (12,13) with Philips head screwdriver as per diagram.

Step 16




Using screw (X) attach hinge (P) into part (7) with Philips head screwdriver as per diagram.

Step 17




Using screw (X) attach hinge (P) into part (5) with Philips head screwdriver as per diagram.

Step 18



Position the assembled unit at the desired location .If necessary, adjust the floor leveler at the bottom of the leg to the level the unit .


Step 19



Using screw (Y) attach plastic strap (U) into part (1) with Philips head screwdriver as per diagram.


Step 20

WARNING




Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.

Wall



Using screw (T) attach plastic strap (U) into nut (V) to wall with Philips head screwdriver as per diagram.

Step 21



Final Assembly