We love that you are rocking JLab Audio!
We take pride in our products and fully stand behind them.

FLEX WIRELESS HEADPHONES

SATISFACTION 30 DAY GUARANTEE

YOUR SATISFACTION IS GUARANTEED
You may exchange or return merchandise purchased within 30 days of the purchase date. Please return the item to the location you purchased it. If your item has been opened or used, restrictions may apply.

LIMITED ONE YEAR WARRANTY 1

YOUR WARRANTY
You may register your product at **jlabaudio.com/register**. All warranty claims are subject to JLab Audio authorization and at our sole discretion. Retain your proof of purchase to ensure warranty coverage.

U.S. BASED CUSTOMER SUPPORT

CONTACT US
Reach out to us at **support@jlabaudio.com** or visit **jlabaudio.com/contact**.

ACCESSORIES

FLAT TANGLE-FREE AUX CABLE

TRAVEL CASE

MICRO USB CABLE

HEADPHONE PORTS / BUTTONS

LEFT EARCUP

VOLUME UP / TRACK FORWARD

VOLUME DOWN / TRACK BACKWARD

POWER ON / OFF

3.5MM JACK

NOISE CANCELING ON / OFF

RIGHT EARCUP

MIC

MICRO USB INPUT

AUDIO BURN-IN

Burn-in is the process for exercising new audio equipment. Most headphones require at least 40 hours of burn-in time to reach their optimal performing state. The main purpose of the burn-in process is to loosen the diaphragm of a newly crafted headphone and to stress the headphone driver. Most audiophiles agree that the sound quality will be noticeably improved after burn-in.

**Burn-in your audio equipment with the JLab Audio app available on the App Store and Google Play**
Or download our burn-in method at: **jlabaudio.com/pages/audio-burn-in**

CHARGING

Note: For optimum performance, charge overnight with Micro USB cable prior to using.

Connect the Micro USB to the headphone and connect the USB into a computer or AC adaptor (not included). Make sure the USB connection has a power output source.

Solid red light indicates the headphone is charging. When it **turns off**, charging is complete. Allow about 3-4 hours to fully charge.

OR

POWER / BLUETOOTH FUNCTION

1 When the Flex Wireless headphones are powered off, press and hold the Power button for approximately 3 seconds. Voice prompts "Hello".

2 Once powered on, the headphones will automatically go into pairing mode. **Fast blinking blue indicator light** indicates searching for Bluetooth device.

3 Search for JLab Flex BT on your Bluetooth device and connect.

4 When the headphones are paired, voice prompts "You are connected" and **blue indicator light will flash slowly**.

JLab Flex BT

Notes:

• Bluetooth is a wireless radio technology, which means it is sensitive to objects between the headphone and the connected device. The headphone is designed to be used within 33 feet (10 meters) of a connected device, with no major objects in between (walls, etc.).

• Once successfully connected, the headphone will memorize your device and automatically pair when turned on in the future. Only one device may be connected at a time. To pair a different device, first unpair the current one through its Bluetooth settings.

• If for any reason Bluetooth connection is lost, manually reconnect your Bluetooth device.

BUTTON FUNCTIONS

NOISE CANCELING ON / OFF

3.5MM JACK / AUX IN

POWER ON / OFF

1 CLICK:
PLAY / PAUSE
ANSWER / HANG UP

2 CLICK:
ACTIVATE SIRI* (iOS)
OR "OK GOOGLE"
(ANDROID)

5 SEC HOLD:
BLUETOOTH PAIRING

VOLUME + TRACK CONTROL

1 CLICK:
VOLUME UP /
VOLUME DOWN

2 SEC HOLD:
TRACK FORWARD /
TRACK BACKWARD

*Siri is a registered trademark of Apple Inc. and is no way affiliated with this promotion.

AUX IN FUNCTION

Connect the AUX cable to the Flex Wireless 3.5mm Jack/AUX input port and your device to use as a non-Bluetooth headphone. Flex Wireless does not need to be turned on for AUX function. However, the button functions will not function while in AUX mode. Functions will be controlled solely from your device.

CAUTIONS

• Avoid getting moisture or liquids on the headphone cups.

• Avoid extreme heat, cold, and humidity.

• Avoid dropping or crushing headphones, stressing the cable by rapid pulling or extreme force, or bending the cable at a sharp angle.

• Wax may build up in headphone cups, lowering the sound quality. Carefully remove the wax with a cotton swab or other small tool to improve the sound quality.

• If you experience discomfort or pain, try lowering the volume or discontinuing use temporarily.

• If you experience regular discomfort while using this product, discontinue use and consult your physician.

• We recommend you treat your headphones as you would a nice pair of sunglasses and keep them in safe location when not in use.