

QUICK SETUP GUIDE

Grounded
Travel Adapter

NS-MNSA2U-C



FEATURES


CAUTION: This product does not convert electrical voltage.

- Compact design for easy portability
- Universal plug connects electronics across many regions (for type A, B, C, D, E, F, G, H, I, J, M, or N plugs)
- 2 USB ports with 15 W (5 V/3 A) total output to charge your devices quickly
- Designed for travelers coming to North and South America

PACKAGE CONTENTS

- Grounded Travel Adapter
- *Quick Setup Guide*

NOTE: The universal socket works with many types of plugs. However, the universal socket is not a voltage converter. If the voltage in the area does not match U.S. voltage, you need a voltage converter.



MAKING SURE THAT YOUR DEVICE IS COMPATIBLE

WARNING: Failure to check the correct voltage could damage your device.

- 1 Determine the voltage of the power outlet you want to use. See Step 4 for common voltages.
- 2 Check the voltage of the device you want to connect to the power outlet.
- 3 Compare the power outlet voltage to your device's voltage.

Notes:

- The voltage of some devices may be a range (for example, a 120–240 V device and a 240 V power outlet).
- If your device has a dual voltage switch, slide it to the correct voltage.

- 4 Find the power outlet voltage in the table.

- If your device's wattage is less than or equal to the corresponding max device wattage, you can use this adapter with your device.
- If your device's wattage is greater than the corresponding max device wattage, you CANNOT use this adapter with your device. You must purchase a converter to power your device.


POWER OUTLET VOLTAGE:	MAX DEVICE WATTAGE:
100 V	1000 W
120 V	1200 W
220 V	2000 W
240 V	2000 W

USING YOUR ADAPTER

1 Make sure that your power adapter and power outlet are compatible.


2 Connect a USB charging cable from your adapter to your device, then connect your adapter to a power outlet.

The power indicator lights up. Use or charge your device as usual.



OR

To connect a device with a plug that does not fit the power outlet, plug the device into the universal socket and the adapter into the power outlet. The power indicator lights up. Use or charge your device as usual.



BE
CAREFUL!

Check out these important safety instructions to keep yourself and your devices safe.

- Before using the adapter, check the product you intend to connect to the adapter for the manufacturer's voltage and wattage rating, which should be located on the product.

CAUTION: This adapter does not convert voltage. To avoid damaging your device, make sure that the power outlet you intend to use has the proper voltage rating to run your device BEFORE using this adapter.

- Do not leave the adapter in the power outlet when not in use.
- Do not continue to use the adapter if it is not working properly, has been damaged, or has been dropped in water.
- This product may not work with certain high power appliances, such as hair dryers. Check your device label to make sure that it does not require more than 10 A. If it does, do not use your device with this adapter.

WARNING: This product is intended for adult use. This product is NOT intended for use by unsupervised children. Choose proper settings and plug in this product before directly supervising children using devices connected to this product.

LEGAL NOTICES

FCC Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if it is not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ICES-003 Statement

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

SPECIFICATIONS

- AC power rating:** 10 A max. 100–240 VAC (1100 W max. at 110 V, 2000 W max. at 230 V)
- USB charging ports:** +5 VDC, 3 A total
- Output AC power outlet:** Support IEC World Plugs Type A/B/C/D/E/F/G/H/I/J/M/N plugs



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority for recycling advice.

ONE-YEAR LIMITED WARRANTY

For complete warranty, visit www.insigniaproducts.com.

QUEBEC AVAILABILITY GUARANTEE

For Quebec Residents Only: No guarantee of replacement parts, repair services, or maintenance/repair information. Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA

1-877-467-4289 (U.S. and Canada)

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies

BEST BUY Distributed by Best Buy Purchasing, LLC
Richfield, MN 55423
©2025 Best Buy. All rights reserved.