



Mercedes-Benz S Class 2000-2006

Visit MetraOnline.com for more detailed information about the product and up-to-date vehicle specific applications


KIT FEATURES

- ISO DDIN radio provision
- 95-8734B is scratch resistant matte black
- 95-8734W is woodgrain


KIT COMPONENTS

- A) Radio trim panel • B) Radio brackets • C) Panel brackets • D) #6 x 3/8" Phillips screws (2) • E) Panel clips (2)


A



B



C



D



E




TABLE OF CONTENTS

| | |
|------------------------|---|
| Dash Disassembly | 2 |
| Kit Preparation | 3 |
| Kit Assembly | 3 |

WIRING & ANTENNA CONNECTIONS (sold separately)

Wiring Harness: Visit metraonline.com for harness and interface information

Antenna Adapter: 40-VW12 or 40-EU10

TOOLS REQUIRED


- Panel removal tool • Phillips screwdriver
- Torx T20 screwdriver

Attention! Let the vehicle sit with the key out of the ignition for a few minutes before removing the factory radio. When testing the aftermarket equipment, ensure that all factory equipment is connected before cycling the key to ignition.


DASH DISASSEMBLY

2000-2002


1. Open the ashtray compartment door, remove (2) Torx T20 screws securing the ashtray assembly, then remove and unplug the ashtray assembly. (Figure A)
2. Unclip, unplug, and remove the climate control panel surrounding the radio, then remove the panel. (Figure B)
3. Remove (4) Torx T20 screws securing the radio, then unplug and remove the radio. (Figure C)



(Figure A)



(Figure B)




(Figure C)


2003-2006

1. Open the ashtray compartment door, remove (2) Torx T20 screws securing the ashtray assembly, then remove and unplug the ashtray assembly. (Figure A)
2. Unclip, unplug, and remove the climate control panel, then remove the panel. (Figure B)
3. Unclip and remove the trim panel above the radio. (Figure B)
4. Remove (4) Torx T20 screws securing the radio, then unplug and remove the radio. (Figure C)


Continue to Kit Preparation



(Figure A)



(Figure B)




(Figure C)


KIT PREPARATION

1. Attach the **panel brackets** to the **radio trim panel** with the two supplied #6 x 3/8" Phillips screws. (Figure A)
2. Secure the climate control to the **radio trim panel** with the factory screws. (Figure B)

Continue to Kit Assembly




(Figure A)




(Figure B)

KIT ASSEMBLY

1. Attach the (2) supplied **panel clips** to the radio housing. (Figure A)
2. Attach the **radio brackets** to the radio using screws supplied with the radio, and then secure into the dash opening. (Figure B)
3. Locate the factory wiring harness and antenna connector in the dash, and complete all necessary connections to the radio. Metra recommends using the proper mating adapter from Metra and/or AXCESS. Re-connect the negative battery terminal and test the radio for proper operation.
4. Snap the **radio trim panel** over the radio and reassemble the dash in reverse order of disassembly.



(Figure A)



(Figure B)



95-8734
INSTALLATION INSTRUCTIONS



Having difficulties? We're here to help.



Contact our Tech Support line at:

386-257-1187



Or via email at:

techsupport@metra-autosound.com

Tech Support Hours (Eastern Standard Time)

Monday - Friday: 9:00 AM - 7:00 PM

Saturday: 10:00 AM - 7:00 PM

Sunday: 10:00 AM - 4:00 PM



® KNOWLEDGE IS POWER

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow.



**Metra recommends MECP
certified technicians**