
Item: TW72DSW

Assembly Instructions






Please visit our website for the most current instructions, assembly tips, to report damage or request parts. www.walkeredison.com

Revised 07/2023-V2

General assembly guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are wood dowels, screws and bolts.
- V. A hammer, a Phillips head screwdriver and a tape measure are required of this product.








Tape measure

VI. Power tools should not be used to assemble this product.



Parts List 7

Part #	Description	Qty	
1	Foot Post	04 pcs	
2	Lower Batten	02 pcs	
3	Upper Batten	02 pcs	
4	Lower Center Batten	01 pc	
5	Upper Support Rail	02 pcs	
6	Upper Center Batten	01 pc	
7	Side Top Panel	02 pcs	
8	Center Top Panel	01 pc	

Hardware List

А	θ			10 pcs
В		ø7*70mm	Bolt	08 pcs
С	(a) (b) (c) (c) (c) (c) (c) (c) (c) (c) (c) (c	ø1/4'*50mm	Bolt	08 pcs
D		ø7*50mm	Bolt	02 pcs
Е		ø4*50mm	Screw	23 pcs
F		ø8*30mm	Wooden dowel	26 pcs
G		ø1/4"	Barrel nut	10 pcs
Н			Plastic foot	04 pcs
I		M4	Hex key	01 pc

Hammer recommended for assembly (not included)

Philips head screwdriver required for assembly (not included)

Tape measure required for assembly (not included)

The hardware quantities listed above are required for proper assembly. Some extra hardware may also have been included.

