

NIGHT OWL®

Quick Setup Guide

Let's get started

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause internal Chemical Burns in as little as 2 hours.
- Keep new and used batteries **OUT OF REACH OF CHILDREN**
- Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.



Caution:

- a) Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- b) Even used batteries may cause severe injury or death.
- c) Call a local poison control center for treatment information.
- d) Non-rechargeable batteries are not to be recharged.
- e) Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.

*The product contains non-replaceable batteries.

*Battery type: CR1220

*Battery nominal voltage: 3V

What's Included

Wireless Hub



(1) 8 Channel
Wireless Hub



(1) Hub Power
Adapter



(1) 6 ft. Ethernet
Cable



(1) Large Window
Sticker




(1) 64GB
microSD Card
(may not be included
with ALL models)

Cameras

Your hub is compatible with multiple Night Owl® Wi-Fi devices. The Wi-Fi devices included with your system will vary based on your model number.

Items Not Included



Monitor
(Not required for Bluetooth® Setup)





Router / Network
Access Point


NOTE: If connecting to a TV or Monitor (Not Required), it must have a minimum resolution of 1080p HD. Use all of the included Night Owl accessories.

Third-party accessories may not work correctly.

Hub Details



microSD
Card Slot




HDD
Tray

Pre-Setup Checklist

To ensure you do not experience any issues getting your hub and cameras connected, please do the following:

1. Verify your home Wi-Fi network is working.
2. Make sure you have your network's name and password.
3. Place the hub in a central location within range of where your cameras will be installed.
4. DO NOT place the hub near large metal objects or sources that may interfere with the signal (such as a microwave).




Placement Tips

Refer to the following tips when placing your new hub to ensure you do not face any signal issues.

1. Central Location: Place the hub in a central location in your home for even signal distribution.
2. Elevated Position: An elevated position, free from obstructions, can enhance signal strength.
3. Avoid Interference: Keep the hub away from devices that can cause interference, such as microwaves, cordless phones and large metal objects.
4. Proximity to Connected Devices: Ensure the hub is within a good range of the devices it needs to connect to, especially important for devices like security cameras.
5. Minimize Obstacles: Thick walls, ceilings and floors can obstruct Wi-Fi signals. Try to minimize the number of these barriers between the hub and connected devices.
6. Avoid Extremes: Keep the hub away from areas with extreme temperatures and humidity to protect its hardware.

Step 1: Power on the Hub


Connect the power cord to the hub and then plug the adapter into a nearby outlet.



Step 2: Ethernet Cable

Using the provided 6 ft. Ethernet cable, connect one end to the hub and the other end to your router.

IMPORTANT: The hub **MUST** be connected to your router via Ethernet cable for initial setup. Once completed, you can remove the cable for a wireless connection.



Step 3: Download the Night Owl App

If you are a first-time user, go ahead and download the Night Owl app. Quickly create an account and log in.

Already have an account? Simply log in.



Step 4: Scan the QR Code

While logged into the app, use your smart device's camera to scan the QR code on the hub.

The app will then walk you through the remaining steps needed to connect your hub.



Step 5: Firmware Update

During setup, you may be prompted to update the hub's firmware. Firmware updates maintain the overall health of your device.

IMPORTANT: DO NOT power off the hub while the firmware is being updated



Step 6: Adding your Cameras


This hub is compatible with multiple Night Owl Wi-Fi devices. When you choose to add a new camera, the app will ask you what type and walk you through the setup steps.

However, you can also scan the QR code below for more in-depth step-by-step instructions.




Step 7: Testing your Cameras

Ensure you test the connection and functionality of each camera you connect before you mount them. Check for signal strength in the desired placement location and adjust the placement if needed.



Step 8: microSD Card Setup

1. Insert the microSD card into the slot at the bottom of the hub.
2. Within the Night Owl app, go to the hub settings to quickly format the microSD card.




Hard Disk Drive Storage (Optional)

The hub can accommodate a 2.5" internal SATA HDD (Hard Disk Drive) for increased storage. You can purchase a compatible HDD from Night Owl.


To install: (a) unplug the wireless hub's power supply, (b) remove the top cover on the hub, (c) pull out the HDD tray, (d) put the HDD in the tray, (e) secure the HDD using the screws and screw holes, (f) reinsert the HDD tray into the hub and replace the top cover, (g) reconnect the wireless hub's power supply, and (h) go to the hub settings in the app to quickly format the HDD.

IMPORTANT: If both a microSD Card and HDD are inserted, the hub will default all recordings to the HDD. HDD size is limited to 2.5" and cannot support SSDs.



TV or Monitor Viewing (Optional)

To view and access your hub from a TV or monitor, simply connect an HDMI cable (not included) from the hub to your TV or monitor. You can use the app to adjust the layout.




Transfer Recordings to a USB Drive

You can easily transfer your recordings to a USB drive for long-term storage or sharing. To do this:


1. Insert a USB flash drive into the USB port on the rear of the hub.
2. Go to the hub settings within the app to transfer the selected recordings.

IMPORTANT: Hub supports up to USB 2.0 with FAT32 file system.



LED Status Lights

LED Status	Hub Status
Solid RED	Powered ON but NOT paired to the app
Solid BLUE	Powered ON and paired to the app
Quickly Flashing BLUE	Configuring network and adding camera
Slowly Flashing BLUE	Networking failed
Flashing RED and BLUE	Firmware is being updated



Troubleshooting

1. Hub Not Connecting to Wi-Fi:
 - Ensure the Wi-Fi network is working by checking other devices.
 - Verify that you entered the correct Wi-Fi password.
 - Restart the hub and try reconnecting.
2. Devices Not Pairing with Hub:
 - Check if the devices are compatible with the hub.
 - Ensure devices are within range of the hub.
 - Restart both the hub and the devices, then attempt to pair again.
3. Firmware Update Issues:
 - Ensure the hub is connected to the Internet.
 - Do not unplug the hub during an update, a flashing blue and red light means it is correctly upgrading firmware.
 - If the update fails, restart the hub, and try again.
4. Loss of Connection or Poor Signal:
 - Avoid placing the hub near metal objects or electronic devices that can cause interference.
 - Move the hub to a more central location in your home.

Factory Reset

Resetting the hub to factory default will erase all settings and require you to set up the hub all over again. We recommend this as a last resort.

To perform, simply hold the reset button down for 3 seconds.

Maintenance Tips

1. Regular Firmware Updates:
 - Keep the hub firmware up to date for security and performance improvements.
 - Turn on automatic updates if available.
2. Physical Maintenance:
 - Dust the hub periodically to ensure proper ventilation.
 - Keep the hub in a dry, temperature-controlled environment.
3. Regular Checkups:
 - Periodically check the status of connected devices.

Need Help?



For more help, please follow the steps below to access your Series support page:

1. Please visit: Support.NightOwlISP.com
2. Enter **FWR8** into the Search bar or scan the QR Code

FCC RADIATION NORM

FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Compliance Statement These limits are designed to provide reasonable protection against frequency interference in residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed or used in accordance with the instructions, may cause harmful interference to radio communication.

However, there is no guarantee that interference will not occur in television reception, which can be determined by turning the equipment off and on. The user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION!

The Federal Communications Commission warns the user that changes or modifications to the unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment should be installed and operated with a minimum distance of 8 inches between the radiator and your body.