

QUICK SETUP GUIDE

Multi-Directional Flat HDTV Antenna

NS-ANT715

This is a specially designed antenna for digital over-the-air TV broadcast reception. It can receive all of the TV signals available in your area in the VHF and UHF bands.



Stand

PACKAGE CONTENTS

- HDTV antenna
- Antenna stand
- *Quick Setup Guide*

FEATURES


- Receive free local HDTV broadcasts
- Flat profile design fits with any decor
- Multiple placement options: stand mount, lay flat, or hang on wall
- 5.4 ft. (1.6 m) integrated coaxial cable

Before using your new product, please read these instructions to prevent any damage.

SETTING UP AND USING YOUR ANTENNA

Positioning the antenna

1 Choose a mounting method:




2 If possible, place your antenna near a window and away from sources of interference.

Connecting the antenna

If you have an HDTV with a digital TV (ATSC) tuner, you can connect the antenna directly to the HDTV. Older TVs may require a separate digital TV tuner, or digital converter box.

1 Connect the end of the antenna's coaxial cable to the coaxial jack on the back of your TV digital converter box, or set-top box.


Connect to an HDTV



OR

Connect to a TV through a digital converter box

Note: See the instructions for your digital converter box for connection steps.



- 2 Turn on your TV, then press **INPUT** or **SOURCE**. Select the input for your antenna (usually labeled TV).
- 3 Open your TV's Setup menu, then select the "scan" or "channel scan" option. Your TV automatically searches for available channels in your area. Refer to your TV manual for detailed instructions.

For the best reception, check the following conditions:

- Keep the antenna away from sources of interference, such as air conditioners, elevators, hair dryers, or microwave ovens.
- Place the antenna near a window when using in an indoor environment.
- Install the antenna as high as possible to avoid possible obstacles between the antenna and transmission tower. Obstacles may cause temporary signal loss.
- Run a channel scan every time you move your antenna.
- If possible, position your antenna toward the transmission tower.
- To determine which channels are available in your area, visit www.antennaweb.org. Type in your zip code to get help with antenna placement.
- Test the antenna in multiple locations to find the strongest signal.
- This antenna is an indoor antenna. Do not place it outside.
- Run a channel scan monthly to make sure that you are receiving all possible channels.
- Some TVs have a signal strength indicator that can help with antenna placement. See your TV manual to see if your TV has this feature.
- This antenna works with any TV or device with an ATSC tuner. Refer to the device manual to check compatibility.

TROUBLESHOOTING

PROBLEM	SOLUTION
Cannot find any channels	<ul style="list-style-type: none"> • Make sure that you have selected the correct input on your TV. • Go to the menu on your TV or set top box, such as a cable/satellite box or streaming media device, and rescan the channels. • Make sure that all your connections are correct and secure. • Adjust your antenna, then rescan for available channels on your TV or set top box. • Make sure that you are connected to a TV or set top box with an ATSC tuner.
Picture quality is good on some channels and poor or no reception on others	<ul style="list-style-type: none"> • Adjust your antenna, then scan for available channels on your TV or set top box. • Keep the antenna away from sources of interference such as air conditioners, hair dryers, and microwave ovens. • Your antenna may be too far from the broadcast antenna to receive an adequate signal. The signal may also be affected by obstructions between the broadcast antenna and your antenna. • Make sure that the signal strength from the antenna is adequate. Some TVs have a signal strength indicator. See your TV manual to see if your TV has this feature. • If you use a UHF/VHF amplifier to boost the signal level, make sure that it is operating correctly.
I don't know what digital TV reception I get in my area	<ul style="list-style-type: none"> • To determine which channels are available in your area, visit www.antennaweb.org. Type in your zip code to get help with antenna placement.
Not all channels are available after performing a channel scan	<ul style="list-style-type: none"> • Adjust your antenna, then scan for available channels on your TV or set top box. • Make sure that the signal strength from the antenna is adequate. Some TVs have a signal strength indicator. See your TV manual to see if your TV has this feature.

SPECIFICATIONS

- Frequency range:
 - VHF 174-230 MHz
 - UHF 470-860, MHz
- Receiving range: UHF/VHF

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

For customer service, call 1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)
www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies
 Distributed by Best Buy Purchasing, LLC
 7601 Penn Ave South, Richfield, MN 55423 U.S.A.
 ©2019 Best Buy. All rights reserved.
Made in China