


Item # : B48CLY

Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkeredison.com


Revised 10/07/2019 (E)

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product.




- VII. Power tools should not be used to assemble this product.















- VIII. Drill may be needed for securing product to wall.

Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	4 pcs
B		Ø15x11mm	Cam lock	4 pcs
C		Ø6x35mm	Cam bolt	4 pcs
D		Ø30mm	Sticker	4 pcs
E		M 4	Hex Key	1 pc
F		Ø6x12mm	Bolt	2 pcs
G		Ø6x25mm	Bolt	12 pcs
J			Shelf support pin	4 pcs
K		Ø4x38mm	Screw	2 pcs
L			Plastic wedge	3 pcs
M		Ø3x17mm	Screw	3 pcs
N			Glue tube	1 pc



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Using cam bolt (C) secure part (1) with Philips head screwdriver as per diagram.

Step 2





Insert wooden dowel (A) into parts (6,8) and screw cam bolt (C) into designated hole on the side panel as per diagram.

Step 3




Using bolt (G) secure parts (4,5) into parts (2,3,10) with hex key (E) as per diagram.

Step 4




Attach and align the bottom panel (8) to side panel (6) using cam lock (B).

Step 5





Using screw (K) secure part (5) into part (8) with Philips head screwdriver as per diagram.

Step 6






Put part (9) into parts (5,6,8) as per diagram.

Step 7




Position the Top Panel (1) onto the inserted Wooden Dowels and fasten it in place with Cam Lock (B) and Bolts (F, G) as per diagram.

Step 8






Using screw (M) secure plastic wedge (L) with Philips head screwdriver as per diagram.

Step 9




Place sticker (D) cover the holes as per diagram.

Step 10



Put shelf support pin (J) into parts (5,6) ,then put part (7) into cabinet as per diagram.

Step 11



Final Assembly