



STOP: Only install a camera in its final location AFTER it's paired and setup is complete.

Flexible Setup Options:

Option 1:

Standalone Camera - Connecting to your Wi-Fi Network:

- 1 First Time User? Download the Night Owl app. Create an account and log in with your username and password. Already have an account? Log in with your username and password!
- 2 Tap "Add New" or "+" and the app will guide you through the setup process.



Option 1
Scan for More Detail

Download the Night Owl App



GET IT ON
Google Play



Download on the
App Store

Option 2:

Add on Camera - Connecting to your Night Owl Recorder:

2a Wired Bluetooth® Recorder:

IMPORTANT - To add a Wi-Fi IP camera to your wired recorder both devices must be connected to the same Internet (Local Area Network).

- 1 Ensure your wired recorder has been added to your Night Owl account.
- 2 Power on your new Wi-Fi IP camera using the provided power adapter.
- 3 Log in to the Night Owl app from your Smart Device.
- 4 Tap on "Add New" or "+" and follow the simple on-screen steps.



Option 2a
Scan for More Detail

NOTE: Scan the QR Code for more information on compatibility and detailed setup steps.

2b Wi-Fi Bluetooth® Recorder

- 1 Power on your new Wi-Fi IP camera using the provided power adapter.
- 2 Log in to the Night Owl app from your Smart Device.
- 3 Tap on your existing Wi-Fi recorder.
- 4 Tap on "Add New" or "+" to add your new Wi-Fi IP camera.
- 5 Follow the on-screen steps to pair your new Wi-Fi IP camera.



Option 2b
Scan for More Detail

NOTE: The camera can also be set up without the app by logging into your Wi-Fi recorder. Scan the QR Code for more information on compatibility and detailed setup steps for both methods.

Product images may vary slightly based on your model, but the setup steps will be the same.





Need Help?

Why call? Our 24/7 online support site has it all!

For system manuals, troubleshooting guides, FAQs, video tutorials and more:

- 1 Please visit **Support.NightOwlSP.com**
- 2 Enter **FWIP4** (for our 2K Wi-Fi IP Cameras) or **FWIP8** (for our 4K Wi-Fi IP Cameras) into the Search bar.

FCC RADIATION NORM

FCC
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Compliance Statement These limits are designed to provide reasonable protection against frequency interference in residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed or used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in television reception, which can be determined by turning the equipment off and on. The user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION!
The Federal Communications Commission warns the user that changes or modifications to the unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment should be installed and operated with a minimum distance of 8 inches between the radiator and your body.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

*RF warning for Mobile device:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. A distance between the surrounding area and the top surface of the device is greater than 20cm.

www.NightOwlSP.com